


TTR05 Guidance & Alternate Details


Standard Drawing Guidance (Do not show on plans)


- ① Large skews may require additional R1 bars.
- \bigcirc 6" min., 12" max. to avoid anchor bolts by $1\frac{1}{2}$ " min.



Use for shallow superstructure where 27" embedment is not possible. (Shape 6 with E=12")


Post spacing guidance:





SECTION BETWEEN CURBS

Copy and paste this detail to Bridge Approach Slab sheet to replace Section Between Curb and Barrier. This detail is scaled to match the scale of the MAJOR Bridge Approach Slab sheets.



Copy and paste this detail to Bridge Approach Slab sheet to replace Section Between Curb and Barrier. This detail is scaled to match the scale of the MINOR Bridge Approach Slab sheet.