

STRIP01 psi end Effective: July 2024 Supersedes: July 2020




## STRIP01\_psi\_end Guidance & Alternate Details


- Standard Drawing Guidance (do not show on plans):
- Modify drawing as necessary.
- Remove non-applicable rows in table.
- A Piece angle length to center of first slotted hole.
- $\bigoplus$  Use squared, left advanced or right advanced Part Plan as needed.
- $\bigcirc$  = 3/4" (Min.)  $\bigcirc$  60°. Verify only. Do not show on plans.
- $\bigcirc = (1 \odot 60^{\circ} + 1/2" + 3/4" (Min.))$ . Verify only. Do not show on plans.
- (E) Remove precast panel for CIP slab.











1/2"Ø Machine Bolt at about 18" cts. (Cut machine bolt flush with steel armor after concrete on each side has taken

€ Prestressed Ğirder

Piece Angle 6 x 3 1/2 x 3/8 (See Detail B)