

Missouri Department of Transportation David B. Nichols, Director

105 West Capitol Avenue P.O. Box 270 Jefferson City, Missouri 65102

573.751.2551 Fax: 573.751.6555

1.888.ASK MODOT (275.6636)

# ADDENDUM 002 KC District Pole Barns Request for Bid 9-131122TV

Bidders should acknowledge receipt of Addendum 002 (TWO) by **signing** and **including it** with the original bid. The due date for receipt of bids remains **unchanged** by this Addendum. Accordingly, the following clarifications, questions and answers are believed to be of general interest to all potential bidders. All other terms and conditions remain unchanged and in full force.

Name and Title of Signer	Name and Title of Department
(Print or type)	Authority
	N
	Name: Tom Veasman
	Title: Sr. General Services Specialist
District Co.	
Bidder Signature	Department of Transportation
	Jon Hearman
(Signature of person authorized to sign)	(Authorizing Signature)
	·
Date Signed:	Date Signed: November 6, 2013

Included with the Request for Bid document was Specification 13125 Pre-Engineered Pole Structures. Specification 13125 included the following language pertaining to gutters:

Gutters and Downspouts:

See Specification 07712. Paint finish as roofing and siding panels and to be selected by owner.

Specification 07465 - Aluminum Soffit Panels and Specification 07631 - Gutters and Downspouts are included in this addendum and should be used in lieu of 07712.



#### 07465

### **ALUMINUM SOFFIT PANELS**

#### PART 1 GENERAL

#### 1.1 SECTION INCLUDES

A. Preformed aluminum soffit panels, trim, and accessories for enclosing exterior roof overhangs,

#### 1.2 REFERENCES

- A. AAMA 1402-86 Aluminum Siding, Soffit, and Fascia.
- B. ASTM B 209 Aluminum and Aluminum-Alloy Sheet and Plate.
- C. ASTM D 226 Asphalt-Saturated Organic Felt Used in Roofing and Waterproofing.
- D. ASTM E 84 Surface Burning Characteristics of Building Materials.

## 1.3 PERFORMANCE REQUIREMENTS

- A. Soffits shall be fabricated and installed to withstand positive and negative wind pressure loads in accordance with applicable codes.
- B. Soffit system to accommodate without damage to components or failure of weather barrier movement caused by seasonal temperature cycling and deflection of structural support framing.
- C. Moisture entering or condensation occurring within soffit system shall drain to exterior.

### 1.4 SUBMITTALS

- A. Provide in accordance with Section 01300:
  - 1. Product data including material descriptions, dimensions, and profiles.
  - 2. Shop drawings showing layout, location of vents, dimensions, penetrations, trim, and installation methods.
  - 3. 4 inch long minimum samples of soffit panel and trim in color selected.
  - 4. Certificates documenting soffit system complies with requirements specified.
  - 5. Manufacturer's installation instructions.
  - 6. Copy of warranty for review by Architect.

## 1.5 QUALITY ASSURANCE

- A. Manufacturer: Company with a minimum 5 years' successful experience manufacturing aluminum soffit.
- B. Single Source Responsibility: To ensure functional and appearance compatibility, soffit panels and all trim pieces shall be products of single manufacturer.
- C. Aluminum soffit system shall be fabricated and installed to comply with:
  - 1. AAMA 1402-86.
  - 2. International Code Council-ES Legacy Report No. 97-64.
  - 3. International Conference of Building Officials (ICBO): Report No. 2027.

## 1.6 PRODUCT HANDLING

- A. Deliver components in manufacturer's protective cartons clearly labeled as to specific products contained.
- B. During delivery and storage keep cartons flat and supported along entire length.
- C. Store material off ground, out of weather, in dry place. Provide ventilation. Protect from falling objects and construction activities.
- D. Handling: Avoid gouging, scratching, and denting.

#### 1.7 WARRANTY

A. Provide under provisions of section 01780 – Closeout Submittals: Fifty (50) year lifetime limited, non-prorated, transferable warranty.

### PART 2 PRODUCTS

## 2.1 MATERIALS

- A. Fabricate soffit panels and trim from sheet aluminum complying with ASTM B 209, AA3000 Allov:
- B. Minimum Aluminum Properties:
  - 1. Ultimate Strength: 25 KSI.
  - 2. Yield Strength: 22 KSI.
  - 3. Modulus of Elasticity: 10,000 KSI.
  - 4. Coefficient of Linear Thermal Expansion: 1.31 x 10(-5) inch/inch/degree F.
  - 5. Melting Range: 1175 to 1210 degrees F.

# 2.2 SOFFIT PANELS

- A. Type: Fully vented, hi-tensile, double V-groove soffit panel with installation flanges along both edges.
  - 1. Dimensions: 12 inches exposed width by 144 inches long.
  - 2. Thickness: 0.016 inches.
  - 3. Profile: V-grooves forming three (3) 4-inch wide panels with all panels vented.
  - 4. Net Free Open Area: 11.6 square inches per linear foot.
  - 5. Surface: Smooth.
  - 6. Finish Color: White.

#### 2.3 TRIM

- A. Provide trim pieces as detailed on manufacturer's installation manual and as required for complete, weathertight, functional installation.
- B. Aluminum Trim: Fabricate from same material as soffit to shape, dimensions, and profile required to accommodate soffit panel and project conditions. Provide with channels to receive panels, flanges for concealed weathertight attachment, and slotted attachment holes. Color shall match or coordinate with soffit color. In order to eliminate or minimize visible joints, form in longest possible lengths with 10 feet being minimum.
  - 1. J-channel: ½ inch wide channel to receive soffit panels with ½ inch attachment flange.
  - 2. Reverse Frieze Molding: F-shaped piece with ½ inch wide channel to receive aluminum soffit panels.
  - 3. Soffit T-Bar: Double channel to receive two soffit panels with exposed face.

### 2.4 ACCESSORIES

- A. Fasteners: Weather and corrosion resistant nails of type, size, and spacing as recommended by soffit manufacturer.
  - 1. Plain Shank Nails: Use for wood studs, furring, and other framing with minimum lengths of 1-1/2 inches. Allow ¾ inch minimum penetration into wood framing.
  - 2. Screw Shank Nails: Use for plywood sheathing.
  - 3. Exposed Nails: Trim nails that match soffit and trim.
- B. Sealants: Silicone type as recommended by soffit manufacturer.

#### PART 3 EXECUTION

# 3.1 GENERAL

- A. Prepare substrate and install soffit in accordance with manufacturer's instructions, approved shop drawings, and manufacturer's soffit installation manual.
- B. Coordinate work with provisions and installation of exterior insulation finish system to ensure compatibility and weathertight, neat transition from vertical surface to horizontal soffit panels.

### 3.2 PREPARATION

A. Inspection: Verify that soffit support framing is rigid, level, and spacing does not exceed 24 inches. Do not proceed until deficiencies are addressed.

## 3.3 INSTALLATION

- A. Field Cutting: Accurately measure and cut soffit panels and trim. Use power circular saw with 10-point aluminum cutting blade, duckbill sheet metal snips, or hacksaw as recommended by manufacturer for specific cutting operation.
- B. Trim: Prior to installing soffit panels, locate and anchor perimeter to receive channels.
- C. Soffit Panels:
  - 1. Layout panels as detailed on approved shop drawings. Provide vented panels to provide sufficient ventilation of space above soffit.
  - 2. Insert panel into receiver channel, flex panel, and insert other end into opposing receiver channel. Ensure panels are perpendicular to perimeter and aligned. Fasten panel to supports by nailing through attachment flanges.
  - 3. Oerlap, engage, and lock subsequent panels over preceding ones.
  - 4. At corners, miter cut soffit panels and install with soffit T-bar. Align joints and grooves of intersecting panels.
- D. Expansion Joints: Where soffit panel engages receiver channel and where aluminum components butt or adjoin other materials, leave expansion gap:
  - 1. Hot weather with aluminum components partially expanded: 1/16 inch.
  - 2. Cold weather with aluminum components partially contracted: 1/8 inch.
- E. Fastening: Install panels and trim with nails. Where exposed, use trim nails with color to match aluminum components.
  - 1. Drive fasteners straight and level. Do not slant fasteners.
  - 2. Do not drive head of fastener tightly against attachment flange. Allow 1/32 inch clearance between fastener head and aluminum surface.
  - 3. Do not place fastener through face of soffit panel.
  - 4. Spacing: Fasten soffit panels at 24 inches maximum.
- E. Sealants: Apply sealants where indicated on manufacturer's approved shop drawings and as required to provide weathertight installation. Depth of sealant bead shall be ¼ inch minimum.

# 3.4 CLEANING AND PROTECTION

- A. Clean aluminum soffits and trim. Use detergent as required. Do not use solvents, abrasive, wire brushes, or steel scrapers.
- B. Remove Excess materials and debris from site.
- C. Protect soffit from subsequent construction operations. If damage occurs, remove and replace damaged components to provide installation in original, undamaged condition.

## **END OF SECTION**

#### 07631

### **GUTTERS AND DOWNSPOUTS**

# PART 1 GENERAL

# 1.1 SECTION INCLUDES

- A. Pre-finished continuous aluminum gutters and downspouts.
- B. Precast concrete splash pads.

### 1.2 RELATED SECTIONS

A. Section 09900 - Painting: Field painting of metal surfaces.

### 1.3 REFERENCES

A. ASTM B209 - Standard Specification for Aluminum and Aluminum-Alloy Sheet and Plate.

# 1.4 DESIGN REQUIREMENTS

A. Conform to SMACNA Manual CDA Handbook for sizing components for rainfall intensity determined by a storm occurrence of 1 in 5 years.

# 1.5 SUBMITTALS FOR REVIEW

- A. Section 01300 Submittals: Procedures for submittals.
- B. Shop Drawings: Indicate locations, configurations, jointing methods, fastening methods, locations and installation details.
- C. Samples: Submit two samples, 12 inches long illustrating component design, finish, color and configuration.

# 1.6 DELIVERY, STORAGE, AND PROTECTION

- A. Section 01600 Material and Equipment: Transport, handle, store and protect.
- B. Stack material to prevent twisting, bending or abrasion and to provide ventilation. Slope to drain.
- C. Prevent contact with materials during storage that may cause discoloration, staining or damage.

# 1.7 PROJECT CONDITIONS

- A. Section 01039 Coordination and Meetings.
- B. Coordinate the work with downspout discharge pipe inlet.

### PART 2 PRODUCTS

# 2.1 MATERIALS

A. Pre-Finished Aluminum Sheet: ASTM B209; 0.032 inch thick; plain finish shop pre-coated with acrylic coating; color as selected from manufacturer's standard.

### 2.2 COMPONENTS

- A. Gutters: SMACNA Square style profile.
- B. Connectors: Furnish required connector pieces for PVC (Polyvinyl Chloride) components.
- C. Anchors and Supports: Profiled to suit gutters and downspouts.
  - 1. Anchoring Devices: Type recommended by fabricator.
  - 2. Gutter Supports: Straps. Spikes and ferrules.
  - 3. Downspout Supports: Straps.
- Fasteners: Aluminum. Same material and finish as gutters and downspouts, with soft neoprene washers.

### 2.3 ACCESSORIES

- A. Splash Pads: Precast concrete type, size and profiles indicated; minimum 3000 p.s.i. at 28 days, with minimum 5 percent air entrainment.
- B. Downspout Boots: Plastic. (N.I. C.)

### 2.4 FABRICATION

- A. Form gutters and downspouts of profiles and size indicated.
- B. Fabricate with required connection pieces.
- C. Form sections square, true and accurate in size, in maximum possible lengths, free of distortion or defects detrimental to appearance or performance. Allow for expansion at joints.
- D. Hem exposed edges of metal.
- E. Fabricate gutter and downspout accessories; seal watertight.

#### 2.5 FACTORY FINISHING

- A. Modified silicone polyester coating: Baked enamel system conforming to AAMA 603.8.
- B. Primer Coat: Finish concealed side of metal sheets with primer compatible with finish system, as recommended by finish system manufacturer.

### PART 3 EXECUTION

## 3.1 EXAMINATION

- Section 01039 Coordination and Meetings: Verification of existing conditions before starting work.
- B. Verify that contact surfaces are ready to receive work.

### 3.2 PREPARATION

A. Paint concealed metal surfaces and surfaces in contact with dissimilar metals with protective backing paint to a minimum dry film thickness of 15 mil.

# 3.3 INSTALLATION

- A. Install gutters, downspouts and accessories in accordance with manufacturer's instructions.
- B. Slope gutters 1/8 inch per foot
- C. Set splash pads under downspouts.

# END OF SECTION