





## LA TYPE D BARRIER




PART PLAN
Note: Concrete vent holes not shown for clarity. TYPE B BARRIER (SBC)











SQ TYPE B BARRIER (SBC)



TYPE B BARRIER (SBC)(ALL)



TYPE B BARRIER (SBC)

STANDARD DRAWING GUIDANCE (do not show on plans):

- (1) Bar height.
- (2) Plate length = 12"/cos(skew) [12" for 0° skew]
- (3) Barrier gap =  $3\frac{1}{2}$ "/cos(skew) [ $3\frac{1}{2}$ " for 0° skew]
- 4 Barrier recess gap = 2 3/8"/cos(skew) [ $2\frac{3}{8}$ " for 0° skew]. Assume recess ends at front
- (5) Installation gap adjustment for temperature: normal to joint.
- (6) Check and revise locations of slotted wells to clear girder end section reinforcement.
- (7) Delete panel for CIP slab.