
OpenRoads Designer


Road 2

Advanced Terrain Modeling


1.1	Group Exercise-1: Create Terrain by Alternate Surface.....	1
1.2	Group Exercise-2: Create Terrain by Graphical Filter	4
1.3	Individual Exercise-3: Create Terrain by Graphical Filter	6
1.4	Group Exercise-4: Create Terrain from Elements (Linear Features).....	8
1.5	Group Exercise-5: Create Terrain from Design Meshes.....	11

1.1 Group Exercise-1: Create Terrain by Alternate Surface

- 1) Open **Perry\J9P3093\Corridors_J9P3093.dgn**
- 2) Review project setup. **AC** is mainline Corridor; **TG** is sideroad Corridor and two linear templates are in the radius return area at the intersection of **AC** & **TG**.
- 3) Review Template Drop on mainline **AC** Corridor.
 - a. Use the Active Template Tab and review the **Alternate Surfaces** for the Template.
- 4) Create a new file named **Terrain_Proposed_J9P3093.dgn** using the following Seed file: **MoDOT_Roadway_Seed_3D.dgn**
- 5) Open the **Coordinate System** tool by selecting the **OpenRoads Modeling Workflow** → **Utilities Tab** → **Geographic Section**.
- 6) Select “**From File**” icon.



- 7) Select the **Terrain_Existing_J9P3093.dgn** file in the data.
- 8) Verify the settings.




9) Reference in the following files:

Corridors_J9P3093.dgn (Default 2D View)
Terrain_Existing_J9P3093.dgn


Important - Set the terrain active after referencing it in.

Note: Creating a Terrain Model with an Alternate Surface(s) will work with any **Corridor** or **Linear Template Feature Definition**.

10) Choose the **Create Corridor Alternate Surfaces** tool by selecting the **OpenRoads Modeling Workflow** → **Terrain Tab** → **Create Section** → **Additional Methods Tools** and then select the “AC” Corridor and wait.




11) After creating the Alternate Surface Terrain Models, **detach all reference files**, select “**Yes**” below to break the rules back to the reference files.



12) There are three Alternate Surface Terrain Models created, rotate the view to see the terrain models **RTEAC.Proposed Finished Grade**, **RTEAC.Subgrade**, and **RTEAC.Bottom of Pavement**.

- 13) Use the **Explorer** → **OpenRoads Model Group** → **Terrain Models** to delete the **AC.Subgrade** and **RTEAC.Bottom of Pavement** terrain models.
- 14) Set the **RTEAC.Proposed Finished Grade** Terrain Model to have a Feature Definition of **Design Triangles**.
- 15) Rotate the view to **top** and select **fit** view.
- 16) Select **Terrain > Edit> Edit Model** tool.
 - a. Edit the Terrain model.




Additional Notes:

- Alternate Surface(s) can only process one corridor at a time.
- The **Create Corridor Alternate Surfaces** tool works with Referenced Corridors, in other words you don't need to be in the Corridors file for the tool to work.
- Alternate Surfaces **do** have rules back to the original Corridor and template.
- With Alternate Surfaces, to get the End Conditions included in the terrain model, typically the existing ground must be **referenced** and **active**.
- The **Terrain Edit** Tools can modify the newly created Terrain Models from the Alternate Surfaces Tool only after the rules have been dropped back to the Corridor.
- When you remove the Rules from the Terrain Model you break the link back to the Corridor.
- The **Corridor Feature Definition** can modify the number of triangles created based on the multiplication interval being applied.

1.2 Group Exercise-2: Create Terrain by Graphical Filter

The following steps will show the User how to create a Terrain Model of the Proposed Surface using the **Design - Proposed Finished Grade with Boundary** Graphic Filter. The Graphic Filter uses points along the entire proposed finished grade surface which includes but is not limited to side-slope conditions, top of pavement, top of shoulder, curb, etc. A Terrain Boundary will also be incorporated that includes the points that make up the Limits of Construction (LOC points).



- 1) Open **Perry\J9P3093\Corridors_J9P3093.dgn**
- 2) Verify the **Corridor Feature Definition** is set to a **Final-x 1** for the **RTEAC** and **TG** Corridors, as well as the **Radius Return Linear Templates**.
- 3) Open the **Terrain_Proposed_J9P3093.dgn**.
 - a) If not already done so, **Delete** and **Detach** everything in the file.
 - b) **Compress File** by Selecting **File → Tools → Compress File**
- 4) Reference in **Corridors_J9P3093.dgn (Default 2D View)**.
 - a) If needed rotate the view to **“Top”** and fit the view.
- 5) Within the **OpenRoads Modeling** Workflow, select **Terrain Model → Create → From Graphical Filter** tool and choose the following:
 - a) Graphical Filter Group: **Design - Proposed Finished Grade with Boundary**
 - b) Select the **Preview** Button
 - a. Linear Elements in the surface of the model should highlight.
 - c) Edge Method: **None**
 - d) Feature Definition: **Design Triangles**
 - e) Name: **Proposed Terrain from Graphic Filter**

Note: When the tool is activated the Corridors 3D View is automatically referenced into the drawing.

- 6) Notice in the Project Explorer that the Filter Group and Individual Filters were copied over into the active file.

Explorer → OpenRoads Standards → Terrain_Proposed_J9P3093.dgn → Terrain Filters


- 7) Detach both references (2D and 3D) to the **Corridors_J9P3093.dgn**.

Additional Notes:

- Terrain Models created from **Graphic Filters** **do not** have rules back to the original Corridor and template.
- **Graphic Filters** can process all Corridors and Linear Templates at the same time.
- The **Graphic Filters** tool works with Referenced Corridors, in other words you don't need to be in the Corridors file for the tool to work.
- The **Terrain Edit** tools can modify the newly created Terrain Models created from the **Graphic Filters** tool.
- The **Corridor Feature Definition** can modify the number of triangles created based on the multiplication interval being applied.
- Compressing a file will purge deleted elements and clears the undo buffer.

1.3 Individual Exercise-3: Create Terrain by Graphical Filter

The following steps will show the User how to create a Terrain Model of the Proposed Surface using the **Design – Bottom of Base with Boundary** Graphic Filter. The Graphic Filter uses points along the entire proposed finished grade surface which includes but is not limited to side-slope conditions, top of pavement, top of shoulder, curb, etc. A Terrain Boundary will also be incorporated that includes the points that make up the Limits of Construction (LOC points).



- 1) Open **Perry\J9P3093\Corridors_J9P3093.dgn**
- 2) Verify the **Corridor Feature Definition** is set to a **Final-x 1** for the **RTEAC** and **TG** Corridors, as well as the **Radius Return Linear Templates**.
- 3) Open the **Terrain_Proposed_J9P3093.dgn**.
 - a) If not already done so, **Delete** and **Detach** everything in the file.
 - b) **Compress File** by Selecting **File → Tools → Compress File**
- 4) Reference in **Corridors_J9P3093.dgn (Default 2D View)**.
 - a. If needed rotate the view to “**Top**” and fit the view.
- 5) Within the **OpenRoads Modeling** Workflow, select **Terrain Model → Create → From Graphical Filter** tool and choose the following:
 - b. Graphical Filter Group: **Design - Bottom of Base - Daylighted with Boundary**
 - i. Select the **Preview** Button
 - ii. Linear elements in the surface of the model **should highlight**.
 - c. Edge Method: **None**
 - d. Feature Definition: **Design Triangles**
 - e. Name: **Proposed Terrain from Graphic Filter**

Note: When the tool is activated the Corridors 3D View is automatically referenced into the drawing.

- 6) Notice in the Project Explorer that the Filter Group and Individual Filters were copied over into the active file.

Explorer → OpenRoads Standards → Terrain_Proposed_J9P3093.dgn → Terrain Filters


- 7) Detach both references (2D and 3D) to the **Corridors_J9P3093.dgn**

Additional Notes:


- Terrain Models created from **Graphic Filters** **do not** have rules back to the original Corridor and template.
- **Graphic Filters** can process all Corridors and Linear Templates at the same time.
- The **Graphic Filters** tool works with Referenced Corridors, in other words you don't need to be in the Corridors file for the tool to work.
- The **Terrain Edit** tools can modify the newly created Terrain Models created from the **Graphic Filters** tool.
- The **Corridor Feature Definition** can modify the number of triangles created based on the multiplication interval being applied.
- Compressing a file will purge deleted elements and clears the undo buffer.

1.4 Group Exercise-4: Create Terrain from Elements (Linear Features)

- 1) Open **Perry\J9P3093\Corridors_J9P3093.dgn**
- 2) Verify the **Corridor Feature Definition** is set to a **4-Final-x 1 – Linear Features Only** for the **RTEAC** and **TG** Corridors, as well as the **Radius Return Linear Templates**.
- 3) Select the “**F6**” key to open the 3D view of the Model.
- 4) Open the **Terrain_Proposed_J9P3093.dgn**.
 - a) If not already done so, **Delete** and **Detach** everything in the file.
 - b) **Compress File** by Selecting **File → Tools → Compress File**
- 5) Reference in **Corridors_J9P3093.dgn (Default 3D View)**.
 - a) In the Reference Dialog turn off the display of the Corridors 2D view
 - b) If needed rotate the view to “**Top**” and fit the view.
- 6) Use the **Level Manager** and only display the “**Surface**” Levels.



- 7) Using the **Element Section** Tool place all **38 visible items** in a Selection Set.
- 8) Within the **OpenRoads Modeling** Workflow, select **Terrain Model Tab** → **Create Section** → **From Elements** tool and choose the following:




- 9) To reduce the long Exterior Triangles that don't represent the proposed linear features, we will change the **Limits of Construction** elements to a **Boundary** Feature Type.


To help with the selection of **Limits of Construction** elements, we will utilize the **Level Display** dialog and the **Display Set** tool. In the **Level Display** dialog **Right Click** on the **Modeling-Limits of Construction** level and **Right Click**, then select **Create Display Set**.

(**NO** levels need to be turned off beforehand, for the **Display Set** to work).

Then using a section fence place the **Modeling-Limits of Construction** elements into a **Selection Set**.



- 10) Using the **Element Section** Tool place all **10 visible items** in a Selection Set.
- 11) Once Selection Set is created, **right-click** and hold in a blank area and select **View Control → Displayset Clear**. The **10** elements should still be in a selection set.
- 12) Within the **OpenRoads Modeling** Workflow, select **Terrain Model** Tab → **Edit Section → Change Feature Type** tool and choose the following:




Additional Notes:

- The **Create Terrain from Elements** tool works with Referenced Corridors, in other words you don't need to be in the Corridors file for the tool to work.
- **Create Terrain from Elements** Surfaces **do not** have rules back to the original Corridor and template elements.
- The **Corridor Feature Definition** can modify the number of triangles created based on the multiplication interval being applied.
- Compressing a file will purge deleted elements and clears the undo buffer.

1.5 Group Exercise-5: Create Terrain from Design Meshes



- 1) Open **Perry\J9P3093\Corridors_J9P3093.dgn**
- 2) In the 2D Default view, change the Design Stage to **2-Final x 1 Top Mesh Only** for all Linear Templates and Corridors.
- 3) Open **Perry\J9P3093\Terrain_Proposed_J9P3093.dgn**
 - a. If not already done so, **Delete** and **Detach** everything in the file.
- 4) Reference in **Corridors_J9P3093.dgn (Default 2D View)**.
 - a. In the Reference Dialog turn off the display of the **Corridors 2D** view
 - b. If needed rotate the view to “**Top**” and fit the view.
- 5) Within the **OpenRoads Modeling** Workflow, select **Terrain Model** Tab → **Create** Section → **Addition Methods** Tools → **Create Terrain from Design Meshes** tool and choose the following:



- 5) Detach both reference files and rotate the view.
- 6) Using the **Terrain Model** heads-up tools select the terrain model **Export** tool and select Land XML.

Additional Notes:


Select Terrain:	Design Triangles
Export Format:	Land XML (.xml)
Project Name:	J9P3093
Project Description:	AC Corridor Proposed Terrain
Export Options:	Export Triangles Only

- The **Create Terrain from Design Meshes** tool works with Referenced Corridors, in other words you don't need to be in the Corridors file for the tool to work.
- **Create Terrain from Design Meshes** Surfaces **do not** have rules back to the original Corridor and template elements.
- The **Corridor Feature Definition** can modify the number of triangles created based on the multiplication interval being applied.

OpenRoads Designer


Road 2

Bridge End-Bent Layout



1.1 Group Exercise: Bridge End-Bent Layout

- 1) Open the **Pike\J2P3081\Exported_Graphics_J2P3081.dgn**.
 - a) **Review** the Existing Survey Graphics.
 - b) Using the Level Display **turn off all levels except** for the following levels:
 - a. **Survey-Edge of Pavement**
- 2) Add a **Feature Definition** of **EOP Existing** to the **Survey-Edge of Pavement** elements (4 elements)
- 3) Create a new file named **Civil_Geometry_J2P3081.dgn** using the **MoDOT_Roadway_Seed_2D.dgn** as the seed file.
- 4) Open the Coordinate System tool by selecting the OpenRoads Modeling Workflow → Utilities Tab → Geographic Section.
- 5) Select “**From File**” icon.
 - a. Choose the **Existing_Terrain_J2P3081.dgn**



- 6) Set Annotation Scale to **50**
- 7) Import Alignment and Profile called “**Mainline**” and “**Proposed**” from the **mainline.xml**
- 8) **Rename** the alignment to **Route 14**
- 9) **Annotate** the **Route 14** alignment.
- 10) **Reference** in the following:
 - a. **Exported_Graphics_J2P3081.dgn**
 - b. **Existing_Terrain_J2P3081**
- 11) **Activate** the Existing Ground Terrain
- 12) Hover over the **Route 14** alignment and verify that there is an active profile.

- 13) Open **Plan_J2P3081.dgn** File.
 - a) Attach **Civil_Geometry_J2P3081.dgn**
 - b) **Review** plan geometry.
- 14) Create a new file named **Corridors_J2P3081.dgn** using the **MoDOT_Roadway_Seed_2D.dgn** as the seed file.
- 15) **Assign the GCS** (Geographic Coordinate System) from file.
- 16) Set Annotation Scale to **50**
- 17) **Reference** in the following files:
 - a) **Civil_Geometry_J2P3081.dgn**
 - b) **Existing_Terrain_J2P3081.dgn**
 - c) **Exported_Graphics_J2P3081.dgn**
 - d) **Plan_J2P3081.dgn**
- 18) **Activate** Existing Ground Terrain.
- 19) Next select the “**F6**” key to open the multi-model view. In the **3D View** turn **Off** the **Display** of the **Exported_Graphics_J2P3081.dgn**
- 20) **Turn off** the Level **Common-Notes** in the **Plan_J2P3081.dgn** referenced file
- 21) **Verify** all the Levels in the **Exported Graphics_J2P3081.dgn** are turned off except for the **Survey-Edge of pavement**.
- 22) **Open** the Project Template Library **J2P3081.itl**.
 - a) **Review** the *Bridge* template
 - b) **Review** the *Roadway* templates
 - c) **Close** Template Library.
- 23) **Create a Corridor** for **Route 14** using the Create Corridor tool
 - a) Name the corridor “**Route14**”
 - b) Apply Roadway template “**J2P3081 2 Lane w/ Agg Base Option 1 Mill and Fill Concrete Widening**” from station **68+00** to **71+68.64 R1** with Drop Interval of **5ft**.
 - c) If not open already select the “**F6**” key to open 3D view of model.

- 24) Review the **LT_Seek_Surface** point in the template drop to verify that the Horizontal Feature Constraint is defined as **EOP Existing** for the Feature Definition. Do the same for the **RT_Seek_Surface** point.

The screenshot shows the 'Constraints' dialog box. It has two columns for 'Constraint 1' and 'Constraint 2'.
 Constraint 1:
 Type: Horizontal
 Parent 1: AsphSurf_T_CL
 Value: -5.0000
 Label: (empty)
 Below these, there is a checkbox labeled 'Horizontal Feature Constraint' which is checked, and a dropdown menu showing 'Linear\Design\Roadway\EOP Existing'. This entire row is highlighted with a red rectangle.
 Range: -50.0000
 Constraint 2:
 Type: Project To Surface
 Parent 1: Any Direction
 Value: (empty)
 Label: (empty)

- 25) Review the **LT_Conc_T_EOP** point in the template drop to verify that the Horizontal Feature Constraint is defined as **EOP New** for the Feature Definition. Do the same for the **RT_Conc_T_EOP** point.
- 26) Close the **Editing Roadway Designer Template Drop** dialog.
- 27) Add the two **EOP New** and two **EOP Existing** lines as **Corridor References**.
- 28) Add the following **Parametric Constraint** to remove Pavement Widening on Left side ending at Station **70+52.89**.

Start:	68+00.00
Stop:	70+52.89
Constraint Label:	LT_Pvmt_Surf_Conc_Width
Start Value:	0.00
Stop Value:	0.00

- 29) To help with placement of a **Horizontal Temporary Dimension Line** in the next step, add in a **Key Station** at **71+68.63** (make sure the **Dynamic Cross Section Model** is not open while executing this step, it will cause incorrect slope values).
- 30) Open Dynamic XS model, and display XS at Station **71+68.63 R1**
- Verify that the pavement slopes on left and right side by adding horizontal dimensioning to the left and right side of pavement.
 - Left = 0.52% Right = -0.79%**

Note: If after using the **Horizontal Dimension Tool**, if you notice a “**Dimension**” message on the end your **Cursor**, that won’t go away, selecting the tool again will remove that message.

31) Apply Roadway/Bridge Approach template.

- Review **Concrete Approach Pavement with Barrier** Template (focus on Display Rule for Type “B” Barrier)
- Apply **Concrete Approach Pavement with Barrier** from station **71+68.65 R1** to **72+37.00 R1**
- Use a drop spacing of 1ft

32) Add the following **two Parametric Constraints** to transition the Overlay Pavement Slopes onto the Concrete Approach Pavement Slopes:**Parametric Constraint #1**

Start:	71+68.65
Stop:	71+78.65
Constraint Label:	LT_Pvmt_Surf_Conc_Slope
Start Value:	0.52%
Stop Value:	2.0%


Parametric Constraint #2

Start:	71+68.65
Stop:	71+78.65
Constraint Label:	RT_Pvmt_Surf_Conc_Slope
Start Value:	-0.79%
Stop Value:	-2.0%

- Note if gap in slope between the two templates is not resolved, check to make sure the existing ground terrain is active.

33) **Create a terrain model from the 3D Model.** This terrain Model will be used to create a profile around the Bridge End Bent.

- Create new file called **Graphic_Filter_J2P3081.dgn** using a **3D Seed**.
- Assign the GCS** (Geographic Coordinate System) from file.
- Reference in the **Corridors_J2P3081.dgn** and its **Default-3D** view.
- Select the **Create Terrain Model From Graphical Filter**.
- Use a Filter Group called **Design – Proposed Finish Grade with Boundary**.
- Use Feature Definition of **Design Triangles**.
- Name the new Terrain model “**J2P3081 Terrain from Graphic Filter**”
- Detach All** References and **Dynamically Rotate** the View to view the new terrain.



Create Horizontal and Vertical Civil Alignment End Bent Corridor:34) Open **Civil_Geometry_J2P3081.dgn**

- a) Reference in **Plan_J2P3081.dgn (Default 2D Model)**
- b) Use Horizontal Geometry **Complex by PI Tool** and trace end bent **counterclockwise**.
 - a. Use radius of 0.00'
 - b. Use Feature Definition > **Bridge_Approach_Slab_503-10.00**
 - i. (Located under: **Linear\Design\Safety and Structures**)
 - c. Use Feature Name "**End_Bent_1**"
- c) Reference in **Graphic_Filter_J2P3081.dgn**
 - a. If triangles are turned on, go into the properties of the Terrain Model and override the symbology and turn **triangles off**.
- d) Select **End Bent 1's** Alignment and open its **Profile Model**.

35) Use Vertical Geometry Tool **Quick Profile from Surface** to create a profile from Graphic Filter Surface.

- a) Set profile **Active**.
- b) To be safe Remove Rules to the newly created profile before performing the next step.
- c) In **Default 2D** view Detach the **Graphic_Filter_J2P3081.dgn**

36) Open **Corridors_J2P3081.dgn** file37) Add the **Traffic Control Barrier Lines** near the End Bent as **Corridor References**.

Note: You will notice that after adding the Corridor References the **Type B Barriers** are still not displaying. Investigate and solve the reason why.

38) Add the following two Parametric Constraints to transition into the Guardrail Widening Width over a distance of **10ft** near the Bridge Approach slab:**Parametric Constraint #1**


Start:	71+87.89
Stop:	71+97.89
Constraint Label:	LT_Guardrail_Widening_Width
Start Value:	-3.9375'
Stop Value:	-1.50'

Parametric Constraint #2

Start:	72+00.52
Stop:	72+10.52
Constraint Label:	RT_Guardrail_Widening_Width
Start Value:	3.9375'
Stop Value:	1.50'

Note: The rest of the **Guardrail Widening** behind the **Type B Barrier** will be removed in another step later in this exercise.


- 39) Review below the Guardrail Widening Width requirements on the right side of **Route 14** to meet our requirements in the **Standard Plans 606.80**.




Using the **Law of Sines** calculate the transition Length.

$$\frac{a}{\sin A} = \frac{b}{\sin B}$$

$$\frac{7\text{ft}}{\sin(15^\circ)} = \frac{b}{\sin(90^\circ - 15^\circ)}$$



$$\frac{a}{\sin A} = \frac{b}{\sin B} = \frac{c}{\sin C}$$



$$b = \left(\frac{\sin 75^\circ}{\sin 15^\circ} \right) (7\text{ft}) = 26.12\text{ft, use 30ft for Guardrail Widening Transition Distance.}$$

- 40) Modify the Guardrail Widening Width requirements on **both sides** of the Mainline using the following Parametric Constraints to meet MoDOT's requirements in **Standard Plans 606.80**.

Parametric Constraint #1

Start:	Start of Alignment
Stop:	68+70
Constraint Label:	Guardrail_Widening_Width
Start Value:	0.00 ft
Stop Value:	0.00 ft

Parametric Constraint #2


Start:	68+70
Stop:	69+00
Constraint Label:	Guardrail_Widening_Width
Start Value:	0.00 ft
Stop Value:	7.00 ft (-7.00 ft for left side)

Parametric Constraint #3

Start:	69+00
Stop:	69+30
Constraint Label:	Guardrail_Widening_Width
Start Value:	7.00 ft (-7.00 ft for left side)
Stop Value:	3.9375 ft (-3.9375 ft for left side)

41) In the **Corridors_J2P3081.dgn** 2D Default View, if it is on, turn off the **3D reference** from the **Corridors 3D Model**.

42) Set the Feature Definition to: **Alignment/Guardrail_Type_A_LT or RT (UFDT)**



43) Using the **Horizontal Geometry - Variable Offset Taper** along with **Civil AccuDraw** tool, place on **BOTH** Left and Right sides of the roadway the 1ft offset taper section of the guardrail.

Variable Offset Taper Settings

Notes:

- If in the 3D View the guardrail looks like a block, go into the View Attributes and turn off the **Construction** View.
- If a very tall guardrail post draw, select the “**F4**” Key.

Locate Element:	Proposed Edge of Shoulder
Start Offset:	1.00
End Offset:	0.00
Start Station:	69+00
End Station:	69+30
Feature Definition:	Guardrail_Type_A_LT/RT (UFDT)

44) Using the **Horizontal Geometry – Single Offset Partial** along with Civil AccuDraw tool, place on the **LEFT** side of the roadway the following section of the guardrail.

Single Offset Partial Settings Left

Locate Element:	Proposed Edge of Shoulder
Offset:	0.00
Start Station:	69+30
End Station:	71+80.11
Feature Definition:	Guardrail_Type_A_Left (UFDT)

Variable Offset Taper Settings Left

Locate Element:	Proposed Edge of Shoulder
Start Offset:	0.00
End Offset:	-0.50
Start Station:	71+80.11
End Station:	71+98.49
Feature Definition:	Guardrail_Type_A_Left (UFDT)

NOTE: You'll notice that the Guardrail meanders in and out, (especially on the left side) because it is tied to the edge of shoulder line. To remove the meander tie the outside shoulder line to the baseline at a 16 feet offset, in other words within the **LT_Conc_T_O_EOS** point make the parent point of the Horizontal Constraint be the **AsphSurf_T_CL** point and set the distance to -16 feet.

- 45) Using the **Horizontal Geometry – Single Offset Partial** along with Civil AccuDraw tool, place on the **Right** side of the roadway the following section of the guardrail.

Single Offset Partial Settings Right

Locate Element:	Proposed Edge of Shoulder
Offset:	0.00
Start Station:	69+30
End Station:	71+98.75
Feature Definition:	Guardrail_Type_A_Right (UFDT)

Variable Offset Taper Settings Right

Locate Element:	Proposed Edge of Shoulder
Start Offset:	0.00
End Offset:	0.50
Start Station:	71+98.75
End Station:	72+11.02
Feature Definition:	Guardrail_Type_A_Right (UFDT)

Note: In the **3D View** the best visualization setting is **Illustration: Modeling** and adjust the Brightness. To get back to the default views hit the **F6** key.

- 46) **Create/Apply a Linear Template Drop for End Bent #1.** To see the End Bent Geometry in the 2D View you may need to turn **ON** the **Roadway-Edge of Pavement level** within the **Level Display** for the Reference File **Civil_Geometry_J2P308.dgn**

Locate Element:	The End_Bent_1 Horizontal Linear Feature
Start Station:	Lock to Start
End Station:	Lock to End
Exterior Sweep Angle:	5 degrees
Mirror:	No
Reflect:	No
Template:	2:1 Earth Slopes with Upper Concrete Structure
Feature Definition:	1-Final x 1
Description:	End Bent 1

- 47) Add **Corridor Clip** to the Mainline Corridor
a. Clip out the End Bent **Linear Template**.

48) Using Parametric Constraints adjust the **End Bent #1** Linear Template Drop:

Parametric Constraint #1
(Bench Width)

Start:	Lock to Start
Stop:	0+25.00
Constraint Label:	Bench_Width
Start Value:	0.00 ft
Stop Value:	0.00 ft

Parametric Constraint #2
(Bench Width)

Start:	0+61.90
Stop:	Lock to End
Constraint Label:	Bench_Width
Start Value:	0.00 ft
Stop Value:	0.00 ft

Parametric Constraint #3
(Wall Depth)

Start:	Lock to Start
Stop:	0+25.00
Constraint Label:	Wall_Depth
Start Value:	0.00 ft
Stop Value:	-4.00 ft

Parametric Constraint #4
(Wall Depth)

Start:	0+61.90
Stop:	Lock to End
Constraint Label:	Wall_Depth
Start Value:	-4.00 ft
Stop Value:	0.00 ft


Parametric Constraint #5
(Fill Slope)

Start:	Lock to Start
Stop:	0+25.00
Constraint Label:	Fill Slope
Start Value:	-25%
Stop Value:	-50%

Parametric Constraint #6
(Fill Slope)

Start:	0+61.90
Stop:	Lock to End
Constraint Label:	Fill Slope
Start Value:	-50%
Stop Value:	-25%

- 49) After applying the Parametric Constraints in the previous step you should notice slopes from the Mainline still solving and not being fully clipped out (see below).



To remove the two slopes we are going to apply a **End Condition Exception** to the Mainline Corridor for each side of the roadway.


End Condition Exception #1 (Right Side)

Name:	Remove Right End Condition
Apply ECE TO:	Backbone Only (Right)
Start:	72+10.53
Stop:	72+50

End Condition Exception #2 (Left Side)

Name:	Remove Left End Condition
Apply ECE TO:	Backbone Only (Left)
Start:	71+97.89
Stop:	72+50


After Applying End Condition Exception




- 50) To help close the gap near the start of the Barrier on the left side of the roadway, add a **Key Station** at **71+97.88**

51) To Clip out the remaining piece of the Mainline Corridor, we are going to create a **Clipping Block**. We will place the Clipping Block in the **Plan_J2P3081.dgn** file.


- a. Use the MicroStation **Move Parallel** tool and offset end bent line.





- b. **Offset** the bent line **0.01 up-station and down-station** using the **copy** option within the **MicroStation Move/Copy Parallel** tool.
- c. We are offsetting the line **twice** because we are going to make **two Clipping Blocks**, one for the clipping out part of the **Mainline Corridor** and another for clipping out part of the future **Bridge Corridor**.



- d. **Extend** the offset lines well past *Corridor Limits* using the **Extend Line** tool.



- e. Select the **Place Block** tool and set the method to **Rotated**.



- f. Create **two** block shapes. One up-station and one down-station using the copied offset lines by using a keypoint snap to each end of the extended line. You will want them to overlap.



52) Open Corridors_J2P3081.dgn

- a. Add Clipping Reference to **Route14** (Mainline) Corridor using the newly created block.

53) Create a new 2D file for the Bridge Corridor named Corridors_Bridge_J2P3081.dgn.

- a. **Set the GCS** using the **Existing_Terrain_J2P3081.dgn**
- b. Reference in the following:
 - i. **Civil_Geometry_J2P3081.dgn**
 - ii. **Existing_Terrain_J2P3081.dgn**
 - iii. **Plan_J2P3081.dgn**
- c. Select **F6** to open the **2D** and **3D** window

54) Create a Corridor named Bridge using the Mainline Alignment.**55) Add the Bridge Template using the following settings:**

Corridor Name:	Bridge
Template:	Bridge
Start Station:	72+20
End Station:	73+50
Drop Interval:	25.00'

56) Add a Clipping Reference to the Bridge Corridor using the down station block shape.**57) Open Corridors_J2P3081.dgn**

- a. In the **3D View** reference in the **3D Model** of the **Corridors_Bridge_J2P3081.dgn**
- b. Review Project


END OF EXERCISE

OpenRoads

Designer Road 2

Intersection Design

2.1 Objectives	2
2.2 Intersection Design Exercise.....	3




2.1 Objectives

The objective of this chapter is to give the user an overview of the Civil Design Tools and the design workflow using these tools. The user will learn how to access the tools, set preferences, navigate through the Create Template and Civil Tool dialog boxes. Designing an intersection can be a complex and iterative process. There are an abundance of criteria to consider such as min/max slopes, stopping sight distance, drainage and R/W constraints – just to name a few.

There are many techniques utilizing Horizontal, Vertical and Corridor Civil Tools that can be used to model intersections. This chapter will cover the workflow used to model a Tee-intersection. In addition, this method may be used to model an intersection where the mainline roadway is within the limits of a horizontal curve. This method will ultimately work for most intersection types.

2.2 Intersection Design Exercise


1. Within the **Cole\J5P0100** folder, open the file: **Plan_Overview_J5P0100.dgn**
2. Zoom in to the location where **Ramp 2** and **Ramp 4** intersect **Big Horn Drive**.



Note: Ramp 2 station at Big Horn is 16+55.31 and Ramp 4 at Big Horn is 0+00. The Ramps run in opposite directions.

Creating the Project Template Library

3. Within the **OpenRoads Modeling** Workflow, select **Create Template** by selecting the **Corridors** Tab → **Create Section** → **Template** Tools.



Path to MoDOT itl → Documents\CADD_Standards\ORD Standards\Connect_Config\WorkSpaces\MoDOT\Standards\Template Library\



4. Select **File > Save As** from the **Create Template** dialog menu. Save the **MoDOT** template library as **J5P0100.itl** in the folder.
5. Within the **itl** create a folder named **J5P0100** to store templates for the Project Corridors.
6. Within to the **J5P0100** folder and create a new folder called **Big Horn**.

- Copy within the **Big Horn** Folder the following Template:


Templates → Overlay → Overlay w/
Asphalt Pavement Widening and A2
Shoulder - Option #3 → **Match Existing
Slope Surface Course.**

- Rename Template to **Big Horn - Match Existing Slope Surface Course**

- To get the Widening to start at the Existing Edge of pavement edit the **Big Horn - Match Existing Slope Surface Course** Template and select the **RT_AsphSurf_B_EOP** and the **LT_AsphSurf_B_EOP** points and modify the **Horizontal Feature Constraint** to be **Linear\Design\Roadway\EOP_Existing**




For the previous step **edit** the following area in the Point Property dialog:



Template Point - Hierarchy of Control

- 
- ▶ Point Control - **Highest**
 - ▶ Horizontal Feature Constraint
 - ▶ Parametric Constraint
 - ▶ Point Constraint - **Lowest**



Point Properties

Name: RT_AsphSurf_T_EOP

☐ Use Feature Name Override: RT_AsphSurf_T_EOP

Feature Definition: \res\Pavement\XS_AsphSurf EOP

☒ Superelevation Flag

Alternate Surface: Proposed Finished Grade

Member of:
Asphalt Surface Pavement
RT_A2 Shoulder Asphalt Surface

Constraints

Constraint 1		Constraint 2	
Type:	Slope	Type:	Horizontal
Parent 1:	AsphSurf_T_CL	Parent 1:	AsphSurf_T_CL
Parent 2:	<input type="checkbox"/> Rollover Values...	Parent 2:	<input type="checkbox"/> Rollover Values...
Value:	-2.00%	Value:	12.0000
Label:	RT_Pvmt_Surf_Asph_Slo	Label:	RT_Pvmt_Surf_Asph_Wi
<input checked="" type="checkbox"/> Horizontal Feature Constraint		<input type="checkbox"/> Linear/Design/DNC/DNC	
Range:		50.0000	

10. Close the **J5P0100.itl** Template Library and **Save** on exit.

Creating the Big Horn Corridor

11. Create the Corridor dgn file for all the alignments going into the Intersection of **Big Horn, Ramp 2, and Ramp 4.**


12. Create a new dgn file named **Corridors_J5P0100.dgn** using the:

MoDOT_Roadway_Seed_2D.dgn seed file.

Note: This new file will hold all the Corridors for this intersection.


13. Open the **Coordinate System** tool by selecting the **OpenRoads Modeling Workflow** → **Utilities** Tab → **Geographic** Section.

14. Select “**From File**” icon.



15. Select the **Terrain_Existing_J5P0100.dgn** file in the **data** folder.

16. Verify the settings.




17. Reference in the following files within the **Default 2D Model**:


Civil_Geometry_J5P0100.dgn

Terrain_Existing_J5P0100.dgn

18. Fit View, change the Annotation Scale to **1" = 50'**, and set the Existing Terrain as **Active**.

19. Create a **Corridor** for **Big Horn Drive**

- a. Open the **New Corridor** tool by selecting the **OpenRoads Modeling Workflow** → **Corridors Tab** → **Create Section** 
- b. Select the **Big Horn Alignment**
- c. **Right Click** for the Active Profile (Big Horn Existing).
- d. **Corridor Name: Big Horn**
- e. Template: **J5P0100** → **Big Horn** → **Big Horn - Match Existing Slope Surface Course**
- f. Start Station **0+97.77** (Start of Alignment)
- g. End Station **21+48.29** (End of Alignment)
- h. Drop Interval **5'**

20. Select **F6** to view the 3D model of the Corridor.

21. To allow the template to see the **Big Horn Existing Edge of Pavement (EOP)** lines we need to set a “**Design**” Feature Definition on those lines. Currently the Big Horn **EOP Existing** lines have a “**Survey**” Feature Definition applied to them, which does not currently work with ORD Corridor Modeling.

To resolve this, let's open the *Exported_Graphics_J5P0100.dgn* file and update the **EOP Existing** Feature Definitions.


22. Using the **Level Display**, turn off all levels except for **Survey-Edge of Pavement**.23. Set the **Feature Definition Toggle Bar** with the following settings:

Linear → Design → Roadway → EOP Existing

Also make sure the **Use Active Feature Definition** is toggle ON.

Open the **Set Feature Definitions** tool by selecting the **OpenRoads Modeling Workflow** → **Geometry Tab** → **General Tools Section** → **Standards Pull-Down**. Then select and “**Set**” the two Existing EOP lines.


24. Reopen the **Corridors_J5P0100.dgn** file and then open a **Dynamic XS** view for the **Big Horn Corridor**. Also add a **Horizontal Temporary Dimension Line** in the **Overlay Area** of the template.



25. Reference into the **Default 2D Model** the following files:


Exported_Graphics_J5P0100.dgn

26. For the Corridor to see the **Existing Edge of Pavement** line, the line needs to be added as a Corridor Reference. To add a Corridor Reference, select the corridor's heads up tools and select the 4th set of tools from the left and select **Add Corridor Reference**.



The start of the Edge of Widening offset should have changed from the default 8' offset defined in the template to the actual distance to the Existing Edge of Pavement line.

Note: Horizontal Feature Constraint Range Explained:




- Range uses the offsets as defined in the template. For example, if your point is defined at 38 offset in the template, and the range is -18, the point will look from 38 to 20 offset from the corridor baseline for the feature definition.
- Positive (+) values entered, will cause the template to look only to the Right of the Template point.

- Negative (-) values entered, will cause the template to look only to the Left of the Template point.
- A Zero (0) value entered, will cause the template to look both left and right of the Template point.
- The start location of the Range is always the original offset location of the Point in the Template. Even if the point is shifted to a different offset in the model, for example a point being shifted using Parametric Constraint, the start location of the Range is always the original offset location of the Point in the Template.
- A **Horizontal Feature Constraint Range** can be overwritten with a **Point Control** using a **Control Type** called **Feature Definition**, the program will determine the offset of the point that is assigned the Point Control and apply the range value to the offset of that point as it exists in the template.
- If there are two or more Features within the **Horizontal Feature Constraint Range**, the closest one to original offset location of the Point in the Template will be selected.

Template Point - Hierarchy of Control

- ▶ Point Control - Highest
 ▶ Horizontal Feature Constraint
 ▶ Parametric Constraint
 ▶ Point Constraint - Lowest



Point Properties

Name: RT_AsphSurf_T_EOP

☐ Use Feature Name Override: RT_AsphSurf_T_EOP

Feature Definition: .res\Pavement\XS_AsphSurf EOP

☒ Superelevation Flag


Alternate Surface: Proposed Finished Grade

Member of:
Asphalt Surface Pavement
RT_A2 Shoulder Asphalt Surface

Constraints

	Constraint 1	Constraint 2
Type:	Slope	Horizontal
Parent 1:	AsphSurf_T_CL	AsphSurf_T_CL
Parent 2:	<input type="checkbox"/> Rollover Values...	
Value:	-2.00%	12.0000
Label:	RT_Pvmt_Surf_Asph_Slo	RT_Pvmt_Surf_Asph_Wi
<input checked="" type="checkbox"/> Horizontal Feature Constraint	Linear\Design\DNC\DNC	
Range:	50.0000	

27. Next, we are going to define the amount of widening. The max amount of Widening will be 12' left and right of the centerline of Big Horn.



To get the Widening to stop at an offset of 12' from the baseline we will need to modify the **Big Horn - Match Existing Slope Surface Course** Template. To do this select the **RT_AsphSurf_T_EOP1** and the **LT_AsphSurf_T_EOP1** points and modify the **Horizontal Constraint** to have a parent point **AsphSurf_B_CL** with an **Offset = 12 ft**

For the previous step **edit** the following area in the Point Property dialog:

Point Properties

Name: RT_AsphSurf_T_EOP1

☐ Use Feature Name Override: RT_AsphSurf_T_EOP1

Feature Definition: .res\Pavement\XS_AsphSurf EOP

☒ Superelevation Flag

Alternate Surface: Proposed Finished Grade


Member of:

- RT_A2 Shoulder Asphalt Surface
- RT_Aspphalt Surface Pavement

Constraints

Constraint 1		Constraint 2	
Type:	Vector-Offset	Type:	Horizontal
Parent 1:	AsphSurf_T_CL	Parent 1:	AsphSurf_B_CL
Parent 2:	RT_AsphSurf_T_EOP	Parent 2:	
Value:	0.0000	Value:	12.0000
Label:		Label:	RT_Pvmt_Surf_AspH_Wi
<input checked="" type="checkbox"/> Horizontal Feature Constraint		<input type="checkbox"/> Linear\Design\DNC\DNC	
Range:	50.0000		

28. Close the **J5P0100.itl** Template Library and **Save** on exit.
29. Reopen a **Dynamic XS** view for the **Big Horn Corridor**. Verify the 12' Widening Limit by using a **Horizontal Temporary Dimension Line**.





Creating the Ramp Corridors

30. Create a Corridor for Ramp2

- Open the **New Corridor** tool by selecting the **OpenRoads Modeling Workflow** → **Corridors** Tab → **Create Section**
- Select the **Ramp 2** Alignment
- Right Click for the **Active Profile** (Ramp 2 Proposed).
- Corridor Name: **Ramp 2**
- Corridor **Feature Definition: 0-Preliminary x 5**
- Template: Components → Pavement - New → Asphalt Pavement w/Shoulders → A2 Shoulders Agg Base → **Asphalt Pavement 1 Lane w/Agg Base Asphalt Shoulder.**
- Start Station **13+00**, End Station **Lock to End**, and Drop Interval **5'**


31. Modify the **Template Drop** in the dgn:

- Make the Template Origin point **AsphSurf_T_EOP**
- Remove** the point constraints from **AsphSurf_T_EOP**.
- Change the **AsphSurf_T_EOP** Feature Definition to **XS_AsphSurf_CL**
- Add Horizontal and Slope Constraints to the **AsphSurf_T_CL** from point **AsphSurf_T_EOP**, horizontally **-18' @ -2%** slope.
- Change the **AsphSurf_T_CL** Feature Definition to **XS_AsphSurf_EOP**
- Add **Guardrail Widening** to the outside Edge of Shoulder:
End Conditions → Combined → Guardrail Widening
- Add a **6:1 Fill or 6:1 Foreslope and Back Ditch** End Condition to the right side of the Guardrail Widening:
End Conditions → Combined → **6:1 Fill or 6:1 Foreslope and Back Ditch**
- Change the **AsphSurf_T_O_EOS** point properties from a **Vector-Offset** constraint to a **Slope** Constraint 2% sloping downward.




- Click **OK** to save the Template

32. From the **OpenRoads Modeling** Workflow, select **Create Template** by selecting the **Corridors** Tab → **Create Section** → **Template** Tools.




33. Navigate to the **J5P0100** folder and create a new folder called **Ramps**.
- From the Create Template dialog select **Tools** → **Template Library Organizer**
 - Copy the **Asphalt Pavement 1 Lane w/Agg Base Asphalt Shoulder** to the **J5P0100** → **Ramps** Folder



- Close, Save, and Check In the Template Library when prompted

34. Create a Corridor for **Ramp4**

- Open the **New Corridor** tool by selecting the **OpenRoads Modeling** Workflow → **Corridors** Tab → **Create Section**
- Select the **Ramp 4** Alignment
- Right Click for the **Active Profile** (Ramp 4 Proposed).
- Corridor Name: **Ramp 4**
- Corridor **Feature Definition: 0-Preliminary x 5**
- Template: **J5P0100** → **Ramps** → **Asphalt Pavement 1 Lane w/Agg Base Asphalt Shoulder**.
- Start Station **0+56**, End Station **3+55**, and Drop Interval **5'**




35. Add a **Point Control** to Ramp4 corridor for both **Vertical** and **Horizontal** to meet Ramp2 corridor. (Note: Make sure all references are displayed in the view)
- Open the **Point Control** Tool from the **Ramp 4** heads up display
 - Set the Start Station **0+00**
 - Set the End Station **3+55**
 - Control Description: **Ramp4 Match Ramp2**
 - Point: **AsphSurf_T_CL**
 - Mode: **Both**
 - Control Type: **Corridor Feature**
 - Corridor: **Ramp2**
 - Reference Feature: **3D Linear Element AsphSurf_T_CL**
 - Priority: **1**
 - Horizontal and Vertical Offsets: **0**

Create Point Co... — □ ×


Parameters	
Lock To Start	<input type="checkbox"/>
<input checked="" type="checkbox"/> Start	0+00.00
Lock To End	<input type="checkbox"/>
<input checked="" type="checkbox"/> Stop	3+55.00
Control Description	Ramp 4 match Ramp 2
Point	AsphSurf_T_CL
Mode	Both
Control Type	Corridor Feature
Corridor	RAMP2
Reference Feature	AsphSurf_T_CL
Priority	1

Horizontal Offsets	
Start	0.0000
Stop	0.0000

Vertical Offsets	
Start	0.0000
Stop	0.0000




NOTE: There appears to be a problem with the **Ramp 2 Profile**. The **Ramp 2 Profile** is supposed to be designed so that the **Crown Point** in-between the **Ramp 2** and **Ramp 4 Corridors** matches the elevation of the **Big Horn EOP/EOP** line. You can see in the 3D view that the **Ramp 2 Corridor** is diving too far below into the Big Horn Corridor.



36. **Open** the **Civil_Geometry_J5P0100.dgn** file
37. **Reference** in the **2D Model** of the **Corridors_J5P0100.dgn**.
38. Make the terrain **active**

39. Open the **Profile Model** for **Ramp 2** and zoom in to an area near the end of the profile.


Utilizing the **Create 3D Cut** tool (the third icon from the right), and the **Corners** option, place a box around the end of the profile. You can see that the profile is not ending anywhere near the EOP/EOS point of the Big Horn Template.



Adjust the **Station** and **Elevation** of the end of the Profile to the following:

Station = 16+43.31


Elevation = 764.57 (See calculations below.)




40. Open the **Corridors_J5P0100.dgn** file to see the adjustments to the Ramp 2 Corridor modeling up to the **EOP/EOS** point of Big Horn.

Creating the Radius Return Linear Templates


41. Reopen the **Civil_Geometry_J5P0100.dgn** file.
42. Using the **Feature Definition Toggle Bar** set the Feature Definition to **MoDOT_Baseline_Proposed** (located under Alignment) and toggle on **Use Active Feature Definition**.
43. For the **SW Radius Return**, select the “**Simple Arc**” tool by selecting the **OpenRoads Modeling** Workflow, then **Geometry Tab** → **Horizontal Section** → **Arc Tools** → **Arc Between Elements**.
- First select the **EOP** line (Baseline) of **Ramp2** and then the **EOP** line of **Big Horn Drive** to place the Arc.
 - Use a radius of **75**.
 - Trim: **None**
 - Name: **SW**



44. For the **NW Radius Return**, use the same **Simple Arc** tool with a radius of 75.
- First select the **EOP** of **Big Horn Drive** then the **EOP** (Baseline) for **Ramp4**. (Important to go in this order so the same template can be used later)
 - Use a radius of **75**.
 - Trim: **None**
 - Name: **NW**



45. Define the **Start Station (0+00)** for each radius return as indicated below using the “**Start Station**” tool. To do this select the **OpenRoads Modeling Workflow**, then **Geometry Tab** → **Horizontal Section** → **Modify Tools** → **Start Station**



46. In the next few steps, we are going to define a profile for the Radius Returns based on the **longitudinal** slopes of the edge of pavements coming into each Radius Return.


First, we are going to use the **Project Extended Profile** tool to view the longitudinal EOP slope coming into and out of the Radius Returns. Then we will use the **Quick Profile Transition** tool to define the transition profile between the two extended profiles.

The **Project Extended Profile** tool is located under the **OpenRoads Modeling Workflow, Geometry Tab → Vertical Section → Profile Creation Tools**.


The **Quick Profile Transition** tool is located under the **OpenRoads Modeling Workflow, Geometry Tab → Vertical Section → Element Profiles Tools**.

NW Radius Return:

- Open the **Profile Model** for the **NW Radius Return**.
- Using the **Project Extended Profile** tool place both longitudinal new Edge of Pavement profile slopes coming into the Radius Returns. Use a **Feature Definition of EOP New** (located under Linear → Design → Roadway).



- Apply a vertical profile to the NW radius return using the **Quick Profile Transition** tool. Using the **Parabolic** method with a Feature Definition of **MoDOT_Baseline_Proposed** (located under **Alignment**).
- Name the Profile: **NW Proposed**




Note: The **Quick Profile Transition** tool will automatically make the newly created profile Active.


47. Drop the **Rules** of the newly created **NW Proposed Profile**.
48. (**Individual Step**) Using the same steps in storing a profile for the **NW Radius Return**, store a profile for the **SW Radius Return** (start on Step 46).
49. Do not do the following step until both the SW and NW profiles have been stored.

Detach the **Corridors_J5P0100.dgn** file from the **Civil_Geometry_J5P0100.dgn** file. When prompted, break the rules between the two files. The **Extended Profiles** (white lines) should disappear from both the NW and SW Profile models leaving the Proposed Profiles (yellow lines).


50. Open the **Corridors_J5P0100.dgn** file.
51. Select the **NW Radius Return**'s alignment and open the heads-up tools and then select **Apply Linear Template**.



52. Set the **Apply Linear Template** dialog up as follows:




53. Individually select the **Big Horn** and **Ramp 4** corridors and select their heads-up tools and add the **NW Linear Template** as a **Clipping Reference**.




Radius Return Linear Templates draw to Big Horn Edge of Pavement

Next, we are going to make the Left EOP in the NW template (**AsphSurf_T_CL**) draw up to the Right Outside Edge of Pavement in the **Big Horn** template (**RT_AsphSurf_T_EOP1**).


To do this we will use a **Point Control**.



But first, another piece of information we will need for our Point Control is the **Start** and **Stop** Location for drawing to the **Big Horn Edge of Pavement**. With the NW Linear Template, we will start at **Sta. 0+00** and end at **Sta. 0+68.45**



54. Using the heads-up prompts on the **NW Linear Template** grips, select the **Corridor Creation Tools → Point Controls**



Fill out Point Control dialog as shown below:

Start Station:	Lock to Start
Stop Station:	0+68.45
Control Description:	Draw NW EOP to Big Horn EOP
Point:	AsphSurf_T_CL
Mode:	Both
Control Type:	Corridor Feature
Corridor:	Big Horn
Reference Feature:	RT_AsphSurf_T_EOP1
Priority:	1
Start Horz. Offset:	0
Stop Horz. Offset:	0
Start Vertical Offset:	0
Stop Vertical Offset:	0

 A screenshot of the 'Create Point Control' dialog box. The dialog is organized into three main sections: 'Parameters', 'Horizontal Offsets', and 'Vertical Offsets'.


- Parameters:** Includes checkboxes for 'Lock To Start' (checked) and 'Lock To End' (unchecked). It has input fields for 'Start' (0+00.00) and 'Stop' (0+68.45). Below these are dropdown menus for 'Control Description' (DrawNW EOP to Big Horn EOP), 'Point' (AsphSurf_T_CL), 'Mode' (Both), 'Control Type' (Coridor Feature), 'Corridor' (BIG HORN), 'Reference Feature' (RT_AsphSurf_T_EOP1), and a 'Priority' field (1).
- Horizontal Offsets:** Contains input fields for 'Start' (0.0000) and 'Stop' (0.0000).
- Vertical Offsets:** Contains input fields for 'Start' (0.0000) and 'Stop' (0.0000).

55. **(Individual Step)** Using the same steps in storing the **NW Linear Template**, that drew the **NW EOP** up to the **Big Horn EOP**. Create a **Linear Template** and then a **Point Control** for the **SW Radius Return** that does the same thing. (These steps started back on step 51).

Note: You will use the same Template that was used in the **NW Linear Template**.

Radius Return Linear Templates draw to Ramp 2 Edge of Pavement

In the second part of modeling our **NW and SW Linear Templates** we are going to use another **Point Control** to draw the EOP up to the **Ramp 2 EOP** line.



56. Using the heads-Up prompts on the **NW Linear Template** grips, select the **Corridor Creation** tools → **Point Controls**. Fill out dialog as indicated below:

Start Station:	0+68.45
Stop Station:	Lock to End
Control Description:	Draw NW EOP to Ramp 2 EOP
Point:	AsphSurf_T_CL
Mode:	Both
Control Type:	Corridor Feature
Corridor:	Ramp 2
Reference Feature:	AsphSurf_T_CL
Priority:	1
Start Horz. Offset:	0
Stop Horz. Offset:	0
Start Vertical Offset:	0
Stop Vertical Offset:	0

Create Point Control	
Parameters	
Lock To Start	<input type="checkbox"/>
<input checked="" type="checkbox"/> Start	0+68.45
Lock To End	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Stop	1+17.81
Control Description	Draw NW EOP to Ramp 2 EOP
Point	AsphSurf_T_CL
Mode	Both
Control Type	Corridor Feature
Corridor	RAMP2
Reference Feature	AsphSurf_T_CL
Priority	1
Horizontal Offsets	
Start	0.0000
Stop	0.0000
Vertical Offsets	
Start	0.0000
Stop	0.0000


57. **(Individual Step)** Using the same steps in storing the **NW Linear Template**, that drew the **NW EOP** up to the **Ramp 2 EOP**. Create a **Point Control** for the **SW Radius Return** that does the same thing.

Hint:

Start Station:	Lock to Start
Stop Station:	0+50.90
Control Description:	Draw SW EOP to Ramp 2 EOP
Point:	AsphSurf_T_CL
Mode:	Both
Control Type:	Corridor Feature
Corridor:	Ramp 2
Reference Feature:	AsphSurf_T_CL
Priority:	1
Start Horz. Offset:	0
Stop Horz. Offset:	0
Start Vertical Offset:	0
Stop Vertical Offset:	0



Modeling Bonus Steps:

58. If your model has a vertical slice sticking up at the Big Horn EOP (see below)...




You may need to add a slight offset to the **SW Linear Template Point Control**. To do this select the **Corridor Objects** icon from the **SW Linear Template** heads-up tools.

After selecting **Point Control** in the Corridor Objects dialog edit the **Big Horn EOP** Point Control. Add a **-0.0001 Horizontal Offset** to both the **Start** and **Stop Offset** (See Below).




Modeling Bonus Steps (Continued):


59. If your model has a mismatched ditch between the **NW Linear Template** and the **Ramp 4 Corridor** (see below)...



You may need to change the **Corridor Feature Definition** for the **Ramp 4 Corridor** from **0-Preliminary x5** to **1-Final x1**.


Also, from the **Ramp 4 Corridor** add in a **Key Station** at **0+87.01**.




Creating a Right Turn Only Grassy Island

60. Open the **Cole/J5P0100/Roadway/data/Corridors_J5P0100.dgn** (If not in it already).
61. From the Corridors file, we will create a Terrain Surface from the **NW** and **SW Linear Templates** to use as a reference surface to create a profile for the island. **Press F6** to make sure the 3D window is open.

Before we create the terrain, first switch the **NW** and **SW Linear Template** Feature Definition to **2-Final x1 Top Mesh Only**. To do this you go into the **Properties** of the Linear Template.




62. Within the **3D Model** and a **Top View** first select the **SW** Radius Return Linear Template.




The corridor road surface highlights.

63. Next, select the **NW** Radius Return Linear Template.



64. To create the Terrain, select the **From Elements** tool by selecting the **OpenRoads Modeling Workflow** → **Terrain Tab** → **Create Section**.

Fill out the dialog as follows:



Left-Click to accept two previously selected elements.

Left-Click to accept the option of **Breakline** for the type.


For Edge Method: **Max Triangle Length** of 10

65. Press **F4** to clear out the tool.


66. Next, we are going to **export** the terrain to a new file via an **XML** file. To export the file to XML we are going to utilize the **Explorer** Tool.

To open Explorer, select the **OpenRoads Modeling Workflow** → **Home Tab** → **Primary** Section.

67. Within **Explorer** select the **OpenRoads Model** section:




68. Right click on the Island Terrain model and select **Export Terrain Model → LandXML**




69. Fill out the Export Terrain to LandXML dialog as follows:


Select Terrain:	Island
Export Format:	LandXML (.xml)
Project Name:	(Optional) use J5P0100
Project Description:	(Optional)
Export Options:	Export Triangles Only



70. Once exported, delete the **Island Terrain** in the **Corridors_J5P0100.dgn** file. Also switch the **Linear Template Feature** back to **1-Final x 1**.
71. Next, we are going create a **NEW DGN** file to store our **Island Terrain**.
- Create a new dgn file named **Terrain_Proposed_J5P0100.dgn** using the **MoDOT_Roadway_Seed_3D.dgn** seed file.
72. Open the **Coordinate System** tool by selecting the **OpenRoads Modeling Workflow** → **Utilities Tab** → **Geographic Section**.
73. Select “**From File**” icon.



74. Select the **Terrain_Existing_J5P0100.dgn** file in the **data** folder.
75. Verify the settings.



76. In this step we are going to import the Terrain Model. To open the **Create from File** tool select the **OpenRoads Modeling Workflow** → **Terrain Tab** → **Create Section**. Fill out the dialog as follows and select **Import**:

Import Terrain Model(s)

Global Options

Terrain Models

Append to existing Terrain Model ☐

Terrain Model to append to

Projection

Target CD - Cole 2011

TargetDescription NAD83/2011 Missouri State

TargetUnits FOOT

File Options

Feature Definition

Feature Definition Terrain\Design Triangles

Filter

Source File Units US Survey Feet

LandXML

Build Terrain From Source And Definition

Triangulation Options

Import Options Import Terrain Only

Geographical Coordinate Systems

Source None

Import

PW_WORKDIR:d0335785\Island.xml

LandXML Import Options

- **Definition** - Utilizes the stored triangulated faces to define the Terrain
- **Source** - Utilizes survey features such as breaklines, voids and points, then triangulates.
- **Source and Definition** (default) Utilizes both in creating the terrain.

Notes: These import options are unique to LandXML files. **Best Practice** on which **LandXML Build Terrain From** Option to use:


- The method used will usually depend on the file and the situation.
- If you do not want to re-triangulate (i.e. you want to duplicate the triangles from the terrain that generated the LandXML file), then use the **Definition** method.
- Otherwise, the default (and recommended method) is to use **Source and Definition**. This does re-triangulate, but uses both triangles **and** source data to produce a “best” triangulation.



2017 Bentley OpenRoads Designer Best Practice – Terrain Modeling

77. Open the **Cole/J5P0100/Roadway/data/Civil_Geometry_J5P0100.dgn**
78. Using the **Feature Definition Toggle Bar** set the Feature Definition to **Island (New)** (located under **Linear → Design → Roadway**) and toggle on **Use Active Feature Definition**.
79. To help create the limits of the Island we are going to use the **Single Offset Entire Element** tool. To do this select the **OpenRoads Modeling Workflow → Geometry Tab → Horizontal Section → Offset and Tapers** tools. Select the **NW Radius Return** to off set the line toward the intersection.

Offset:	-18
Use Spiral Transitions:	No
Mirror:	No
Remove Offset Rule:	No
Feature Definition:	Island (New)
Name:	Island North



80. Repeat the **Single Offset Entire Element** tool for the **SW Radius Return**. Offset the line toward the intersection.

Offset:	-18
Use Spiral Transitions:	No
Mirror:	No
Remove Offset Rule:	No
Feature Definition:	Island (New)
Name:	Island South

Single Offset E...

Parameters

☒ Offset: -18.0000

Use Spiral Transitions ☐

Mirror ☐

Remove Offset Rule ☐

Feature

Feature Definition Use Active Feature

Name Island South

81. Repeat the **Single Offset Entire Element** tool, one more time, for the **Big Horn** baseline. Offset the line toward the **West** (away from the Big Horn centerline).

Offset:	17
Use Spiral Transitions:	No
Mirror:	No
Remove Offset Rule:	No
Feature Definition:	Island (New)
Name:	Island Big Horn

Single Offs...

Parameters

☒ Offset: 17.0000

Use Spiral Transitions ☐

Mirror ☐

Remove Offset Rule ☐

Feature

Feature Definition Use Active Feature

Name Island Big Horn

82. To help round the corners of the Island we are going to use the **Simple Arc** tool. To do this select the **OpenRoads Modeling Workflow** → **Geometry Tab** → **Horizontal Section** → **Arcs** → **Arc Between Elements** tools.

Trim Extend:	Both
Radius:	4 feet
Loop:	No
Feature Definition:	Island (New)
Name:	Island Noses

Simple...

Parameters

Trim/Extend Both


☒ Radius 4.0000'

Loop ☐

Feature

Feature Definition Use Active Feature

Name Island Noses



83. Next, we are going to **Create a Complex Element** around the island to make it one piece. To do this use the **Complex by Elements** tool located under the **OpenRoads Modeling Workflow** → **Geometry Tab** → **Horizontal Section** → **Complex Geometry** tools.

Method:	Manual
Max Gap:	Use Default (0.0328)
Feature Definition:	Island (New)
Name:	Island

Create ...	
Parameters	
Method	Manual
Maximum Gap	0.0328
Feature	
Feature Definition	Use Active Feature
Name	Island

- Click each line/arc that makes up the island. Make sure each arrow points in the clockwise direction. (Manual option makes sure the elements all go in the correct direction).
 - Accept the last element in a blank area with a **Left Click**.
84. Reference within the **Default 2D Model** the following file:

Terrain_Proposed_J5P0100.dgn


85. Open the **Island's Profile Model** in **Window 8**.

86. Next, we are going to create a **Profile** from the **Island** Terrain Model created earlier. To do this use the **Quick Profile from Surface** tool located under the **OpenRoads Modeling Workflow → Geometry Tab → Vertical Section → Profile Creation** tools.

- For **Locate Reference Element**, Left Click on the **Island** Complex Element.
- For **Locate Reference Surface**, choose the **Island** Terrain Model.

The profile is automatically created.

87. Left Click on the new **Island** profile (solid light green line), then name it **Island Proposed** and set it **Active**.



88. Open the Cole/J5P0100/Roadway/data/Corridors_J5P0100.dgn

89. Make sure you can see the new **Island** geometry, if you don't see the Island, use the **Level Display** to visualize the Island elements, **Level → Roadway Safety**.

90. To help the Island draw to the **Proposed "Island" Surface** created back on **Step 71**, reference within the **Default 2D Model** the following file:

Terrain_Proposed_J5P0100.dgn

91. Open the **Create Template** tool by selecting the **OpenRoads Modeling Workflow → Corridors Tab → Create Section → Template** tools.

92. From the Corridor tools click on the **Create Template** tool


Make sure the **J5P0100.itl** is open, if not, click **File → Open** and select:

Cole/J5P0100/Roadway/J5P0100.itl

93. From the **Components → Curb and/or Gutter** folder, *copy* **Curb and Gutter Type B** to the J5P0100 → **Ramps** folder.

94. **Double-click** on the newly copied **Curb and Gutter Type B** to open it in the editor window.

95. Change the template origin to be the **Curb_Surf_Flowline** point and remove the constraints on the gutter point. Simply Right-Click on the **Curb_Surf_Flowline** point and choose the **Change Template Origin**.



96. Zoom to the left of the template and locate the **Curb_Surf_Edge** point. **Double-click** on this point.


Set the Point Constraints to the following:

Constraint 1: **Horizontal**
 Parent 1: **Curb_Surf_Flowline**
 Value: **-2.5000**

Constraint 2: **Project to Surface**
 Parent 1: **Any Direction**
 Surface: **Island**

Constraints	
Constraint 1	Constraint 2
Type: Horizontal	Type: Project To Surface
Parent 1: Curb_Surf_Flowline	Parent 1: Any Direction
Value: -2.5000	Surface: Island
Label: 	Label:
<input type="checkbox"/> Horizontal Feature Constraint	Linear\Design\DNC\DNC
Range: 0.0000	


97. Run the **Test** when finished to see the Edge rise and fall with the surface.
98. **Close**, then **Save** changes to the **J5P0100.itl**, and then **Check-In**.
99. Select the **Island** geometry and bring up it's heads up tools and select **Apply Linear Template**.



100. Fill out the **Apply Linear Template** dialog as follows:

Lock to Start:	Check
Lock to End:	Check
Exterior Corner Sweep Angle:	5
Mirror:	No
Reflect:	No
Template:	Curb and Gutter Type B
Description:	Optional
Feature Definition:	1-Final x 1
Name	Island


101. Press **F4** to clear out the tool.
102. Press **F6** if the **Default-3D** window is not showing.
- At this point, the 3D model should show the new island.




Next, we will add a grass top to the island.

103. Make the 3D view active, open the tool from Terrain Model tools, **Create from Elements**


Feature Type:	Boundary
Edge Method:	None
Feature Definition:	Design Grassy Area
Name	Island Grassy Area



For *Locate Element to Add*, **Left-Click** the 3D line along the top inside edge of the curb (**Curb_Surf_Back**).




104. For *Locate Next Element*, **zoom out** to see a blank area, **Right-Click** in the blank area of the Default 2D View.
105. **Left-Click** to the prompts to accept all the values already entered in the dialog.




After the island is placed, let's look at the dynamic cross sections for the **Ramp-4** Corridor.

106. Left-Click on the **Ramp-4** Corridor Grip and bring up the heads-up tools.




107. Open **Window 8** and left click in the window to display the Dynamic XS View.




108. To clip the pavement area out below the Island let's do the following:

Select the **SW** and **NW** Radius Return **Liner Templates** and Add a **Clipping Reference** and select the **Island Linear Template** as the Reference.




Below is what the **Ramp 4 Dynamic XS View** should look like after the **Clipping References** have been applied:



Remove Grassy Island for Concrete Island

109. First, we need to turn off the Triangles of the Grassy Area. If we don't the grassy area will still bleed through the newly placed pavement. The Grassy Island Terrain Model resides within the 3D view, with that view turn off the Triangles of the Island Grassy Area,
110. Using the **Apply Surface Template** tool located under the **OpenRoads Modeling Workflow** → **Model Detailing** Tab → **3D Tools** Section → **Surface Template** tools.



- a) For the Template select the following from the MoDOT section of the Template Library (itl):

Components\Pavement - New\Pavement Only\Concrete\Concrete Pavement w/ Rock Fill Base.


- b) Do not **Apply an External Clip Boundary**
c) Select **Enable Linear Features**
d) Name the Surface Feature **Concrete Island**

Notes:


Apply External Clip Boundary will limit the area the Surface Template within a User selected closed area/element.

Enable/Disable Linear Features will tell the program to either plot all the **Mesh** Layers of the Template (Enable), or just the Surface **Mesh** Layer (Disable).


111. **Edit** the newly applied **Surface Template**.



112. When the Template window opens select the **Active Template** Tab. Then open the **Parametric Constraints** folder and **right-click** on the **Pvmt_Surf_Conc_Depth** and select **Edit**.




113. Change the Default value to -4 inches by typing in **-4/12** and then select **OK**.



114. Select **OK** to the **Editing Roadway Designer Template Drop** dialog.

115. **Review** the **Dynamic XS Model** for the updated Concrete Island.



Sight Visibility Tools


116. Create a new dgn file named **Site_Visability_J5P0100.dgn** using the:

MoDOT_Roadway_Seed_2D.dgn seed file.

Note: This new file will hold all the Site Lines for this Project.


117. Open the **Coordinate System** tool by selecting the **OpenRoads Modeling** Workflow
→ **Utilities** Tab → **Geographic** Section.

118. Select “**From File**” icon.



119. Select the **Terrain_Existing_J5P0100.dgn** file in the **data** folder.

120. Verify the settings.



121. Reference in the following files within the **Default 2D Model**:

Civil_Geometry_J5P0100.dgn
Corridors_J5P0100.dgn
Terrain_Existing_J5P0100.dgn

122. Fit View, change the Annotation Scale to **1”=50’**, and set the Existing Terrain as **Active**.

123. Open **View Attributes** and turn-on **Line Weights**. This will help with visualizing the Site Lines that are drawn in the 2D Default View.

124. Select **F6** key to open the Multi-Model Views.

Sight Visibility Tools

Recently **OpenRoads Designer** added a **Sight Visibility** tools that analyzes a corridor and/or terrain to display what can be seen and not seen along a given line of sight.



It uses the **Stopping** and **Passing Sight Distance** listed in **AASHTO Green Book 2018** and **MUTCD 2009**.

The Sight Visibility Tools can use a **pre-defined** Settings file to define the lengths of visibility. For MoDOT Users that setting file is called:

MoDOT-Sight Visibility Tables and Equations.xml

The Sight Visibility Tool uses a **Height of Eye** Position of **3.50 feet** and a **Height of Object** of **2.0 feet**, as defined in the setting file.

Sight Distance - Stopping Sight Distance


EPG Category 230.2

AASHTO 2018 Green Book Section 3.2.2



Definition – **Stopping Sight Distance (SSD)**, based on the anticipated posted speed, is the **sum** of the distance for **Braking Reaction** and the **Braking Distance** required for a driver to stop the vehicle after sighting an object on the roadway.

1. **Break Reaction Distance:** the distance traversed by the vehicle during the time the driver takes to react.
2. **Breaking Distance:** the distance needed to stop the vehicle.



Sight Distance - Stopping Sight Distance

EPG Category 230.2

AASHTO 2018 Green Book Section 3.2.2



AASHTO Table 3-1. Stopping Sight Distance on Level Roadways

U.S. Customary				
Design Speed (mph)	Brake Reaction Distance (ft)	Braking Distance on Level (ft)	Stopping Sight Distance	
			Calculated (ft)	Design (ft)
15	55.1	21.6	76.7	80
20	73.5	38.4	111.9	115
25	91.9	60.0	151.9	155
30	110.3	86.4	196.7	200
35	128.6	117.6	246.2	250
40	147.0	153.6	300.6	305
45	165.4	194.4	359.8	360
50	183.8	240.0	423.8	425
55	202.1	290.3	492.4	495
60	220.5	345.5	566.0	570
65	238.9	405.5	644.4	645
70	257.3	470.3	727.6	730
75	275.6	539.9	815.5	820
80	294.0	614.3	908.3	910
85	313.5	693.5	1007.0	1010

AASHTO Table 3-2. Stopping Sight Distance on Grades

U.S. Customary						
Design Speed (mph)	Stopping Sight Distance (ft)					
	Downgrades			Upgrades		
	3%	6%	9%	3%	6%	9%
15	80	82	85	75	74	73
20	116	120	126	109	107	104
25	158	165	173	147	143	140
30	205	215	227	200	184	179
35	257	271	287	237	229	222
40	315	333	354	289	278	269
45	378	400	427	344	331	320
50	446	474	507	405	388	375
55	520	553	593	469	450	433
60	598	638	686	538	515	495
65	682	728	785	612	584	561
70	771	825	891	690	658	631
75	866	927	1003	772	736	704
80	965	1035	1121	859	817	782
85	1070	1149	1246	949	902	862

MoDOT-Sight Visibility Tables and Equations.xml file.

```


1 <?xml version="1.0" encoding="utf-8"?>
2 <OpenRoadsSightVisibility xmlns="OpenRoads">
3   <Methods>
4     <!-- 2018 AASHTO Standard Variables and Constants -->
5     <!-- double reactionTime //Brake reaction time. Defaults to 2.5 seconds if not defined in this settings file -->
6     <!-- double gradeThreshold // Grades(ft/ft) less than gradeThreshold will use SSD equation 3-2 -->
7     <!-- // Grades(ft/ft) greater than or equal to the gradeThreshold will use SSD equation 3-3 -->
8     <!-- double gravityConst = 32.2; // feet/sec^2 -->
9     <!-- int roundingMultiple // Computed Required Sight distances will be rounded to this multiple. 0 indicates no rounding.-->
10    <SightDistanceMethod name="2011 AASHTO Stopping Site Distance - Zero Offset" methodType="AASHTO_2011_SSD" >
11      <EyePosition interval="50.0" offset="0.0" height="3.5"/>
12      <ObjectPosition moveTargetToAchieveVisibility="false" interval="10.0" offset="0.0" height="2.0"/>
13      <StandardVariables reactionTime="2.5" gravityConstant="32.2" gradeThreshold="0.03" roundingMultiple="1"/>
14    </SightDistanceMethod>
15    <SightDistanceMethod name="2011 AASHTO Stopping Site Distance - Eye 9 foot Offset" methodType="AASHTO_2011_SSD" >
16      <EyePosition interval="50.0" offset="9" height="3.5"/>
17      <ObjectPosition moveTargetToAchieveVisibility="false" interval="10.0" offset="0.0" height="2.0"/>
18      <StandardVariables reactionTime="2.5" gravityConstant="32.2" gradeThreshold="0.03" roundingMultiple="1"/>
19    </SightDistanceMethod>
20
21    <!-- 2018 AASHTO Tables -->
22    <SightDistanceMethod name="AASHTO 2018 Stopping on Level Roadways" methodType="Table" >
23      <EyePosition interval="50.0" offset="0.0" height="3.5"/>
24      <ObjectPosition moveTargetToAchieveVisibility="true" interval="10.0" offset="0.0" height="2.0"/>
25      <SpeedTableEntry speed="15" sightDistance="80" relaxedDistance="80"/>
26      <SpeedTableEntry speed="20" sightDistance="115" relaxedDistance="115"/>
27      <SpeedTableEntry speed="25" sightDistance="155" relaxedDistance="155"/>
28      <SpeedTableEntry speed="30" sightDistance="200" relaxedDistance="200"/>
29      <SpeedTableEntry speed="35" sightDistance="250" relaxedDistance="250"/>
30      <SpeedTableEntry speed="40" sightDistance="305" relaxedDistance="305"/>
31      <SpeedTableEntry speed="45" sightDistance="360" relaxedDistance="360"/>
32      <SpeedTableEntry speed="50" sightDistance="425" relaxedDistance="425"/>
33      <SpeedTableEntry speed="55" sightDistance="495" relaxedDistance="495"/>
34      <SpeedTableEntry speed="60" sightDistance="570" relaxedDistance="570"/>
35      <SpeedTableEntry speed="65" sightDistance="645" relaxedDistance="645"/>
36      <SpeedTableEntry speed="70" sightDistance="730" relaxedDistance="730"/>

```

Sight Distance - Passing Sight Distance

AASHTO 2018 Green Book Page 3-11 & NCHRP Report 605

Minimum Passing Sight Distance



Sight Distance - Passing Sight Distance

MUTCD 2009

AASHTO 2018 Green Book Section 3.2.4.1



Minimum Passing Sight Distance

AASHTO 2018 Green Book states *“Minimum passing sight distances for use in design are based on the minimum sight distances presented in the MUTCD as warrants for no-passing zones on two-lane highways.”*

Table 3B-1. Minimum Passing Sight Distances for No-Passing Zone Markings

85th-Percentile or Posted or Statutory Speed Limit	Minimum Passing Sight Distance
25 mph	450 feet
30 mph	500 feet
35 mph	550 feet
40 mph	600 feet
45 mph	700 feet
50 mph	800 feet
55 mph	900 feet
60 mph	1,000 feet
65 mph	1,100 feet
70 mph	1,200 feet

Note: For the **Non-Table Methods**, when the **AASHTO Stopping Sight Distance method** is selected, the program uses the Equations 3-2, and 3-3 from the 2011 and 2018 AASHTO Green book. In the 2018 edition these are in section “3.2.2 Stopping Sight Distance”.

125. Within the **3D** view of **Site_Visibility_J5P0100.dgn** file, rotate to a top view. Next, select the **Sight Visibility** tool by selecting the **OpenRoads Modeling Workflow** → **Terrain Tab** → **Analysis Section** → **Sight Visibility Tools**.
126. Define the dialog as follows and apply to the **Big Horn Corridor** and **Existing Ground Terrain**.

Settings File Name:	MoDOT-Site Visibility Tables and Equations
Method:	Table
Table Name:	AASHTO 2018 Stopping on Level Roadways
Speed:	60
Required Distance:	570
Relaxed Distance:	570
Locate Corridor:	Bighorn
Locate Eye Control Alignment:	Reset for Main Alignment
Locate Object Control Alignment:	Reset for Main Alignment
Start Station:	Lock to Start
End Station:	Lock to End
Located Existing Ground:	J5P0100 Terrain Existing

Sight Visibility

Parameters

Lock To Start ☒

☒ Start 0.0000'

Lock To End ☒

☒ Stop 2050.5198'

Settings File Name MoDOT-Sight Visibility Tables and Equations.xml

Method Table

Table Name AASHTO 2018 Stopping on Level Roadways

Speed 60

Required Distance 570.0000

Relaxed Distance 570.0000

Interval 50.0000

Offset 0.0000

Height 3.5000

Object Position

Move Target To Achieve Visibility ☒

Interval 10.0000

Offset 0.0000

Height 2.0000

Feature

Feature Definition Stopping Sight Distance

Name SSD

127. Compare your results with Table Below:

Sight Visibility Results - Section: SSD2												
<input checked="" type="checkbox"/> Achieved <input checked="" type="checkbox"/> Relaxed <input checked="" type="checkbox"/> Not Achieved <input type="checkbox"/> Show Selected												
Eye Position	Object Position	Eye Level	Actual Level	Object Level	Design Speed	Instantaneous Grade	Average Grade	Sight Distance Required	Sight Distance Relaxed	Sight Distance Achieved	Sight Distance Along Sight Line Achieved	Sight Line Status
1+97.77	7+67.77	745.0494	755.9403	755.9403	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.2536	Achieved
2+47.77	8+17.77	743.8854	756.6248	756.6248	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.5033	Achieved
2+97.77	8+67.77	743.1561	757.4337	757.4337	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.7933	Achieved
3+47.77	8+57.77	742.7835	757.2718	757.2718	60.0000	0.00%	0.00%	570.0000	570.0000	510.0000	509.9525	Not Achieved
3+97.77	7+97.77	743.0555	756.3325	756.3325	60.0000	0.00%	0.00%	570.0000	570.0000	400.0000	399.9981	Not Achieved
4+47.77	7+77.77	744.2481	756.0710	756.0710	60.0000	0.00%	0.00%	570.0000	570.0000	330.0000	330.0000	Not Achieved
4+97.77	8+57.77	747.0482	757.2718	757.2718	60.0000	0.00%	0.00%	570.0000	570.0000	360.0000	360.0000	Not Achieved
5+47.77	11+17.77	750.2274	762.2336	762.2336	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.9987	Achieved
5+97.77	11+67.77	752.7164	763.8850	763.8850	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.9574	Achieved
6+47.77	12+17.77	754.7762	765.5712	765.5712	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.8074	Achieved
6+97.77	12+67.77	756.0912	766.8441	766.8441	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.5020	Achieved
7+47.77	13+17.77	757.1289	767.7696	767.7696	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.0198	Achieved
7+97.77	13+67.77	757.8325	768.0095	768.0095	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	568.3680	Achieved
8+47.77	14+17.77	758.6099	767.9933	767.9933	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	567.8020	Achieved
8+97.77	14+67.77	759.4169	767.6060	767.6060	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	567.4702	Achieved
9+47.77	14+67.77	760.2828	767.6060	767.6060	60.0000	0.00%	0.00%	570.0000	570.0000	520.0000	517.7282	Not Achieved
9+97.77	14+67.77	761.1150	767.6060	767.6060	60.0000	0.00%	0.00%	570.0000	570.0000	470.0000	468.0413	Not Achieved
10+47.77	14+77.77	762.1642	767.5097	767.5097	60.0000	0.00%	0.00%	570.0000	570.0000	430.0000	428.3806	Not Achieved
10+97.77	14+97.77	763.3412	767.3448	767.3448	60.0000	0.00%	0.00%	570.0000	570.0000	400.0000	398.8284	Not Achieved
11+47.77	15+57.77	764.7916	766.6731	766.6731	60.0000	0.00%	0.00%	570.0000	570.0000	410.0000	409.2498	Not Achieved
11+97.77	17+67.77	766.4056	766.4065	766.4065	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.5667	Achieved
12+47.77	18+17.77	767.9006	766.9980	766.9980	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.8435	Achieved
12+97.77	18+67.77	768.9387	767.8928	767.8928	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.9685	Achieved
13+47.77	19+17.77	769.4572	768.9947	768.9947	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.9884	Achieved
13+97.77	19+67.77	769.5249	770.4621	770.4621	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.9827	Achieved
14+47.77	20+17.77	769.2987	772.2503	772.2503	60.0000	0.00%	0.00%	570.0000	570.0000	570.0000	569.9786	Achieved

Note: Move Target to Achieve Visibility is defined as follows: The Object position's XY location is calculated like the Eye Position. However, for object position, the location is down range from the Eye Position along the Control Reference alignment a distance equal to the Required Distance.

When Move Target is **On** a sight line for each Object Position Interval is analyzed until the Required distance is either achieved for that Eye Position or an intersection with a design or an existing terrain or mesh is found. In the case where an intersection is found and the Required Sight Distance has not been achieved, the analysis displays the last successful sight line for that eye position.

128. In the 3D view, select and then delete the **Sight Lines** that were drawn in the previous step.

129. Again, make sure 3D view is set to a TOP view.

130. Next, select the **Line of Sight** tool by selecting the **OpenRoads Modeling Workflow** → **Terrain Tab** → **Analysis Section** → **Sight Visibility Tools**.

131. Fill in the **Sight Lines** prompts/dialog when directed, working within in the **2D** view:

Settings File Name:	MoDOT-Site Visibility Tables and Equations
Method:	Radial
Locate Corridor or Design Surface:	Select the Bighorn Corridor
Locate the Existing Surface:	J5P0100 Existing Ground
Eye position:	Click somewhere within the Existing Ground Terrain
Object position:	Click somewhere within the Existing Ground Terrain
Stop Direction	Try to make a 360-degree solution.

Line of Sight

Parameters

Method: Radial

Eye Position

Height: 3.5000

Object Position

Height: 2.0000

☐ Radius: 0.0000'

☐ Start Direction: 00°00'00"

☐ Stop Direction: 00°00'00"

Direction Interval: 10°00'00"


☐ Hand: Clockwise

Feature

Feature Definition: Stopping Sight Distance

Name: SSD


Note: You will need to datapoint both the **Height of Eye** and the **Height of Object** positions in the 3D view. When you Data Point to Accept Design the Sight Triangle will be placed in the **3D View**.




132. In the **Corridors_J5P0100.dgn** 3D view, select and then delete the **Sight Lines** that were drawn in the previous step.

3D Drive Through


133. Within the **Corridors_J5P0100.dgn** file select the **3D Drive Through** tool by selecting the **OpenRoads Modeling Workflow** → **Corridors Tab** → **Review Section**.
134. Select the 3D view, and then select the centerline of Big Horn Drive.
135. Under **General Controls** Tab set the following settings:





136. Within the **Advance Control** Tab set the following settings:




137. Within **Camera/Target Controls** Tab set the following settings:



138. Lastly, go back to the **General Controls** Tab and select the **Play** icon. Utilize the **Reverse** and **Rotate View** controls.




139. After using the 3D Drive Tool, you will notice a fish-eyed view within your 3D View, to turn that view effect off go into the **View Attributes** and deselect the “**Camera**” setting:



OpenRoads Designer Road 2


Ramp Transition & Special Ditch




19.1 Group Exercise: Ramp Transition Layout

Objective and Background Information

The objective of this exercise is to demonstrate how the Power GeoPak Civil Tools can be used to create a profile for a ramp transition. This is the area between the sections A-A and E-E in the following figure from Missouri Standard Plans for Highway Construction (203.41). The profile will be applied along the ramp chain.



As the figure indicates, the ramp is in Superelevation transition from the pavement cross slope at Section A-A to the Superelevation required for the beginning curve of the ramp at Section E-E. These two sections as shown in the standard plans are provided below.



The break in the slope between the mainline and the ramp can occur

Before proceeding with the steps to create the profile, a decision needs to be made regarding the location of the break line between the mainline and ramp cross slopes. According to the Design Standards group, the exact location of this break line at Section E-E is not set. It can be located anywhere within the two-foot width of the ramp nose. For the purposes of this exercise, it will be located on the ramp side of the nose and held at a constant offset of 20' relative to the ramp chain from the ramp nose back to the point where this offset intersects with the mainline edge of pavement. As a designer, you can determine its location for your project.

Also needed is the Superelevation rate at the ramp nose, which is based on the design speed of the ramp and the radius of the curve. The radius of the first curve in Ramp 2 is 1,041 feet.

The relevant portion of the Superelevation table from Missouri Standard Plan 203.20F is shown below. Based on $e_{\max} = 8\%$, the ramp's design speed of 40 M.P.H. and a rounded down radius of 1030', the Superelevation for the start of the ramp is 5.8%.

MINIMUM RADII FOR DESIGN SUPERELEVATION DESIGN SPEEDS, AND $e_{\max} = 8\%$															
e%	DESIGN SPEED (MPH)														
	30			35			40			45			50		
	RADIUS	* 1	* 2	RADIUS	* 1	* 2	RADIUS	* 1	* 2	RADIUS	* 1	* 2	RADIUS	* 1	* 2
NC	3,240	0	0	4,260	0	0	5,410	0	0	6,710	0	0	8,150	0	0
RC	2,370	36	55	3,120	39	58	3,970	41	62	4,930	44	67	5,990	48	72
2.2	2,130	40	60	2,800	43	64	3,570	46	68	4,440	49	73	5,400	53	79
2.4	1,930	44	65	2,540	46	70	3,240	50	74	4,030	53	80	4,910	58	86
2.6	1,760	47	71	2,320	50	75	2,960	54	81	3,690	58	87	4,490	62	94
2.8	1,610	51	76	2,130	54	81	2,720	58	87	3,390	62	93	4,130	67	101
3.0	1,480	55	82	1,960	58	87	2,510	62	93	3,130	67	100	3,820	72	108
3.2	1,370	58	87	1,820	62	93	2,330	66	99	2,900	71	107	3,550	77	115
3.4	1,270	62	93	1,690	66	99	2,170	70	106	2,700	76	113	3,300	82	122
3.6	1,180	65	98	1,570	70	105	2,020	74	112	2,520	80	120	3,090	86	130
3.8	1,100	69	104	1,470	74	110	1,890	79	118	2,360	84	127	2,890	91	137
4.0	1,030	73	109	1,370	77	116	1,770	83	124	2,220	89	133	2,720	96	144
4.2	955	76	115	1,280	81	122	1,660	87	130	2,080	93	140	2,560	101	151
4.4	893	80	120	1,200	85	128	1,560	91	137	1,960	98	147	2,410	106	158
4.6	834	84	125	1,130	89	134	1,470	95	143	1,850	102	153	2,280	110	166
4.8	779	87	131	1,060	93	139	1,390	99	149	1,750	107	160	2,160	115	173
5.0	727	91	136	991	97	145	1,310	103	155	1,650	111	167	2,040	120	180
5.2	676	95	142	929	101	151	1,230	108	161	1,560	116	173	1,930	125	187
5.4	627	98	147	870	105	157	1,160	112	168	1,480	120	180	1,830	130	194
5.6	582	102	153	813	108	163	1,090	116	174	1,390	124	187	1,740	134	202
5.8	542	105	158	761	112	168	1,030	120	180	1,320	129	193	1,650	139	209
6.0	506	109	164	711	116	174	965	124	186	1,250	133	200	1,560	144	216
6.2	472	113	169	669	120	180	909	128	192	1,180	138	207	1,480	149	223
6.4	442	116	175	628	124	186	857	132	198	1,110	142	213	1,400	154	230


- 1) Open **Osage\J5P0555\Plan_Overview_J5P0555.dgn**
 - a) Review project scope.
- 2) Open **Plan_J5P0555.dgn** File.
 - a) Attach **Civil_Geometry_J5P0555.dgn**
 - b) Review plan geometry.

Create template for Route 50 Corridor

- 3) Create template for Route 50 Corridor
 - a) **Corridor Tab → Template Tools → Create Template**
 - b) Open the **MoDOT Template Library (MoDOT.itl)**


The path to the MoDOT itl is as follows: Documents\CADD_Standards\ORD Standards\Connect_Config\WorkSpaces\MoDOT\Standards\Template Library\

- c) Save the **MoDOT.itl** to the Project's data folder naming it **J5P0555.itl**
- d) Create a folder under the root directory named **J5P0555**.
- e) Under the J5P0555 folder create a **Route 50** folder.
- f) Copy the following template into the **Route 50** folder:
 - **Templates → Concrete Pavement w/ Shoulders → A2 Shoulders Agg Base → Concrete Pavement 4 Lane Divided w/ Agg Base Option 3**
- g) Use the **Delete Components** option and remove the **right outside** Shoulder & Sublayers, Guardrail Widening, and End Conditions. Do not delete Aggregate Base (See picture below).
- h) Delete three outside Aggregate Base points (See arrows below)



Note: The next few steps will add an **auxiliary lane** on the right side of the template. The auxiliary lane is being added to provide the User a way to transition over a distance the **Pavement Normal Slope** of (2%) to the slope at the beginning of **Ramp 2 (3.87%)**.

- 4) In the **Dynamic Settings**, verify the **Apply Affixes**, are set with X & Y Steps = **0.1**
- 5) Add the following components to the right side of the template:
 - a) Components → Pavement – New → Concrete Pavement w/ Shoulders → A2
Shoulders Agg Base → Concrete Pavement 1 Lane w/ Agg Base Option 3
 - b) End Conditions → Combined → 6:1 Fill or 6:1 Foreslope and Backslope Ditch




- 6) Optional Step: Merge the common components.
- 7) Edit the **RT_Conc_T_EOP1** point.
 - a) Toggle off the Horizontal Feature Constraint
- 8) Edit the **RT_Conc_T_EOP2** point.
 - a) Toggle off the Superelevation Flag
 - b) For the Slope Constraint Label enter in **Auxiliary_Lane_Pavement_Slope**
 - c) Set the Horizontal Feature Constraint from the drop-down menu, select **Linear** → **Design** → **Roadway** → **EOP_New**
 - d) Set Horizontal Constraint distance to 0.001'
- 9) Edit the **RT_AsphSurf_T_O_EOS1** point.
 - a) Set the Horizontal Feature Constraint from the drop-down menu, select **Linear** → **Design** → **Roadway** → **EOS_New_Asphalt**

10) Close, and Save the **J5P0555.itl**

Create Route 50 Corridor

- 11) Create **Corridors_J5P0555.dgn** using the **MoDOT_Roadway_Seed_2D.dgn** as the seed file.
- a) Set the **Geographic Coordinate System** from the **Existing_Terrain_J5P0555.dgn**
 - b) Reference in the following dgn files:
 - Existing_Terrain_J5P0555.dgn**
 - Plan_J5P0555.dgn**
 - Civil_Geometry_J5P0555.dgn**
 - c) Set **Annotation Scale** to **50**
 - d) Activate Existing Ground Terrain.
 - e) Select the “**Corridor Tab → Create Section → New Corridor**” tool.
 - f) Select the **Route50** baseline (use the active profile) and name the corridor “**Route50**”
 - g) Apply Roadway template
 - **J5P0555 → Route 50 → Concrete Pavement 4 Lane Divided w/ Agg Base Option 3**
 - From Station **445+30.94 R1** to Sta. **460+00 R1**
 - Drop Interval of **5ft.**
 - Note if the drop interval is too large the corridor might not see the Corridor Reference Elements.
 - h) Select the “**F6**” key to open 3D view of model.
- 12) Make the **Default 2D** view the active view in the **Corridors_J5P0555.dgn**.
- a) Turn off the display of the Corridors 3D file using the reference dialog.
- 13) In the **Route 50 Corridor** add the four individual **EOP_New** lines from the **Plan_J5P0555.dgn** file as **Corridor References**.



- 14) Add the following two Key Stations to the Route 50 Corridor
- 451+40.67 R1** (Just past beginning of Ramp 2)
 - 453+55.67 R1** (Just before location of Shoulder Gore nose)


Notes:

- If a template drop does not cross an individual corridor reference element, the Corridor will not draw to that corridor reference element.
- Use the **Corridor Object Tool** to verify the Key Stations were placed at the correct location.
- You can also use the **undo/redo** buttons to help see the changes to your model.

- 15) The shoulder width in the Ramp area is going to be narrower than the mainline. In the Route 50 Corridor add the Complex **EOS_New_Asphalt** line from the **Plan_J5P0555.dgn** file as Corridor References.

Notes:

- The shoulder is going to vary in width in certain areas of the project. The plan shoulder element (**EOS_New_Asphalt**) will control the width in these areas




- 16) Add the following Key Station to the Route 50 Corridor.
- 453+88.86 R1** (Just before location of Median Grass Gore nose)

Notes:

- If a template drop does not cross an individual corridor reference element, the Corridor will not draw to that corridor reference element.
- Use the **Corridor Object Tool** to verify the Key Station was placed at the correct location.
- You can also use the **undo/redo** buttons to help see the changes to your model.

Calculation of Ramp 2 Vertical Complex Element (Profile)

- 17) Create **Superelevation_J5P0555.dgn** using the **MoDOT_Roadway_Seed_2D.dgn** as the seed file.
- Set the **Geographic Coordinate System** from the **Existing_Terrain_J5P0555.dgn**
 - Reference in **Civil_Geometry_J5P0555.dgn**
 - Set **Annotation Scale** to **50**
 - Review the undivided non-spiraled Superelevation runoff diagram below.



- 18) Select **Create Superelevation Section.**

Feature Definition:	Superelevation
Feature Name:	Ramp 2 Superelevation
Section Name:	Ramp2
Alignment:	Ramp2
Start Station:	Lock to Start
Stop Station:	Lock to End
Minimum Transition Length:	1000
Lane Creation Method:	Manual

Create Superelevation ...	
Parameters	
Name	Ramp 2
Lock To Start	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Start Station	0+00.00
Lock To End	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> End Station	16+55.31
Minimum Tangent Length	1000.0000
Lane Creation Method	Manual
Feature	
Feature Definition	Superelevation
Name	Ramp 2 Superelevation

Note: If two Superelevation Sections are created, delete second Superelevation Section, and then extend the First section to the end of the Ramp 2 alignment.

19) Select **Create Superelevation Lanes** and create the following two Superelevation Lanes.

Lane Name:	0-6FT
Type:	Primary
Side of Centerline:	Left
Inside Edge Offset:	0'
Width:	6'
Normal Cross Slope:	2.00%

Cre... — □ ×

Parameters ^

Name	0-6FT
Type	Primary
Side Of Centerline	Left
Inside Edge Offset	0.0000
Width	6.0000
Normal Cross Slope	2.00%

Lane Name:	6-18FT
Type:	Primary
Side of Centerline:	Left
Inside Edge Offset:	6'
Width:	12'
Normal Cross Slope:	2.00%

Cre... — □ ×

Parameters ^

Name	6-18FT
Type	Primary
Side Of Centerline	Left
Inside Edge Offset	6.0000
Width	12.0000
Normal Cross Slope	2.00%

20) Select **Calculate Superelevation**.


Rules File Name:	MoDOT_Superelevation_Rules_File.xml
e Selection:	8%
L Selection:	MoDOT – AASHTO 2018 Eq. 3-23 and Table 3-16a
Design Speed:	40 mph
Pivot Method:	Right Edge
Open Editor	Yes

Calculate Superelevation — □ ×

Parameters ^

Rules File Name	pw:\modot-pw.bentley.com.modot-pw-04\Documents\CADD_Standards\ORD Stand...
e Selection	8%
L Selection	MoDOT - AASHTO 2018 Eq. 3-23 and Table 3-16a
Design Speed	40
Pivot Method	Right Edge

Below is a view of the Superelevation Editor for **Ramp 2**.



21) Delete the 6-18ft Lane.

22) Verify your result by running a **Superelevation Calculation Report** and comparing with the results listed below:

Superelevation Calculation Report

Report Created: Tuesday, May 7, 2024
Time: 2:37:04 PM

File Name:
Input Grid Factor:

Note: All units in this report are in feet unless specified otherwise.

Section Name: Ramp 2-1
Base Horizontal Name: RAMP2
Standards Filename: c:\temp\dms00171\MoDOT_Superelevation_Rules_File.xml
Design Speed: 40
Pivot Method: Right Edge
E Selection: 8%
L Selection: MoDOT - AASHTO 2018 Eq. 3-23 and Table 3-16a
Calculation Units: US survey foot
Start Station: 0+00.00 R1 **End Station:** 16+55.31 R1

Format Options [X]

Mode	Precision	Format
Northing/Easting/Elevation:	0.123	
Angular:	Degrees	ddd.ddd
Slope:	0.12	50%
Use Alternate Slope if Slope Exceeds:	0.00%	
Alternate Slope:	0.12	50%
Linear:	0.12	
Station:	0.12	SS+SS.SS
Acres/Hectares:	0.123	
Area Units:	0.123	
Cubic Units:	0.123	<input type="checkbox"/> Convert to Cubic Yard
Direction:	Bearings	ddd.ddd
Face:	Right Face	
Vertical Observation:	Zenith	

Delimeter: +

Lane Set: 1
Left Offset: -18.00
Right Offset: 0.00
Curve Set: 1 **Outside Lane:** 6-18FT

Global Variables:

NRotatedLanes	1.50
PivotType	4 (Right Edge)
WidthLane	12.00
InitialCrossSlope	-0.02
UseSpiralLength	true
PercentOnTangent	0.67
LengthsAreTotalTransition	false
UseRunoutLength	false
Radius	1059.74
Speed	40.00

Maximum cross slope calculations

Max E Value: 5.80%
Result from: From Non-interpolated Table 8%

Transition length calculations

Transition Length: 150.00
Result from: MoDOT - AASHTO 2018 Eq. 3-23 and Table 3-16a
Equation: TransitionLength


Variables:	Name	Value	Equation
	NominalLaneWidth	12.00	12
	NRotatedLanes	1.50	
	MaxE	0.06	
	bw	0.83	(NRotatedLanes+1)/(2*NRotatedLanes)
	Speed	40.00	
	gradient	0.58	
	TransitionLength	150.00	100*(NominalLaneWidth*NRotatedLanes)*MaxE*bw/gradient

- 23) Next calculate the transition distance of the Mainline Pavement in the transition area before the **PC location** of the **Ramp2 Curve**.

$$x = (150) (2\%) / (5.8\%) = 52'$$

$$\text{Distance from C-C section to PC} = L - (L/3) - x = (150') - (150'/3) - 52' = 48'$$

Note: This is the distance the Auxiliary Lane will have to transition from 2% (Mainline Slope) to a 3.87% (**Ramp 2 Slope**) at the **PC location** of the Ramp.



Open the **Corridors_J5P0555.dgn**.

- 24) For the next step select the **Corridor Views** → **Open Cross Section Model** and verify the **Route 50 Mainline Ramp Pavement** is transitioning downward. Use the **Place Temporary Dimension Line** to verify the slopes of the mainline pavement.
- 25) Apply the following **Parametric Constraint**.
- Route50** station value at start location of Ramp2 = Sta. 451+40.67
 - Transition Start Station = Sta. 451+40.67 - 48' = **Sta. 450+92.67**

Create Parametric Co... — □ ×

Parameters

Lock To Start ☐

☐ Start 450+92.67

Lock To End ☐

☐ Stop 451+40.67

Constraint Label Auxiliary Lane Pavement Slope ▾

Start Value -2.00%

Stop Value -3.87%

Start: 450+92.67 R1
 Stop: 451+40.67 R1
 Constraint Label: Auxiliary_Lane_Pavement_Slope
 Start Value: -2.00%
 Stop Value: -3.87%

Create templates for Ramp 2 Corridor

26) Create template for Ramp2 Corridor

- a) In the Corridor Modeling Tab select the **Create Template** icon
- b) Open the **J5P0555.itl**
- c) Navigate to the **J5P0555** and **Create** a new folder called **Ramp 2**
- d) Right click on **Ramp 2** folder and select **New > Template**
- e) Name the Template **Ramp 2**
- f) In the **Dynamic Settings** dialog, verify the **Apply Affixes (LT_ , RT_)**, with X & Y Steps = **0.1**
- g) Use the following Components and End Conditions to create the **Ramp2** Template:

Template Components:**Left Side**

Concrete Pavement 1 Lane w/ Agg Base Option 3

Right Side


A2 Shoulder Asphalt Option 3 w/ Agg Base

Template End Conditions:**Left Side**

Fill Slope (6:1)

Right Side

6:1 Fill or 6:1 Forslope and Backslope Ditch

***Notes**

- a) **Concrete Pavement 1 Lane w/ Agg Base Option 3** is located in the following location:
Components\Pavement - New\Concrete Pavement w/ Shoulders\A2 Shoulders Agg Base\
- b) **A2 Shoulder Asphalt Option 3 w/ Agg Base** is located in the following location:
Components\Shoulders\Asphalt Adjacent to Concrete Pavt w/o Curb\
- c) **6:1 Fill or 6:1 Forslope and Backslope Ditch** is located in the following location:
End Conditions\Combined\
- d) Adjust pavement slope to be 2% going up from baseline.
- e) If not already done so, adjust the shoulders to follow the pavement slope using a Vector Offset constraint.
- f) Check Priorities on End Conditions using the “**TEST**” button.


Next, we will need to create another **Ramp2** template for the area where the ramp and mainline butt up to each other.

27) Copy and paste the “**Ramp2**” Template located in the **Ramp2** folder.

28) Name new template “**Ramp2 - No LT Shoulder**”.

29) Use the Delete Components option and remove the **left outside** Shoulder & Sub layers, and End Conditions. Do not delete Aggregate Base (See picture below).

30) Delete two Aggregate Base points (See arrows below)



31) Close and save.

Create Ramp 2 Profile


- 32) Open the **J5P0555_Superelevation.dgn** file and review superelevation sections.
- Verify slope at PC location is **3.87%**
 - Verify slope at Max Super is **5.80%**
- 33) Open the **J5P0555_Civil_Geometry.dgn** file.
- Within the Default 2D View reference in the **Corridors_J5P0555.dgn** file.
- 34) Open the **Profile Model** for the **Ramp2** Alignment.
- 35) From the **Route50** edge of pavement, project the superelevation slope down to the Ramp2 baseline. Select the **Geometry Tab → Vertical Geometry Section → Element Profiles Tools → Profile by Variable Slope from Element**.

Profile At Slope To Element

Parameters	
Slope Style	Linear
Slope Relative To Target	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Start Slope	-3.87%
<input checked="" type="checkbox"/> End Slope	-5.80%
<input type="checkbox"/> Vertical Offset	0.0000
Range	
Lock To Start	<input type="checkbox"/>
<input checked="" type="checkbox"/> Start Distance	6+10.01
Lock To End	<input type="checkbox"/>
<input checked="" type="checkbox"/> End Distance	6+81.97
Feature	
Feature Definition	Use Active Feature
Name	RTE 50 EOP Projected Slope

Feature Definition:	Geometry Scratch
Name:	RTE 50 EOP Projected Slope
Slope Relative to Target:	Check
Slope Style:	Linear
Plan Element:	Ramp2 Baseline
Reference Element:	EOP_New line between Ramp and Mainline
Start <u>Distance</u> :	6+10.01 (Ramp2 Sta. 0+00.00)
Start Value:	-3.87%
Stop <u>Distance</u> :	6+81.97 (Ramp2 D-D Section)
Stop Value:	-5.80%
Vertical Offset:	0.00'

Note: The profile created in the previous step should look like the profile below. Because the Reference Element (Mainline EOP) had 90-degree edge near the beginning of Ramp2, a kink is produced in the resulting profile. The 90-degree edge was created because the EOP_New plan line is being targeted with Corridor Reference.



- 36) To create a profile without a kink, remove the **EOP_New** Corridor Reference nearest the PC of the Curve.
 - a) Open the **Corridors_J5P0555.dgn** file
 - b) From the Corridor heads up tools, select “**Remove Corridor Reference**”
- 37) Open the **J5P0555_Civil_Geometry.dgn** file.
- 38) Open the **Profile Model** for the **Ramp2** corridor.
- 39) Delete first projected profile.

- 40) From the **Route50** Edge of **Pavement**, project the superelevation slope down to the Ramp2 baseline. Select the **Geometry Tab** → **Vertical Geometry Section** → **Element Profiles Tools** → **Profile by Variable Slope from Element**.

Profile At Slope To Element

Parameters

Slope Style: Linear

Slope Relative To Target: ☒

☒ Start Slope: -3.87%

☒ End Slope: -5.80%

☐ Vertical Offset: 0.0000

Range

Lock To Start: ☐

☐ Start Distance: 6+12.74

Lock To End: ☐

☒ End Distance: 6+72.71

Feature

Feature Definition: Use Active Feature

Name: RTE 50 EOP Projected Slope

Feature Definition:	Geometry Scratch
Name:	RTE 50 EOP Projected Slope
Slope Relative to Target:	Check
Slope Style:	Linear
Plan Element:	Ramp2 Baseline
Reference Element:	EOP_New line between Ramp and Mainline
Start <u>Distance</u> :	6+12.74 (Ramp2 Sta. 0+00.00)
Start Value:	-3.87%
Stop <u>Distance</u> :	6+72.71 (Ramp2 D-D Section)
Stop Value:	-5.80%
Vertical Offset:	0.00'

Note: If you add EOP_New Corridor Reference back in the kink will show back up. The profile is dynamically linked to the EOP profile.

- 41) Open the **Route50** Profile model and verify the profile grade at **Sta. 451+40.61** is **4.00%**

- 42) Reopen the **Ramp2** Profile model.

- 43) Using the **Profile Line Between Points** tool, located under the **Geometry Tab** → **Vertical Geometry Section** → **Line Tools**, place a **4%** slope before the Projected Ramp2 profile.

Profile Line Between Points

Parameters

☐ Length: 0.0000

☐ Slope: 4.00%

Feature

Feature Definition: Use Active Feature


Name: Match RTE 50 Profile Slope

Feature Definition:	EOP_New
Name:	Match RTE 50 Profile Slope
Slope:	4%

- 44) Once again project the superelevation slope down to the Ramp2 baseline, but this time from the **Route50 Edge of Shoulder**.

Select the **Geometry Tab → Vertical Geometry Section → Element Profiles Tools → Profile by Variable Slope from Element**.

Project down from the midpoint of the shoulder line to right edge (See below).




To understand how **Start** and **Stop** distances of this step relates to the station limits and plan geometry, review the notes in the **Plan_J5P0555.dgn** file.

Profile At Slope To Element	
Parameters	
Slope Style	Linear
Slope Relative To Target	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Start Slope	-5.80%
<input checked="" type="checkbox"/> End Slope	-5.80%
<input type="checkbox"/> Vertical Offset	0.0000
Range	
Lock To Start	<input type="checkbox"/>
<input checked="" type="checkbox"/> Start Distance	8+49.4593'
Lock To End	<input type="checkbox"/>
<input checked="" type="checkbox"/> End Distance	8+66.1476'
Feature	
Feature Definition	Use Active Feature
Name	RTE 50 EOS Projected Slope

Feature Definition:	Geometry Scratch
Name:	RTE 50 EOS Projected Slope
Slope Relative to Target:	Check
Slope Style:	Linear
Plan Element:	Ramp2 Baseline
Reference Element:	EOS_ New line between Ramp and Mainline
Start <u>Distance</u> :	8+49.46 (Ramp2 Sta. 2+28.79)
Start Value:	-5.80%
Stop <u>Distance</u> :	8+66.1476 (Ramp2 Sta. 2+45.18)
Stop Value:	-5.80%
Vertical Offset:	0.00'

- 45) Within the Feature Definition Toggle Bar set the Feature Definition to MoDOT_Baseline_Proposed. Also, toggle on “Use Active Feature Definition”.



- 46) Using the **Parabola from Element** tool, located under the **Geometry Tab → Vertical Geometry Section → Curve Tools → Profile Curve from Element** Sub-Tools, place a vertical curve from the start of the Projected profile to the end.
- a) After starting the tool, the “**Locate Element**” will be the **4% Profile Line**.
 - b) After placing the start point at the beginning of the Projected Profile, define the endpoint of the vertical curve by Accu-Snapping to the right endpoint of the second Projected Profile.
 - c) When asked to Trim, select the “**None**” option.

Note: You can use Civil AccuDraw to help start the profile at **Sta. 0+00.00**

- 47) The last VPI for the **Ramp2** profile will be where the ramp chain **crosses the Big Horn crossroad gutter line**. This point is **offset 18.5'** from the crossroad centerline. The elevation of the crossroad at this point and corresponding ramp station have already been determined below. Based on this, **the last VPI at the end of the profile should use the following VPI station and elevation.**

<u>Station</u>	<u>Elevation</u>
16+36.81	763.92

Using the **Tangent Profile Line to Element** tool, located under the **Geometry Tab → Vertical Geometry Section → Lines Tools → Profile Line to Element** Sub-Tools, select the previously placed profile line, and using AccuDraw and its “Z” Mode place the endpoint at **Sta. 16+36.81** at an **Elevation of 763.92**. When asked to **Trim**, select the “**Back**” option.

- 48) Delete both the **4% Profile** line located before the **PC Point** and the two **Projected Profiles**.
- 49) Join the two profile elements using the Vertical Geometry **Profile Complex By Elements**, naming the profile **Ramp 2 Proposed** (If the tool does not let you Complex the profile elements make sure you delete all the elements in the previous step).
- 50) Set the **Ramp2 Proposed** profile as **active**.

51) Run the **Vertical Alignment Report** on the **Ramp 2 Proposed** profile.

Vertical Alignment Review Report

Report Created: Sunday, December 3, 2023
Time: 11:26:19 PM

Project: Default
Description:
File Name: c:\temp\dms35432\Civil_Geometry_J5P0555.dgn
Last Revised: 12/3/2023 23:25:14

Note: All units in this report are in feet unless specified otherwise.

Horizontal Alignment: RAMP2
Horizontal Description:
Horizontal Style: Alignment\MoDOT_Baseline_Proposed

Vertical Alignment: Ramp 2 Proposed
Vertical Description:
Vertical Style: Alignment\MoDOT_Baseline_Proposed

	Station	Elevation
Element: Symmetrical Parabola		
VPC	0+00.00 R1	728.845
VPI	3+70.59 R1	743.669
VPT	7+41.18 R1	749.596
Length:	741.18	
Entrance Grade:	4.00%	
Exit Grade:	1.60%	
$r = 100 * (g2 - g1) / L$:	-0.32	
$K = L / (g2 - g1)$:	308.74	
Middle Ordinate:	-2.22	
 Element: Linear		
VPT	7+41.18 R1	749.596
END	16+36.81 R1	763.920
Tangent Grade:	1.60%	
Tangent Length:	895.63	

52) Open the **Corridors_J5P0555.dgn** file.

53) Reapply the **EOP_New** element located just before the beginning of **Ramp 2** as a **Corridor Reference** for the **Route50** corridor.

Create Ramp2 Corridor

- 54) Create a new corridor by selecting **Corridors** Tab → **New Corridor**.
- 55) Select the **Ramp2** baseline and name the corridor “**Ramp2**”.
- 56) Apply Roadway template.
- a) **J5P0555\Ramp2\Ramp2 - No LT Shoulder**
 - b) From Station **0+00.00 R1** to **Sta. 2+45.18 R1**
 - c) Drop Interval of **1ft**.
- 57) Apply Roadway template.
- a) **J5P0555\Ramp2\Ramp2**
 - b) From Station **2+45.19 R1** to **Sta. 15+00 R1**
 - c) Drop Interval of **10ft**.
- 58) From the **Route 50 Corridor** clip out the **Ramp2 Corridor**.
- 59) If needed select the “**F6**” key to open 3D view of model.
- 60) Within the Default 2D View, reference in the **J5P0555_Superelevation.dgn** file.
- a) Assign Superelevation to the **Ramp2** Corridor.
 - b) The slope of the pavement before the shoulder nose will be controlled by the **Route 50 Edge of Pavement** using a **Point Control**.
 - c) The slope of the pavement after the **shoulder nose** will be controlled by the **Superelevation shape**. Therefore, adjust the **Priority** of the Superelevation Point Control to be **greater than 1**.
 - d) In the Reference Dialog turn off the Display of the Superelevation.dgn.

Associate Superelevation

	Superelevation Lane	Superelevation Point	Pivot Point	Start Station	Stop Station	Priority
	0-6FT	LT_Conc_T_EOP	Conc_T_CL	0+00.00	16+55.31	2

OK Cancel

61) To make the **Ramp2** pavement draw up to the **EOP** of the **mainline** set the following Point Control:

Create Point Control

Parameters

Lock To Start ☒

☒ Start 0+00.00

Lock To End ☐

☒ Stop 2+12.42

Control Description Draw to Mainline EOP

Point LT_Conc_T_EOP

Mode Both

Control Type Corridor Feature

Corridor ROUTE50

Reference Feature RT_Conc_T_EOP2

Priority 1

Start Station:	0+00
Stop Station:	2+12.42 (just shy of the shoulder nose)
Description:	Draw to Mainline EOP
Point:	LT_Conc_T_EOP
Mode:	Both
Control Type:	Corridor Feature
Corridor:	Route50
Reference Feature:	RT_Conc_T_EOP2
Priority:	1
Horz. & Vert. Offset:	0

62) To make the **Ramp2** pavement draw up to the **EOS** of the mainline (in the area of the shoulder median), set the following Point Control:

Create Point Control

Parameters

Lock To Start ☐

☒ Start 2+12.44

Lock To End ☐

☒ Stop 2+45.18

Control Description Draw to Mainline EOS

Point LT_Conc_T_EOP

Mode Both

Control Type Corridor Feature

Corridor ROUTE50

Reference Feature RT_AsphSurf_T_O_EOS1

Priority 1


Start Station:	2+12.44
Stop Station:	2+45.18
Description:	Draw to Mainline EOS
Point:	LT_Conc_T_EOP
Mode:	Both
Control Type:	Corridor Feature
Corridor:	Route50
Reference Feature:	RT_AsphSurf_T_O_EOS1
Priority:	1
Horz. & Vert. Offset:	0

- 63) You will notice that after the point Controls were applied that the Ramp Pavement at the start of the alignment now does not draw correctly. To fix this will apply a **Key Station**.




The first two Template Drops for Ramp 2 are both solving for the Route 50 EOP. The first Template Drop is solving for the widened Axillary Lane EOP, and the Second Template Drop is solving for the normal Route 50 EOP.

To fix this we will introduce a **Key Station** just after the Start of the Ramp 2 start location at **Station 0+00.01** and adjust the **Template Drop Start Station** to **0+00.004**.



- 64) To make the Ramp 2 pavement model correctly, the **Route 50** shoulder indicated by the red arrow needs to be removed.

Because there is shoulder width in the area indicated by the red arrow, the **pavement of Ramp 2** is not allowed to draw to the **Route 50 Edge of Shoulder** near the Shoulder Median Nose.



- 65) In the **Route 50** Template modify the **RT_AsphSurf_T_O_EOS1** point and **rename** the **Horizontal Constraint Label** from **Shldr_Asph_A2_Width** to **RT_Outside_Shldr_Asph_A2_Width**.

Notes:


- In the next step we will use a Parametric Constraint to set the Route 50 Shoulder Width to zero in the area above.
- The benefit to using a Parametric Constraint is because it's a lower level of control than the Feature Constraint. Therefore, the User should define a general station range to apply the Parametric Constraint around the shoulder gore area and let the Plan Element of the Feature Constraint exactly define the limits of the shoulder gore nose.
- See next page for Template Point Hierarchy of Control.

- 66) Apply the following **Parametric Constraint** to the **Route 50 Corridor** to set the Shoulder Width to zero around the Shoulder Nose.

Start:	453+40.00 R1 +/-
Stop:	453+70.00 R1 +/-
Constraint Label:	RT_Outside_Shldr_Asph_A2_Width
Start Value:	0.00
Stop Value:	0.00

Template Point - Hierarchy of Control

- Point Control - **Highest**
- Feature Constraint
- Parametric Constraint
- Point Constraint - **Lowest**



Point Properties

Name: Conc_T_O_EOS

☐ Use Feature Name Override: Conc_T_O_EOS

Feature Definition: XS_Conc 0 EOS

☐ Superelevation Flag

Alternate Surface: Proposed Finished Grade


Member of:
A2 Shoulder Concrete

Constraints

Constraint 1		Constraint 2	
Type:	Vector-Offset	Type:	Horizontal
Parent 1:	Curb_Surf_Edge	Parent 1:	Conc_T_EOP
Parent 2:	Conc_T_EOP	Parent 2:	
Value:	0.0000	Value:	-2.5000
Label:		Label:	-Shldr_Conc_A2_Width
<input checked="" type="checkbox"/> Horizontal Feature Constraint: EOS_New_Concrete			
Range:		-50.0000	


67) Add the **EOP_New** line that transitions from an **18'** offset to a **20'** offset as corridor references in the **Ramp2 Corridor**. The EOP line is near the grass gore point (see **Blue Arrow** below).

- Next, you will need to change the **LT_Conc_T_EOP** point's **Horizontal Feature Constraint** in **both** the **Ramp 2** Template Drops from Linear → Design → Roadway → **DNC** to Linear → Design → Roadway → **EOP_New**



68) Edit the J5P0555\Ramp2\Ramp2 template and modify the **Horizontal Constraint** for the **LT_Conc_T_EOP** point to a width of 18'.

69) To help with the situation below, within the **Ramp 2** Corridor, **Target Alias** the Route 50 Corridor. Also **add the terrain** as the secondary target.



Create Special Ditch - Drawing the Ditch Foreslope to a Alignment and Profile

70) In the **Civil_Geometry_J5P0555.dgn** create following Ditch Alignment and Profile.

- a) Use the Horizontal Geometry Tool **Complex By PI** to place a line with a **Feature Definition** of Linear → Design → Drainage → **Special_Ditch_Right** at the following locations:

- Note: use **Civil AccuDraw** to place line accurately along the **Route50** and **Ramp 2** Alignment.
- Use a radius of **200'**
- Name the ditch alignment: **Special Ditch**

Station	Offset	Chain
445+30.94	120	Route50
448+70.00	120	Route50
449+50.00	150	Route50
1+00	90	Ramp2
5+00	70	Ramp2
10+00	100	Ramp2

- b) Open the **Special Ditch Profile View**. Use the Vertical **Profile Line Between Points** Tool to place a profile with the following VPIs:

- Note: use **Civil AccuDraw** to place profile accurately along the **Special Ditch** Alignment.
- Name this profile: **Special Ditch Proposed**
- Make the profile **Activate**

Station	Elevation
0+00	688.00
15+75.75	704.00

71) In the next few steps, we are going to apply a Point Control that will control how the **Ditch Foreslope Bottom** point (RT_Dtch_Frslp_1_B) behaves. Currently within the Ramp2 Corridor, all the right End Conditions are only solving for a Fill Slope.

Note: For the **RT_Dtch_Frslp_1_B** to be controlled with a Point Control the Right Ditch End Condition must be solving somewhere in the corridor.

In other words, with a Point Control, to select and control the **RT_Dtch_Frslp_1_B** point, a right cut/ditch must be drawing somewhere in the corridor. If a ditch is not drawing, the ditch foreslope point will not be listed as an available point to control in the **Point Control** dialog.

Open the **Corridors_J5P0555.dgn** and within the **first Ramp 2 Corridor Template Drop** change the **Ditch Foreslope Slope** constraint to a **-50%** slope.

- 72) In the **Corridors_J5P0555.dgn** file create the following Point Controls to have the ditch bottom foreslope point draw the special ditch.


Route 50 Corridor:

Start Station:	Beginning of Alignment
Stop Station:	451+40.67 R1 (Start of Ramp 2)
Control Description:	Draw to Special Ditch Alignment and Profile
Point:	RT_Dtch_Frslp_1_B
Mode:	Both
Control Type:	Linear Geometry
Plan Element:	Special Ditch
Profile Element:	Special Ditch Proposed
Use as Secondary Alignment:	Yes
Priority:	1
Horz. & Vert. Offset:	0

Ramp 2 Corridor:

Start Station:	Beginning of Alignment
Stop Station:	15+00 R1
Control Description:	Draw to Special Ditch Alignment and Profile
Point:	RT_Dtch_Frslp_1_B
Mode:	Both
Control Type:	Linear Geometry
Plan Element:	Special Ditch
Profile Element:	Special Ditch Proposed
Use as Secondary Alignment:	Yes
Priority:	1
Horz. & Vert. Offset:	0

- 73) Open the **Route 50 Dynamic Cross Section** Model View. Place **Temporary Dimension Lines** along the Ditch Foreslope. You should notice that the slope is changing from section to section because the Bottom Ditch Foreslope point must hit the Special Ditch Alignment and Profile. In the next few steps, the parameters will change such that the slope remains constant, and the ditch will follow the ditch elevation.



Notes: When placing a **Temporary Dimension Line** and you're having troubles selecting a location on the template, you might try the following:

- Delete the Dynamic XS View, by **Right Clicking** and **Holding** in the Cross Section view, select **View Controls** → **Delete Dynamic XS View**.
- If you used the "**Locate Station via Datapoint**" option, make sure the Dynamic Cross Section you're viewing is on a template drop location and not in between two drops.


Create Special Ditch - Drawing to a Ditch Profile while holding Constant the Ditch Foreslope

Point Controls work by replacing the constraint that most closely matches the point control. **Example:** If a point has a **Horizontal** and **Slope** Constraint, a **Vertical** Control will replace the **Slope** Constraint, but if the point has a **Vertical** Constraint and a **Slope** Constraint, the **Vertical** Control would replace the **Vertical** Constraint. If the constraints are the same (**Slope-Slope** for instance), the **Second** constraint will be replaced.


Tips and Tricks for Roadway Designer - Bentley 2009 Roads and Bridges

74) To draw to Ditch profile some points in the Ditch Component need to be redefined in **all three template drops** on the **south** side of the project.

- a) Edit the **RT_Dtch_Frslp_1_B** point.
 - Adjust the slope to **-25.00%**
 - Change the **Horizontal Constraint** to a **Vertical Constraint**.
- b) Edit the **RT_Dtch_Bkslp_1_T** point.
 - Adjust the slope to **25.00%**



75) In the **Route 50** and **Ramp 2** Corridors, edit the Special Ditch Point Controls by changing the **Point Control Mode** from **Both** to **Vertical**.



Note: There is one section off the **Route 50 Corridor** that does not solve for a Ditch after applying the adjusted Point Controls. To make that section solve as a ditch, the User could move the **Special Ditch Profile** down one foot at the start the profile.

Note: Point Control Recommendations from **Kevin McDonald** at Bentley

- I advise all Users not to use point controls on the last point of an end condition. End conditions need the freedom to seek their targets successfully, and typically, extending the end condition out to meet the target is typically last, even after point controls are applied.
- Instead of using point controls on the last point of end conditions, a higher priority end condition can be created that seeks the linear geometry. So, for example, in the station range from **138+97.04** to **139+78.05** right, we should not use point controls on the points “Fill_Slope_1_B_R” and “Fill_Slope_2_B_R”, we should instead create **Priority 1** End Conditions that seek the **Linear Geometry** elements (or add an end condition exception that does it). If they find their target, they will construct a point along the linear, if they fail, they will move to the next priority end condition that will seek the Terrain.
- The question sometimes gets raised... “Why does it work sometimes?” As in this case, it seems to work OK on some stations, but it is now failing. The answer I give is because there are lot of factors that affect the order end conditions and point controls are processed, so it can work sometimes, but not dependably. Using **End Conditions** to seek targets is the dependable method.

In Summary:

It's good practice to never to use a **Point Control** on the last point of an **End Condition**. The main reason is that the end condition needs the freedom on the last point to successfully find its target. Point controls can possibly move the last point such that it doesn't find the target which can cause the entire end condition to fail. (There are cases where it will work out OK, but it is just safer never to do it.)

If you have some geometry that will **fully control** the last point of an **end condition**, just seek that geometry with an End Condition. For example, if I have a geometry representing the **Horizontal** and **Vertical** location of where I want a slope to tie, I can model it with an end condition that seeks the **horizontal**, then attach another end condition that seeks the **vertical**. If you mark the first point as **Do Not Construct**, it will draw the slope from the start point to the tie point.

Kevin McDonald
Bentley Systems, Inc.

OpenRoads Designer Road 2

Rock Excavation



Table of Contents

19.1 Things you might learn new in this Chapter:	3
19.2 Determine Boring Locations.....	4
19.2.1 Create Route 179 Corridor.....	4
19.2.2 Creating Superelvation.....	5
19.3 Create Preliminary Cross Sections Sheets:	10
19.3.1 Creating the Named Boundary.....	10
19.4 Soil Survey Report has just arrived:	16
19.5 Creating the Rock Surface from Borehole Data	19
19.5.1 Plotting the Borehole Locations:	19
19.5.2 Creating the Rock Terrains	27
19.5.3 Extending the Rock Terrain Surface:.....	30
19.5.4 Creating a Terrain for the Extend Rock:.....	38
19.5.5 Creating the Rock Final Terrain:	40
19.6 Creating the Benching Template:	44
19.6.1 Interesting Notes about End Conditions, Benching, Parent/Child Relationships:.....	56
19.6.2 Template Display Rules.....	57
19.6.3 Point - Feature Name Override.....	66
19.6.4 Component - Feature Name Override.....	68
19.7 Verify Cross Sections are drawing at Critical Locations.....	72
19.8 Creating Rock Meshes to be used in Earthwork Calculations.....	73
19.9 Create Cut and Fill Volumes:	74
19.10 Create Cross Sections Sheets with Earthwork Quantities:	78
19.11 Creating the Named Boundary.....	79
19.12 End Area Volume Reporting:	82
19.12.1 Changing the Format Options of the Report:.....	83

19.1 Things you might learn new in this Chapter:

- Class C Excavation
- Requesting Soil Borings
- Superelevation Lanes
- Importing Rock Borings
- Extending a Rock Surface
- Reading a Soil Survey
- What is Slope of Repose?
- Template Creation
 - Tracing Rock and Ground Surfaces
 - Point “Value Equations”
 - Display Rules
 - AND, OR, and NOT conditions
 - Parent Components
 - Benching Components
 - Automatic Point Merging involving Multiple Points.
 - End Condition Branching off other End Conditions
 - End Condition Priorities vs Display Rules
 - Feature Name Override (Point and Component)
- Modifying Corridor Feature Definitions
- Creating Complex Terrain Models
- Apply Terrain Elevations to COGO Points using the Modify Points tool
- Cross Section Navigator

19.2 Determine Boring Locations

- 1) Open the **Cole\J5U0441G\Project_Summary_J5U0441G.dgn**.
 - a) **Review** the project limits.
- 2) Open the **Cole\J5U0441G\Typical_Sheet_Scale-10_J5U0441G.dgn**.
 - b) **Review** the Preliminary Typical Section.

19.2.1 Create Route 179 Corridor

- 3) **Open** the Project Template Library **J5U0441G.itl** using the **Create Template** tool located within the **OpenRoads Modeling Workflow → Corridors Tab → Create Section**
 - a) **Review** the **4 Lane Asphalt w/ Type C Barrier** template in the **J5U0441G** folder.
 - b) **Close** Template Library.
- 4) Create a new file named **Corridors_Preliminary_J5U0441G.dgn**
 - a) Use the **MoDOT_Roadway_Seed_2D.dgn** as the seed file.
 - b) Set the **Geographic Coordinate System** from the **Terrain_Existing_Ground_J5U0441G.dgn**
 - c) Reference in the following dgn files:
 - **Terrain_Existing_Ground_J5U0441G.dgn**
 - **Civil_Geometry_J5U0441G.dgn**
 - d) Set **Annotation Scale** to **50**
 - e) Activate Existing Ground Terrain.
- 5) Select the “**Corridor Tab → Create Section → New Corridor**” tool.
 - a) Use a Corridor Feature of **1-Final x 1**
 - b) Select the **Route 179** baseline (use the active profile) and name the corridor **Rte179**.
 - c) Apply the following Roadway template:
J5U0441G → 4 Lane Asphalt w/ Type C Barrier
 - d) Apply Stationing from **62+00 R1 to Sta. 142+00 R1**
 - e) Use a Drop Interval of **100ft**.
- 6) Select the “**F6**” key to open **3D** view of model.

19.2.2 Creating Superelevation


- 7) Create a new file named **Superelevation_J5U0441G.dgn** using the **MoDOT_Roadway_Seed_2D.dgn** as the seed file.
 - a) Set the **Geographic Coordinate System** from the **Terrain_Existing_Ground_J5U0441G.dgn**
 - b) Reference in the following dgn files:
 - **Civil_Geometry_J5U0441G.dgn**
- 8) Set **Annotation Scale** to **50**
- 9) Select **Create Superelevation Section.**

Name:	179
Locate Corridor or Alignment:	Select CL Alignment
Start Station:	Lock To Start
End Station:	Lock To End
Minimum Transition Length:	10,000
Lane Creation Method:	Manual
Feature Definition:	Superelevation
Feature Name:	SE 179

Parameters	
Name	179
Lock To Start	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Start Station	15+66.65
Lock To End	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> End Station	276+27.34
Minimum Tangent Length	10000.0000
Lane Creation Method	Manual
Feature	
Feature Definition	Superelevation
Name	SE 179

Note: If more than one Superelevation Section is created, delete the extra Superelevation Section(s), and then extend the First section to the end of the Route 179 alignment.

- 10) Review the Typical Section below, remember with Superelevation the Designer must account for the concept of **Number of Lanes Rotated**. Our **MoDOT Superelevation Settings** file considers a **Half a Lane Rotated** as being a Lane Width from 0-6ft, and a **Full Lane Rotated** is being a Lane Width greater than 6ft up to 12ft. With our Typical Section below we have **2-1/2 Lanes Rotated** (6ft Lane) + (12ft Lane) + (12ft Lane).



TYPICAL SECTION ROUTE 179

- 11) Select **Create Superelevation Lanes** and create the following two Superelevation Lanes.

Lane Name:	0-6FT
Type:	Primary
Side of Centerline:	Left
Inside Edge Offset:	0'
Width:	6'
Normal Cross Slope:	-2.00%

Create S...

Parameters

Name	0-6FT
Type	Primary
Side Of Centerline	Left
Inside Edge Offset	0.0000
Width	6.0000
Normal Cross Slope	-2.00%


Lane Name:	0-6FT
Type:	Primary
Side of Centerline:	Right
Inside Edge Offset:	0'
Width:	6'
Normal Cross Slope:	-2.00%

Create S...

Parameters

Name	0-6FT
Side Of Centerline	Right
Inside Edge Offset	0.0000
Width	6.0000
Normal Cross Slope	-2.00%

Lane Name:	6-18FT
Type:	Primary
Side of Centerline:	Right
Inside Edge Offset:	6'
Width:	12'
Normal Cross Slope:	-2.00%



Create S... — □ ×

Parameters ▲

Name 6-18FT


Side Of Centerline Right ▼

Inside Edge Offset 6.0000

Width 12.0000

Normal Cross Slope -2.00%

Lane Name:	6-18FT
Type:	Primary
Side of Centerline:	Left
Inside Edge Offset:	6'
Width:	12'
Normal Cross Slope:	-2.00%



Create S... — □ ×

Parameters ▲

Name 6-18FT


Side Of Centerline Left ▼

Inside Edge Offset 6.0000

Width 12.0000

Normal Cross Slope -2.00%

Lane Name:	18-30FT
Type:	Primary
Side of Centerline:	Left
Inside Edge Offset:	18'
Width:	12'
Normal Cross Slope:	-2.00%



Create S... — □ ×

Parameters ▲

Name 18-30FT


Side Of Centerline Left ▼

Inside Edge Offset 18.0000

Width 12.0000

Normal Cross Slope -2.00%

Lane Name:	18-30FT
Type:	Primary
Side of Centerline:	Right
Inside Edge Offset:	18'
Width:	12'
Normal Cross Slope:	-2.00%



Create S... — □ ×

Parameters ▲

Name 18-30FT

Side Of Centerline Right ▼


Inside Edge Offset 18.0000

Width 12.0000

Normal Cross Slope -2.00%

12) Select **Calculate Superelevation** and use setting below:

Rules File Name:	MoDOT_Superelevation_Rules_File.xml
e Selection:	8%
L Selection:	MoDOT – AASHTO 2018 Eq. 3-23 and Table 3-16a
Design Speed:	60 mph
Pivot Method:	Crown
Open Editor	Yes



13) Review within the **Editor**, that the Superelevation values are same for all the **Left Lanes**, and that all the Superelevation values are same for all the **Right Lanes**.


14) Run a Superelevation Report and verify the **Number of Lanes Rotated** is equal to **2.5**

Use the **Superelevation Calculations.xsl** report.

Transition length calculations			
Transition Length:		218.400	
Result from:		MoDOT - AASHTO 2018 Eq. 3-23 and Table 3-16a	
Equation:		TransitionLength	
Variables:			
	Name	Value	Equation
	NominalLaneWidth	12.000	12
	NRotatedLanes	2.500	
	MaxE	0.052	
	bw	0.700	(NRotatedLanes+1)/(2*NRotatedLanes)
	Speed	60.000	
	gradient	0.500	
	TransitionLength	218.400	100*(NominalLaneWidth*NRotatedLanes)*MaxE*bw/gradient

- 15) Because our Route 179 Template has **two** Pavement components (32ft wide each), we only need two Superelevation Lanes, one on the **Left** side of CL and one on the **Right** side of CL.

Delete **two** of the **three** lanes from each side of the Centerline.



- 16) Reopen the **Corridors_Preliminary_J5U0441G.dgn**

- 17) Attach and then Apply the Superelevation to the **Route 179 Corridor**.

Note: Depending on which **Superelevation Lanes** you delete in a previous step, the Superelevation Lane name listed could vary from **User** to **User**.

Associate Superelevation							
	Superelevation Lane	Superelevation Point	Pivot Point	Start Station	Stop Station	Priority	
▶	Left Lane	LTO_AsphSurf_T_EOP	AsphSurf_T_CL	15+66.65	276+27.34	1	▲
	Right Lane	RTO_AsphSurf_T_EOP	AsphSurf_T_CL	15+66.65	276+27.34	1	▼

OK Cancel

- 18) Open the **Cross Section Model** and verify Superelevation is applied to the **Route 179 Corridor**.

- 19) Within **View 1, Default** turn-off the **Display** of the **Superelevation_J5U0441G.dgn** file.


19.3 Create Preliminary Cross Sections Sheets:

- 20) Create a new file named **Named_Boundary_179_Preliminary_XS_J5U0441G.dgn**
 - a. Use the **MoDOT_Roadway_Seed_2D.dgn** seed file.
 - b. Set the **Geographic Coordinate System** using the settings in the following file:
Terrain_Existing_Ground_J5U0441G.dgn
 - c. Reference in the following dgn files:
Civil_Geometry_J5U0441G.dgn
Corridors_Preliminary_J5U0441G.dgn
Terrain_Existing_Ground_J5U0441G.dgn
 - d) Set **Annotation Scale** to **50**
 - e) **Activate** Existing Ground Terrain.


19.3.1 Creating the Named Boundary

- 21) **IMPORTANT:** Enable both the **2D** and a **3D** view by selecting the **F6** key (or the tool will create the Named Boundaries and **NOT** the sheet and drawing models. The sheets may be created at a different time using the Named Boundaries Manager)
- 22) In this next step we are going to be placing Named Boundary's to indicate where we want to cut cross sections. We are going to show you two ways to open the Named Boundary Tool.


The first way to access the Named Boundary tool is to select the **OpenRoads Modeling Workflow** → **Drawing Production** tab → **Named Boundary** tool.



This method unfortunately does not set up the **Named Boundary** Attributes.




The second way to open the **Named Boundary** tool is to **Right-Click** in a blank area in the Default 2D window (typically **View #1, Default**)




The benefit of using the right click option is that ORD will automatically set up the Attributes for the **Named Boundary**.


Before



After



23) After the Place Named Boundary dialog opens, select the **Civil Cross Section** icon



a) Set the following Dialog Settings:

b) Once the dialog has been filled out then Accept/Reject to either place the named boundary or end the tool.

Place Named Boundary Civil Cross Section > Accept/Reject. Data point in Plan View to place boundary

- 24) When you **Accept** the dialog input with the **Show Dialog** checked on there will be another dialog that opens (see below).

Change the Annotation Group to the **XS Annotation - No Grid** option.

Create Drawing

Mode: **Cross Section**

☐ One Sheet Per Dgn:

View Name: RTE179 - 62+00.00

Drawing Seed: XS Sheet - 20 Scale

View Type: Civil Cross Section

Discipline: Civil

Purpose: Section View

Drawing Model

Model Name: RTE179 - 62+00.00

Seed Model: MoDOT D Size - Cross Section Sheet - 20'

Filename: (Active File)

Scale: 1"=20'

Annotation Group: XS Annotation - No Grid

Sheet Model

☒ Create Sheet Model

Model Name: RTE179 - 62+00.00

Seed Model: MoDOT D Size - Cross Section Sheet - 20'

Filename: (Active File)

Sheets: (New)

Full Size 1 = 1

Drawing Boundary: D Size XS Sheet - 20 Scale

Detail Scale: 1"=20' (By Named Boundary)

☐ Add To Sheet Index

☐ Make Sheet Coincident


☒ Open Model

OK **Cancel**

In the next few steps, we are going to use the **Cross Section Navigator** tool to review the cross sections to identify the flat bottom ditch location. Typically, borings are done at the back of ditch location.

25) Open the **Multi-Model Views**, and then also open View 8

26) Select the **Drawing Production** Tab → **Review Section** → **Cross Section Navigator**.



27) Below is a list where boring should be requested:

Station	Left 72 feet	CL	Right 72 feet
62+00	Yes	Yes	Yes
63+00	Yes	Yes	Yes
64+00	Yes	Yes	Yes
65+00	Yes	Yes	Yes
66+00	Yes	Yes	Yes
67+00	Yes	Yes	Yes
68+00	Yes	Yes	Yes
69+00	Yes	Yes	No
70+00	Yes	Yes	No
71+00	Yes	Yes	No
72+00	Yes	Yes	No
73+00	Yes	Yes	No
74+00	No	No	No
75+00	No	No	No
76+00	No	No	No
77+00	No	No	No
78+00	No	No	No
79+00	No	No	No
80+00	No	No	No
81+00	No	No	No
82+00	No	No	No
83+00	No	No	No
84+00	No	No	No
85+00	No	No	No
86+00	No	No	No
87+00	Yes	Yes	Yes
88+00	Yes	Yes	Yes
89+00	Yes	Yes	Yes
90+00	Yes	Yes	Yes
91+00	Yes	Yes	Yes
92+00	No	Yes	Yes
93+00	No	Yes	Yes
94+00	Yes	Yes	Yes
95+00	Yes	Yes	Yes
96+00	Yes	Yes	Yes
97+00	Yes	Yes	Yes
98+00	Yes	Yes	Yes
99+00	No	Yes	Yes
100+00	No	No	No
101+00	No	No	No
102+00	No	No	No

Station	Left 72 feet	CL	Right 72 feet
103+00	No	Yes	Yes
104+00	Yes	Yes	Yes
105+00	Yes	Yes	Yes
106+00	Yes	Yes	Yes
107+00	Yes	Yes	Yes
108+00	Yes	Yes	Yes
109+00	No	Yes	Yes
110+00	No	No	No
111+00	No	No	No
112+00	No	No	No
113+00	No	No	No
114+00	No	No	No
115+00	No	No	No
116+00	No	No	No
117+00	Yes	Yes	No
118+00	Yes	Yes	No
119+00	Yes	Yes	Yes
120+00	Yes	Yes	Yes
121+00	Yes	Yes	Yes
122+00	No	Yes	Yes
123+00	No	Yes	Yes
124+00	No	No	No
125+00	Yes	Yes	Yes
126+00	Yes	Yes	Yes
127+00	Yes	Yes	Yes
128+00	Yes	Yes	Yes
129+00	Yes	Yes	Yes
130+00	No	Yes	Yes
131+00	No	Yes	Yes
132+00	No	Yes	Yes
133+00	No	No	No
134+00	No	No	No
135+00	No	No	No
136+00	No	No	No
137+00	No	No	No
138+00	No	No	No
139+00	No	No	No
140+00	No	No	No
141+00	Yes	Yes	Yes
142+00	Yes	Yes	Yes

19.4 Soil Survey Report has just arrived:

Inter-Office Correspondence

MISSOURI HIGHWAY AND TRANSPORTATION DEPARTMENT

DATE: September 5, 1996

TO: W. L. Trimm, Division
Engineer Materials Division

FROM: Edward Martin, R. G.
District Soils & Geology Technologist

SUBJECT: District Five - Materials
Soil Survey
Route 179, Job No.: J5U0441
Cole County

The soil survey for the above job has been completed. This 4.751 mile length of new road extends from Missouri Boulevard, station 25+42.651, to Route B, station 276+27.400, partially within the city limits of Jefferson City.

The proposed improvement is currently planned to be constructed in four, separate sections and consists of the following:

A. Four 12-foot lanes of PCC pavement with 10-foot PCCP shoulders and 12-foot PCCP median with barrier from Missouri Boulevard to Edgewood Road extension.

B. Two 12-foot lanes of PCC pavement with 10-foot PCCP shoulders from Edgewood Road extension to Route B. Right of Way will be purchased to add future lanes and a median on these sections.

C. A modified single point interchange at Edgewood Road extension; a diamond interchange at Route C; and a folded diamond interchange at Highway 54. The interchanges at Edgewood Road extension and Route C are currently planned for future construction.

D. Structures at Edgewood Road extension (future); Frog Hollow Road; Route C (future); Idlewood Road; Route 54; and Idlewood Road/outer roadway connection over 54.

E. An outer roadway, south of Highway 54, connecting Idlewood Road, Southwood Hills Road, Jack Stocker Road, and Route 179.

This soil survey was prepared in accordance with the strip map furnished February 21, 1996.

Logs of subsurface information are attached. Also attached are soil survey summary sheets with descriptions and typical properties of the various soils and horizons encountered.

28) The District Geologist indicated the Rock line would be below the “**Weathered Dolomite**” layer.

MISSOURI HIGHWAY AND TRANSPORTATION DEPARTMENT Division of Materials SUBSURFACE LOGS FOR SOIL SURVEY		
		Sheet <u>8</u> of <u>61</u>
County <u>Cole</u>	Route <u>179</u>	Job No. <u>J5U0441</u>
Logged by <u>E. Martin</u>	Date Work Performed <u>March - June, 1996</u>	
LOCATION	LOG OF MATERIALS	CLASSIFIED BY
64+00 C/L	0-2.07ft Light brown, fat clay with chert gravel and cobbles. 2.07-8.73ft Weathered, reddish brown shale with dolomite stringers. 8.73- 12.51ft Weathered dolomite. 12.51-13.22ft Moderately hard dolomite. 13.22ft Refusal on hard dolomite.	Versa Drill & 3in augers
64+00 72ft Lt . C/L	0-5.31ft Light brown fat clay with chert cobbles and gravel. 5.31-8.92ft Weathered red/brown, clay shale. 8.92-12.20ft Reddish brown shale with chert nodules. 12.20- 15.59ft Weathered dolomite. 15.59-16.66ft Moderately hard, cherty dolomite. 16.66-16.71ft Hard dolomite, 16.71ft Refusal.	Versa Drill & 3in augers
64+00 72ft Rt. C/L	0-2.62ft Light brown, fat clay with chert and sandstone cobbles and gravel. 2.62-4.92ft Light brown, shaly clay with scattered chert gravel. 4.92- 8.57ft Weathered dolomite. 8.57-9.96ft Hard dolomite. 9.96ft Refusal.	Versa Drill & 3in augers
65+00 C/L	0-1.80ft Chert cobbles, boulders and lean clay. 1.80-4.17ft Brown, fat clay with scattered chert gravel. 4.17- 10.41ft Weathered dolomite. 10.41-10.45ft Hard dolomite. 10.45ft Refusal.	Versa Drill & 3in augers
65+00 72ft Lt . C/L	0-6.63ft Chert and sandstone cobbles, gravel and brown, lean clay. 6.63-10.86ft Gray and brown, weathered clay shale. 10.86- 18.17ft Weathered dolomite with clay and shale seams. 18.17-20.21ft Moderately hard to hard dolomite. 20.21ft Refusal on hard dolomite.	Versa Drill & 3in augers
65+00 72ft Rt . C/L	0-1.48ft Brown, lean to fat clay. 1.48- 7.95ft Weathered dolomite. 7.95-8.41ft Moderately hard to hard dolomite. 8.41ft Refusal on hard dolomite.	

- 29) A summary of the Soil's Report Depth of Cover (doc) to the Rock Line is listed in the following chart:

Station	72' Left (feet)	C/L (feet)	72' Right (feet)
62+00	17.31	7.26	8.31
63+00	15.45	9.88	8.44
64+00	15.59	12.51	8.57
65+00	18.17	10.41	7.95
66+00	20.74	8.31	7.32
67+00	9.46	6.21	3.98
68+00	7.87	4.11	2.99
69+00	6.28	2.01	No Core
70+00	4.39	3.65	No Core
71+00	2.5	5.29	No Core
72+00	3.52	3.49	No Core
73+00	3.01	2.645	No Core
Break in Borings	Break in Borings	Break in Borings	Break in Borings
Station ??+?? ?? == Bridge Exception == Station ??+?? ??			
Break in Borings	Break in Borings	Break in Borings	Break in Borings
87+00	9.29	8.11	7.26
88+00	7.42	7.62	8.44
89+00	5.55	7.13	9.62
90+00	6.54	4.63	4.24
91+00	4.27	4.26	3.95
92+00	No Core	3.88	3.65
93+00	No Core	2.95	4.26
94+00	7.66	2.01	4.86
95+00	8.21	9.52	9.69
96+00	7.11	7.87	6.9
97+00	6.01	6.21	4.11
98+00	6.56	4.41	6.05
99+00	No Core	7.8	7.32
Break in Borings	Break in Borings	Break in Borings	Break in Borings
103+00	No Core	11.2	8.6
104+00	7.21	8.74	6.95
105+00	12.41	6.28	5.29
106+00	8.19	4.96	5.74
107+00	3.98	3.65	6.19
108+00	7.65	6.83	6.64
109+00	No Core	7.62	4.32
Break in Borings	Break in Borings	Break in Borings	Break in Borings
117+00	6.6	7.08	No Core
118+00	4.63	5.75	No Core
119+00	4.77	5.44	7.01
120+00	4.9	5.13	6.6
121+00	2.01	5.16	5.19
122+00	No Core	3.58	5
123+00	No Core	0	4.8
Break in Borings	Break in Borings	Break in Borings	Break in Borings
125+00	6.57	3.01	4.03
126+00	7.88	9.23	9.95
127+00	6.77	8.28	8.24
128+00	5.65	7.32	6.54
129+00	4.95	5.88	5.55
130+00	No Core	4.44	4.57
131+00	No Core	7.26	6.54
132+00	No Core	5.85	5.75
Break in Borings	Break in Borings	Break in Borings	Break in Borings
141+00	9.56	6.6	7.26
142+00	11.92	7.18	6.88

19.5 Creating the Rock Surface from Borehole Data


19.5.1 Plotting the Borehole Locations:

In the next few pages, we are going to take the information from the soil report and plot the locations of the Boreholes.

30) Create a new file named **Borehole_Locations_J5U0441G.dgn**

- a. Use the **MoDOT_Roadway_Seed_2D.dgn** seed file.
- b. Set the **Geographic Coordinate System** using the settings found in the **Terrain_Existing_Ground_J5U044G.dgn**
- c. Reference in the following dgn files:
 Civil_Geometry_J5U0441G.dgn
 Terrain_Existing_Ground_J5U0441G.dgn
- d) Set **Annotation Scale** to **50**
- e) **Activate** Existing Ground Terrain.

31) Next, we need to plot the locations of the Rock Boreholes in the dgn file. We will do this by processing a **CSV** file of the locations of the Rock Borings. The CSV file will be in the formation of **Point Name, Station, Offset**.




Note: We extended the **Beginning** and **Ending** Station by **0.30 ft** of each section of Boreholes so that when we cut Cross Sections, we don't place a section right on


the edge of a Surface/Mesh. For example, Beginning Station **62+00** was entered in as **61+99.70** and Ending Station **73+00** was entered as **73+00.30**

Below is an **example** of a Cross Section cut right on the edge of a **Rock Surface/Mesh Element**.

Note: The **Rock Mesh Element** below was created by taking the **Rock Surface** that we will create shortly and adding a **depth** to that surface. We will be doing all of this later in the exercise along with the Rock Benching you see in the Cross Section.



If you cut a section, just inside the **Rock Mesh Element** (0.01ft), you will see you will get the entire Mesh Element.



32) Select the **Geometry Tab** → **General Tools Section** → **Import/Export** → **Import Horizontal Points from Ascii File**

- a) Select the **Route 179** Alignment
- b) Select the **Borehole Locations Station-Offset.csv**

Note: At this point the **Import Horizontal Points from ASCII** File dialog will open.

- c) Select the 3rd icon over from the Left → **Create New Text Import Settings File**
 - Select the **Columns** Tab
 - In the **Options** section Select **Delimited Separators**
 - In the **Column Delimiters** section, Check **Comma**
 - In the bottom section, set the column heads as follows
 - Column1 → Name
 - Column 2 → Station
 - Column 3 → Offset

Create Text Import Settings File

Columns
Basic Mode - Define columns in imported file.

File Format
Columns
Filters

Options
☒ Delimited Separators
☐ Fixed Widths

Column Delimiters
☐ Tab
☒ Comma
☐ Space
☐ Other:
☐ Semicolon
☒ Ignore Consecutive Delimiters

Column Options
 Text Qualifier:
 Start Column for Line:
 Start Column for Field:

Name	Station	Offset
62+00/Left	6199.99	-72
62+00/CL	6199.99	0


Cancel < Back Next > Finish

- d) Select **Finish** and save the **Text Import Wizard Settings File** as:

Borehole Locations Station-Offset_**TIW.xml**

Note: **TIW** = **T**ext **I**mport **W**izard


- e) Set the Feature Definition to **COGO** Points, which can be found in the following location:
Point → Design → Drafting Standards → Miscellaneous → **COGO Point**



- f) Select **Import**


Next, we are going to assign the **Existing Ground Elevation** to the COGO points place in the previous step.

- 33) First place the **COGO** points into a **Selection Set** using the **Element Selection Tool**, and the **Color Tab** in the **Extended Settings**:



- 34) Set the Elevation by using the **Modify Points Tool** by selecting the **OpenRoads Modeling Workflow** → **Geometry Tab** → **Horizontal Section** → **Point Tools**

Mode:	Named Terrain Model / Mesh
Elevation Offset:	0.0000
Rotation Mode:	No Change



- 35) Once again put the **COGO Points** into a selection set using the Element Selection Tool. You should only get **130 points**, if you get **260 points** turn off the **Default-3D** view within the Reference Dialog.
- 36) Verify the COGO Points have elevations by using the **Point Feature Station Offset Elevation Report** by selecting the **OpenRoads Modeling Workflow → Geometry Tab → General Tools Section → Report Tools**

Station Offset Elevation Feature Report					
Report Created: Friday, November 8, 2024 Time: 12:13:32 PM					
Project: Default					
Description:					
Baseline (Active) Alignment: RTE179					
File Name: c:\temp\pwise_local_development_vollek.sa\d0335933\Borehole_Locations_J5U0441G.dgn					
Last Revised: 11/8/2024 10:56:06					
Input Grid Factor:			Note: All units in this report are in feet unless specified otherwise.		
Point	Description	Station	Offset	Elevation	Feature
62+00/Right		6199.980 R1	72.000	742.154	Point\Design\Drafting Standards\Miscellaneous\COGO Point
62+00/CL		6199.980 R1	-0.000	748.459	Point\Design\Drafting Standards\Miscellaneous\COGO Point
62+00/Left		6199.980 R1	-72.000	749.655	Point\Design\Drafting Standards\Miscellaneous\COGO Point
63+00/Left		6300.000 R1	-72.000	745.355	Point\Design\Drafting Standards\Miscellaneous\COGO Point
63+00/Right		6300.000 R1	72.000	735.392	Point\Design\Drafting Standards\Miscellaneous\COGO Point

Note: The **Horizontal Point Report** will also show the **elevations** of the COGO points. Also, with Reports you can **Right-Click** on the report and get some **Export** Options.


Geometry Point Report					
Report Created: Friday, November 8, 2024 Time: 12:15:29 PM					
Project: Default					
Description:					
Baseline (Active) Alignment:					
File Name: c:\temp\pwise_local_development_vollek.sa\d0335933\Borehole_Locations_J5U0441G.dgn					
Last Revised: 11/8/2024 12:13:34					
Input Grid Factor:			Note: All units in this report are in feet unless specified otherwise.		
Point	Feature	Description	Northing	Easting	Elevation
103+00/CL	Point\Design\Drafting Standards\Miscellaneous\COGO Point		992711.210	1718554.410	661.923
103+00/Right	Point\Design\Drafting Standards\Miscellaneous\COGO Point		992712.737	1718482.426	668.457
104+00/CL	Point\Design\Drafting Standards\Miscellaneous\COGO Point		992611.213	1718552.289	673.347
104+00/Left	Point\Design\Drafting Standards\Miscellaneous\COGO Point		992609.685	1718624.273	661.267
104+00/Right	Point\Design\Drafting Standards\Miscellaneous\COGO Point		992612.740	1718480.305	684.803
105+00/CL	Point\Design\Drafting Standards\Miscellaneous\COGO Point		992511.235	1718550.168	679.779

In the next few pages, we are going to add in additional the information from the **Soil Report** and create a Rock Surface.

37) Create a new file named **Terrain_Rock_Boreholes_J5U0441G.dgn**

- a. Use the **MoDOT_Roadway_Seed_3D.dgn** seed file.
- b. Set the **Geographic Coordinate System** using the settings in the following file:
Terrain_Existing_Ground_J5U0441G.dgn
- c. Reference in the following dgn files:
Civil_Geometry_J5U0441G.dgn
- d. Set **Annotation Scale** to **50**

38) Next, we need to plot the **Top of Rock** locations of the Boreholes in the dgn file. We will do this by processing a CSV file of the locations of the Rock Borings. The CSV file will be in the format of **Point Name, Station, Offset, Rock Elevation**.




```
File Edit Format View Help
62+00/Left, 6199.70, -72, 732.159,
62+00/CL, 6199.70, 0, 741.015,
62+00/Right, 6199.70, 72, 733.858,
63+00/Left, 6300.00, -72, 729.905,
63+00/CL, 6300.00, 0, 732.011,
63+00/Right, 6300.00, 72, 726.952,
64+00/Left, 6400.00, -72, 718.947,
64+00/CL, 6400.00, 0, 719.936,
64+00/Right, 6400.00, 72, 716.875,
65+00/Left, 6500.00, -72, 702.623,
65+00/CL, 6500.00, 0, 710.194,
65+00/Right, 6500.00, 72, 705.446,
66+00/Left, 6600.00, -72, 684.794,
66+00/CL, 6600.00, 0, 698.215,
66+00/Right, 6600.00, 72, 690.662,
67+00/Left, 6700.00, -72, 685.932,
67+00/CL, 6700.00, 0, 687.005,
67+00/Right, 6700.00, 72, 680.166,
68+00/Left, 6800.30, -72, 683.734,
68+00/CL, 6800.30, 0, 681.885,
68+00/Right, 6800.30, 72, 673.981,
Ln 1, Col 1 100% Windows (CRLF) UTF-8
```

39) Select the **Geometry Tab** → **General Tools Section** → **Import/Export** → **Import Horizontal Points from Ascii File**

- a) Select the **Route 179** Alignment
- b) Select the **Borehole Location Station-Offset-Elevation.csv**

Note: At this point the Import Horizontal Points from ASCII File dialog will open.

- c) Select the **3rd icon** over from the **Left** → **Create New Text Import Settings File**
 - Select the **Column** Tab
 - In the **Options** section Select **Delimited Separators**
 - In the **Column Delimiters** section Check **Comma**
 - In the bottom section set the column heads as follows
 - Column1 → Name
 - Column 2 → Station
 - Column 3 → Offset
 - Column 4 → Elevation




- d) Select **Finish** and save the **Text Import Wizard Settings File** as:

Borehole_Locations_with_Top-of-Rock_Elevations_J5U0441G_TIW.xml

Note: **TIW** = **T**ext **I**mport **W**izard

- e) Set the Feature Definition to **COGO** Points, which can be found in the following location:

Point → Design → Drafting Standards → Miscellaneous



- f) Select **Import**

40) In the **View 1**, Turn off the Display(s) of the **Civil_Geometry_J5U0441G.dgn**


19.5.2 Creating the Rock Terrains

- 41) Next, we are going to create **Rock Terrain Models** from the **3D COGO** points placed in the previous step.

One by one, place each group of **COGO** points into a **Selection Set**, using the **Element Selection Tool**, by placing a selection fence around each group of points.

42) Select the **From Elements** tool located within the **Terrain Tab** → **Create Section**

Feature Type:	Spot
Edge Method:	Max Triangle Length
Max Side Length:	150ft (XS Spacing x 1.5)
Feature Definition:	Existing Rock Surface
Name:	Rock Boreholes-1



Note: When adjusting the Name, be sure to Enter or Tab in the name field, otherwise the tool will apply the Default name.

43) After creating the first Rock Terrain, **repeat** steps until **all six** groups of Rock shots have been processed and their terrains created.

Next, we are going to delete all the **COGO Points**. The reason we are going to do this is to stop the **COGO Points** from automatically showing up in our **Corridor** and **XS Models**.


44) Before we can delete the **COGO Points**, we need to first **drop** the **rules** in the six (6) newly created Rock Terrains. This has to be done individually one at a time.

Note: If you don't drop the rules first before deleting the **COGO Points**, the terrain in some instances will not hold its current shape.


45) **Detach** all Reference Files.

46) Next, place the **COGO** points into a **Selection Set** using the **Element Selection Tool**, and the **Color Tab** in the **Extended Settings**.

47) Select **Delete**.



- 48) **Verify** the naming of each Rock Surface either by hovering over each Terrain or using Explorer → Open Roads Model → Terrain Models → Existing Rock Surface



- 49) In this step we are going to reopen the **Corridors_Preliminary_J5U0441G.dgn** file and reference in the **Terrain_Rock_Boreholes_J5U0441G.dgn** to see how the Rock Surface is laying out compared to the Corridor Template.


Open the **Corridors_Preliminary_J5U0441G.dgn**

Within the **View 1, Default** reference in **Terrain_Rock_Boreholes_J5U0441G.dgn**


- 50) Open the **Dynamic Cross Sections** and review the **Rock Layer** at the **Major 100' Stations** locations.

19.5.3 Extending the Rock Terrain Surface:

The rock terrain that we have created extends from **Centerline of Route 179** out to the **Back of Ditch** location. For the Rock Benching to draw in your cross sections we will need to **extend the rock past the benching**. We can do this by utilizing the **Extend Rock Template** in the MoDOT section of the Template library.





Note: The diagram below displays how the **Extended Rock Template** works.



51) **Open** the Project Template Library **J5U0441G.itl** using the **Create Template** tool located within the **OpenRoads Modeling Workflow** → **Corridors Tab** → **Create Section**

- Copy** the **Extend Rock** template from the **Components** → **Benching** folder and place it in the **J5U0441G** folder.
- Review** the **Extend Rock** template along with the documentation on the following two pages.

Note: The **Extend Rock** template is described below (only Left Side Showing).



The **Value Equation** is located here in the **Point Properties** dialog box.

Point Properties

Name:

☐ Use Feature Name Override:

Feature Definition:

☐ Superelevation Flag

Alternate Surface:

Member of:

Constraints

	Constraint 1	Constraint 2
Type:	<input type="text" value="Horizontal"/>	<input type="text" value="Vertical"/>
Parent 1:	<input type="text" value="LT_Seek Outside Edge o"/> <input type="button" value="Apply"/>	<input type="text" value="LT_Extend_Rock_1"/> <input type="button" value="Apply"/>
Value:	<input type="text" value="-60.0000"/> <input type="button" value="="/>	<input type="text" value="=\${(LT_Seek_Ground_1)}-\${(LT_Extend_Rock_1)}"/> <input type="button" value="="/>
Label:	<input type="text" value="-Section Width"/>	<input type="text"/>
<input type="checkbox"/> Horizontal Feature Constraint	<input type="text" value="Linear\Design\DNC\DNC"/>	
Range:	<input type="text" value="0.0000"/>	

Value Equation uses two points to calculate the value. You have two options with Value Equation, **Horizontal** or **Vertical Difference**.

Value Equation

Multiplier:

$$=${(LT_Seek_Ground_1)}-${(LT_Seek_Ground_2)}*-1.000$$

In the **Extend Rock Template** the Value equation helps us find the Vertical Elevation Difference of the two **Seek Ground Points**. Once that is determined the template applies that difference to the outside **Rock point**.

52) Close Template Library.


In the next few steps, we are going to place a shape around each Rock Surface. The shapes will define the edge of the Rock Surfaces and will have a Feature Definition of **Geometry Scratch**. The **Extend Rock** template will utilize this shape when extending the Rock Surface. We will place these shapes in the **plan file**.

53) Create a new file named **Plan_J5U0441G.dgn**

- a. Use the **MoDOT_Roadway_Seed_2D.dgn** seed file.
- b. Set the **Geographic Coordinate System** using the settings in the following file:
Terrain_Existing_Ground_J5U0441G.dgn
- c. Reference in the following dgn files:
Terrain_Rock_Boreholes_J5U441G.dgn


54) Merge into Master the **Terrain_Rock_Boreholes_J5U441G.dgn** file.55) Next, we are going to create the **Shapes** around each Rock Surface. To do this use the **Create Region** Tool located within: **OpenRoads Modeling Workflow** → **Drawing Tab** → **Groups Section**

Use the following settings below:




Note: When creating the shape, it might look like the **Create Region** tool is not enclosing the entire shape, but what is really happening is the Terrain Element, in certain areas, is visualizing on top of the shape element.

- 56) Using the **Element Section** tool select and **delete all** items that have an **Element Color** of **78**.



- 57) Set the Feature Definition of the shapes to **Geometry Scratch** using the **Set Feature Definition** Tool located within the **OpenRoads Modeling** Workflow → **Geometry** Tab → **General Tools** Section → **Standards Tools**.



- 58) Create a new file named **Corridors_Extend_Rock_J5U0441G.dgn**
- Use the **MoDOT_Roadway_Seed_2D.dgn** seed file.
 - Set the **Geographic Coordinate System** using the settings in the following file:
Terrain_Existing_Ground_J5U0441G.dgn
 - Reference in the following dgn files:
Civil_Geometry_J5U0441G.dgn
Plan_J5U441G.dgn
Terrain_Existing_Ground_J5U0441G.dgn
Terrain_Rock_Boreholes_J5U441G.dgn
 - Set **Annotation Scale** to **50**
 - Activate **Existing Ground** Terrain.

59) Select the “**Corridor Tab → Create Section → New Corridor**” tool.

a) Select the **Route 179** baseline (use the active profile) and name the corridor **Rte179**.

b) Apply the following Roadway template:


J5U0441G → Extend Rock

c) Create other Template Drops using the stationing ranges listed below:


- Sta. 61+99.80 to Sta. 73+00.20
- Sta. 86+99.80 to Sta. 99+00.20
- Sta. 102+99.80 to Sta. 109+00.20
- Sta. 116+99.80 to Sta. 123+00.20
- Sta. 124+99.80 to Sta. 132+00.20
- Sta. 140+99.80 to Sta. 142+00.20

d) Drop Interval of 20ft.


Note: Once again, we are offsetting the **Start** and **Stop** location of the **Extend Rock Templates Drops** so that when we create a **Terrain Surface** of the extended rock corridor the **Terrain Surface** will extend slightly past the start and stop locations of the **Final Roadway “Benching” Template Drops**.




- 60) Select the “F6” key to open 3D view of model.
- 61) Add as a **Corridor Reference** the **Six Geometry Scratch** shapes that represent the Rock Limits. To help with this in the **View 1, Default** you can turn off the **Display** of the **Terrain_Rock_Boreholes_J5U0441G.dgn** file
- 62) You should notice many gaps in-between the Rock Surface and the Extended Rock Surface.



The **Extend Rock** template has two points Seeking one of the Six (6) Rock Terrain Surfaces.



The two points on the inside of the **Rock_Extention_Line** Component (see both **Point #4s** above) have a Project to Surface Constraint that looks for the **Rock Surface** defined in the **Value** field.



63) For each of the **Six (6)** Template Drops, set the appropriate **Rock Boreholes-X** Surface for the **LT_Extend_Rock_1** and **RT_Extend_Rock_1** points.

Note: If there are spikes in your 3D Rock Extension Model, verify you are using **0-Preliminary x5** Corridor Feature Definition. With this Corridor Feature Definitions, the **Densify Vertical** setting is set to **False**. When this setting is set to **True**, spikes tend to draw in the model.

64) Once the Rock Extension is done for all sections, review how the **Rock Extension** is drawing within the Cross Section or 3D View.

65) Open the **Corridors_Preliminary_J5U0441G.dgn**

66) Within **View 1, Default** reference in the **Corridors_Extend_Rock_J5U0441G.dgn**


67) Open the **Dynamic Cross Sections** and review the **Extended Rock Layer**.

- 68) After reviewing the Dynamic Cross Sections **Detach** the following two files from the **View 1, Default window** and if necessary, the **View 2, Default-3D** window:

Corridors_Extend_Rock_J5U0441G.dgn
Terrain_Rock_Boreholes_J5U0441G.dgn


19.5.4 Creating a Terrain for the Extend Rock:

- 69) Create a new file named **Terrain_Extend_Rock_J5U0441G.dgn**
- Use the **MoDOT_Roadway_Seed_3D.dgn** seed file.
 - Set the **Geographic Coordinate System** using the settings in the following file:
Terrain_Existing_Ground_J5U0441G.dgn
 - Reference in the **Default-3D Model** of the following dgn file:
Corridors_Extend_Rock_J5U441G.dgn
- 70) Within the **Level Display** and the **Corridors_Extend_Rock_J5U0441G.dgn**, Turn Off the **Default** and **Scratch-1** levels.



- 71) Within the **Reference Dialog**, select the **Default-3D** Model and then select **Tools** → **Merge into Master**.

Then **Left Click** in a blank area to accept the Merge.




- 72) Select **all** Extended Rock Corridor Features and then select **Drop Element** Tool located withing the **OpenRoads Modeling Workflow** → **Drawing Tab** → **Groups Section** → **Drop Tools**.

Toggle on **Solids** and set **To Wireframe**

Note: Dropping Solids - (3D only) If checked **ON**, the associated option menu lets you drop SmartSurfaces or SmartSolids:


To Geometry - They are dropped to simple surfaces.

To Wireframe - They are dropped to wireframe elements.



- 73) Create a terrain model for each **Extended Rock Template Geometry** using the **From Elements** tool located within the **OpenRoads Modeling Workflow** → **Terrain Tab** → **Create Section**.

Increment the Terrain **Feature Name** accordingly for each Rock Surface, making sure you select the **Enter** or **Tab** key to lock in the Name, else the name won't stick.



Notes: We are using a **Feature Definition** of **Design Triangle** so that the **Symbology** is different when we **Complex** the **Extended Rock Terrain** and the **Terrain** created from the **Boreholes**.

Once again when adjusting the **Name**, be sure to **Enter** or **Tab** in the name field, otherwise the tool will apply the Default name.

- 74) Clean Up any bogus triangles as needed, using the Terrain **Edit Model** tools located within the **OpenRoads Modeling Workflow** → **Terrain Tab** → **Edit Section**.

Note: To help with determining which Triangles need to be deleted, you can turn **On** and **Off** the **Modeling-Terrain-Proposed Level**.


- 75) Turn off the **Extended Rock Graphics** by using the **Level Display** Tool and turning off the **XS-Existing subsurface-rock Level**.

19.5.5 Creating the Rock Final Terrain:

- 76) Create a new file named **Terrain_Rock_Final_J5U0441G.dgn**
- d. Use the **MoDOT_Roadway_Seed_3D.dgn** seed file.
 - e. Set the **Geographic Coordinate System** using the settings in the following file:
Terrain_Existing_Ground_J5U0441G.dgn
 - f. Reference in the following dgn file:
Terrain_Extend_Rock_J5U0441G.dgn
Terrain_Rock_Boreholes_J5U441G.dgn

- 77) Create a terrain model for each rock area using the **Create Complex Terrain Model** tool by selecting the **OpenRoads Modeling Workflow** → **Terrain Tab** → **Create Section** → **Additional Method Tools**.

Increment the Terrain **Feature Name** accordingly for each Rock Surface.




Note: We are using a Feature Definition of **Existing Triangles** so that the Symbology is **different** than the two Symbologies of the Terrains we are Merging. By doing so, we will be able to see how well the Surfaces Merged together. We will adjust this **Terrain Feature Definition** at a later step.

To help with visualizing how the Terrains Merged together, you can turn **On** and **Off** the **Modeling-Triangle-Existing** Level.


If the **Rock Terrain Model** is created but is **not visible**, go into **Explorer**, **Delete** the Terrain Model, run the **ORD Clean-up Tool** and reapply the **Merge**.

After typing in the **Terrain Name** for the first time, highlight and copy the **Final Rock-1** name so that it can be pasted into the dialog box for **Final Rock-2** through **Final Rock-6** names. The tool does not remember the previous terrain named used.

- 78) Within each newly created **Rock Final** Terrains, **remove the rules** back to the original terrains.



The easiest way to **Remove** the **Rules** using the **Explorer** → **OpenRoads Model** Section.




- 79) Once all the Rules have been Removed with the Reference dialog select **Tools** → **Detach All**

- 80) Within all the Final Rock Terrain Models, set the Feature Definitions to **Existing Rock Boundary**.

Note: Unlike dropping the terrain **Rules**, you can use **Explorer** to **bulk** edit the **Terrain Feature** definition.

The next few steps we are going to recreate our Corridor and then Cross Sections so that we can calculate our Rock Excavation using the **End Area Method** and **Cross Sections every 100 feet**. Within our Corridor we need to add to our roadway template a Benching Component, so that Rock Benching will draw if our Roadway template crosses our Rock Surface. The Benching Template should follow the guidelines specified in the Soil Survey as for as **Bench Height, Bench Width, Ditch Width**, and the **Soil Back Slope**.



19.6 Creating the Benching Template:

81) Open the Cole\J5U0441G\Corridors_**Preliminary**_J5U0441G.dgn.

82) Select **Save As** and name the new file as Corridors_**Rock**_J5U0441G.dgn.

83) In View **1, Default**, reference in the Terrain_**Rock_Final**_J5U0441G.dgn located in the **Final** sub folder.

84) Verify the active **Template Library** is pointing to the **J5U0441G.itl**

85) In the dgn **Edit** the **Template Drop**.


We are going to add the Rock Benching on the **Left** side of the Template first and then come back and do the **Right** side.

86) Modify the **Priority** of the End Conditions on both sides of the **Route 179** Template Drop with the following:

- **Ditch** End Condition = 3
- **Fill** End Condition = 4

87) Verify Apply Affixes are turned on and Step Options are greater than zero.

88) Add to the **Left** outside Shoulder Point (LT_O_AsphSurf_T_O_EOS) a Benching Components called **Rock Benching** located within **Components → Benching**




Note: Verify when placing the **Benching** Component that only the Origin Point Merges with the existing **Shoulder** Point. In some cases, if the **new** Template geometry is similar to the **existing** Template Geometry, sometimes the Common Points will all merge together. **If needed place the template in a blank area and move the elements.**


- 89) Within **BOTH** Benching **Component Properties** verify the **Target Type** is set to **Terrain Model** and the Terrain Model is set to **Rock Final 1**.
- 90) Select the **Test** button to verify the Benching Component is seeking the Rock Surface.
- 91) Verify the Rock Ditch is **unable** to draw when the Rock Surface is sloping down to the **Right**.
- 92) Once again add to the **Left** outside Shoulder Point (LT_O_AspHSurf_T_O_EOS) a second Benching Components called **Rock Surface Below Benching Wall w/Ground Backslope** located within **Components → Benching**

Note: Verify when placing the **Benching** Component that only the Origin Point Merges with the existing **Shoulder** Point. Again, in some cases, if the **new** Template geometry is similar to the **existing** Template Geometry, sometimes the Common Points will all merge together.

- 93) Verify using the **Test** button that the Rock Ditch is now **able** to draw when the Rock Surface is sloping down to the Left within the Ditch area. (Hint, with the Rock Surface use a positive slope like 5% or 10%)


- 94) **Close** and **Save** the Template Library.

- 95) Selecting the Corridor Grips, **Open** the **Dynamic Cross Section Model**. 
Verify the Rock Bench is drawing in area of the **first** Rock Surface/Terrain.



Next, we're going to focus on what happens after the Benching component draws up to the **Rock Surface**. In this example we are going to first follow the **Top of Rock Surface** out until it finds the **Slope of Repose**. Once it finds the **Slope of Repose**, we will then seek the **Existing Ground Surface** with a **4:1 End Condition**.

In the next step we will add a temporary component to help us visualize where the **Slope of Repose** is located.



96) Select the **Berm** Component located under **Components** → **Berm** and place it in a **blank area** of the template near the **LT_Back of Ditch** location.

97) Edit the **Berm** Component by modifying the following:

Component Properties

Name:

☐ Use Name Override:

Description:

Feature Definition:

Display Rules:

Parent Component:

☐ Exclude From Top/Bottom Mesh

Vertex Fillet Tangent Lengths

Select points to apply fillet tangent length to:

Name	Tangent Length

Fillet Tangent Length:

Feature Definition → Mesh\Design\Design Standards\Modeling\Corridor Meshes\Bottom Mesh

Notes: We are changing the Feature Definition to help make **Slope of Repose** line stand out from the other elements (Orange Line).

By defining the **Parent** Component, the Berm Component (Slope of Repose) will only draw if the Rock Benching Draws.

98) Modify the **LT_Berm_B** point with the following Constraint Settings:

Constraints													
	<table border="1"> <thead> <tr> <th colspan="2">Constraint 1</th> </tr> </thead> <tbody> <tr> <td>Type:</td> <td>Vertical</td> </tr> <tr> <td>Parent 1:</td> <td>LT_Berm_T</td> </tr> <tr> <td>Value:</td> <td>10.0000</td> </tr> <tr> <td>Label:</td> <td>-Berm_Width</td> </tr> </tbody> </table>	Constraint 1		Type:	Vertical	Parent 1:	LT_Berm_T	Value:	10.0000	Label:	-Berm_Width		
Constraint 1													
Type:	Vertical												
Parent 1:	LT_Berm_T												
Value:	10.0000												
Label:	-Berm_Width												
	<table border="1"> <thead> <tr> <th colspan="2">Constraint 2</th> </tr> </thead> <tbody> <tr> <td>Type:</td> <td>Slope</td> </tr> <tr> <td>Parent 1:</td> <td>LT_Berm_T</td> </tr> <tr> <td></td> <td><input type="checkbox"/> Rollover Values...</td> </tr> <tr> <td>Value:</td> <td>-1:2 or -50.00%</td> </tr> <tr> <td>Label:</td> <td>-Slope of Repose</td> </tr> </tbody> </table>	Constraint 2		Type:	Slope	Parent 1:	LT_Berm_T		<input type="checkbox"/> Rollover Values...	Value:	-1:2 or -50.00%	Label:	-Slope of Repose
Constraint 2													
Type:	Slope												
Parent 1:	LT_Berm_T												
	<input type="checkbox"/> Rollover Values...												
Value:	-1:2 or -50.00%												
Label:	-Slope of Repose												

99) Move the **LT_Berm_T** Point to the **LT_Back of Ditch** point.

100) Left-Click on the **LT_Berm_T** Point and select **Merge**.

When asked **Delete Point**, select the **LT_Berm_T** point. Then when asked **Merge LT_Berm_T With Point**, select the **LT_Back of Ditch (Rock)** point.


Delete Point	Merge LT_Berm_T With Point
LT_Back of Ditch (Rock) B	LT_Back of Ditch (Rock)
LT_Back of Ditch (Rock)	LT_Back of Ditch (Rock) B
LT_Berm_T	LT_Dtch_Bkslp_1_B
LT_Dtch_Bkslp_1_B	LT_Dtch_Bkslp_1_B1

Note: We placed the **Berm (Slope of Repose)** this way so that we could control which point the **LT_Berm_T** Point would be merged with. We wanted the **LT_Berm_T** Point to merge with the **point** that is part of the Bench Wall.

Check the Dynamic Cross Section Model



Next step we will add a **Component** to the Rock Wall that will follow the Slope of the Rock until it intersects the **Slope of Repose**.




Important Notes about adding to **Benching Components** and **End Conditions**:


- **Benching Component** is an End Condition with the **Benching Count** option **Turned On**.
- If an **End Conditions** is added to the **last point** of a **Benching Component**, the End Condition will typically always draw on the last segment of the **Benching Component**.
- If a regular **Component** (Non-End Condition) is added to the **last point** of a **Benching Component**, the **Component** may or may not always draw on the last segment of the **Benching Component**. If you need to add a regular **Component** (Non-End Condition) and it needs to be draw on the last segment of the **Benching Component**, add an **End Condition** to the end of the **Benching Component**.
- After adding **End Condition** to a **Benching Component**, if the **End Condition** is checking for interception and does not hit its Target the **End Condition** and the **Benching Component** will not Display.
- **You** can have many **End Conditions** branching off of a single point, but the only **End Condition** that will Display is the one that **finds its Target** and has the **Lowest Priority**. If all the branching End Conditions have the **same Priority** and they **all find their Target**, typically the **first** End Condition added will be the only one that Displays.

- 101) Select the **Berm** component located under **Components** ➔ **Berm** and place it on the **LT_Bench_Outer** point.




You will notice (as described above about adding to a **Benching** component) that the **Berm** is not drawing on the **last** segment of the **Benching Component**.

- 102) To fix this issue in the last step, select the **Ditch Back Slope 1 (4:1) End Condition** located under **End Conditions** → **Ditch** and also place it on the **LT_Bench_Outer** point. 
- 103) Adjust the **LT_Ditch_Bkslp_1_T2** point with the following settings to **temporarily** turn off the **End Condition**. We will come back to this **End Condition** at a later step.



Point Properties

Name: 

☒ Use Feature Name Override:

Feature Definition:

☐ Superelevation Flag

Alternate Surface:

End Condition Properties

☒ Check for Interception

☒ Place Point at Interception

☒ End Condition is Infinite


☒ Do Not Construct

Member of:

Constraints

Constraint 1

Type:

Parent 1: 


Parent 2: ☐ Rollover Values...

Value: =

Label:

Constraint 2

Type:

Parent 1: 

Parent 2: ☐ Rollover Values...


Value: =

Label:


☐ Horizontal Feature Constraint

Range:

- 104) Double-Click on the newly placed **Berm Component** and change the following settings listed below:



Component Properties


Name: 

☐ Use Name Override:

Description:

Feature Definition:

Display Rules:

Parent Component: 

☐ Exclude From Top/Bottom Mesh

Buttons: Apply, Close, < Previous, Next >, Edit..., Classifications

Feature Definition → Mesh\Template Components\Grading\XS_Ground_Proposed

- 105) To get the **Berm Component** in the proper orientation, **Modify** the **LT_Berm_B** point with the following Settings, modifying **Constraint 2** first then **Constraint 1**:

Point Properties

Name: **LT_Seek Slope of Repose 1** [Apply] [Close] [< Previous] [Next >]

☐ Use Feature Name Override: LT_Seek Slope of Repose 1

Feature Definition: \tutes\Grading\XS_Ground_Proposed

☐ Superelevation Flag

Alternate Surface: Proposed Finished Grade

Member of: LT_Berm

Constraints

2 Constraint 1

Type: Vertical

Parent 1: LT_Bench_Outer

Value: 3.0000

Label:

1 Constraint 2

Type: Slope

Parent 1: LT_Back of Ditch (Rock)

☐ Rollover Values...

Value: -50.00%

Label: -Slope of Repose

☐ Horizontal Feature Constraint

Range: 0.0000

- 106) To get the **LT_Top Bench (Sloped)** to follow the **Rock Surface** out to the **Slope of Repose** modify again the **LT_Seek Slope of Repose 1** point with the following Settings:

Constraints

Constraint 1

Type: Project To Surface

Parent 1: Any Direction

Value: Final Rock-1

Label:

Constraint 2

Type: Slope

Parent 1: LT_Back of Ditch (Rock)

☐ Rollover Values...

Value: -50.00%


Label: -Slope of Repose

Note: We purposely used a “**Regular**” Component over an **End Condition**, because based on the testing we did, the “**Regular**” Component (**Berm**) seemed to trace the ground more accurately with the point settings listed above...

Next, we need to add another **End Condition** to **left** side of the **LT_Top Bench Sloped Component** that will draw to the **Existing Ground** Terrain model.

107) Again, select the **Ditch Back Slope 1 (4:1)** End Condition located under **End Conditions** ➔ **Ditch** and place it on the **LT_Seek Slope of Repose 1** point.

108) Modify the **Ditch Back Slope 1 (4:1)** Component with the following settings:



Component Properties

Name: **LT_Top Bench (Seek Ground) 1**

☐ Use Name Override: LT_Top Bench (Seek Ground) 1

Description:

Feature Definition: onents\Grading\XS_Ground_Proposed


Display Rules:

Parent Component: **LT_Top Bench Sloped**

☐ Exclude From Top/Bottom Mesh

Buttons: Apply, Close, < Previous, Next >, Classifications

109) Modify the **LT_Dtch_Bkslp_1_T3** Point with the following settings:



Point Properties

Name: **LT_Dtch_Bkslp_1_T3**

☒ Use Feature Name Override: LT_LOC_Cut

Feature Definition: nt Features\Grading\XS_LOC_Cut

☐ Superelevation Flag

Alternate Surface: Proposed Finished Grade

End Condition Properties

☒ Check for Interception

☒ Place Point at Interception

☒ End Condition is Infinite

☐ Do Not Construct

Member of: LT_Ditch Back Slope 12

Constraints

Constraint 1

Type: Slope

Parent 1: **LT_Seek Slope of Repos**

Parent 2: ☐ Rollover Values...

Value: -50.00%

Label: -Slope of Repose

Constraint 2

Type: Horizontal

Parent 1: **LT_Seek Slope of Repos**

Value: -4.0000

Label: -Ditch_Bkslp_1_Width


☐ Horizontal Feature Constraint

Range: -0.0000

Buttons: Apply, Close, < Previous, Next >

Constraint 1 Parent 2 ➔ LT_Seek Slope of Repose 1

Note: One thing we have to think about is when the template traces the Rock Surface will it “**Catch Water**”? If so, this is typically an undesirable result, in this situation a flat slope would be more desirable. So in the next several step we will incorporate a **Display Rule** to draw a **Flat Top Slope** when we encounter the Rock Surface sloping away from the Rock Bench.



110) Edit the **LT_Dtch_Bkslp_1_T2** point and toggle OFF **Do Not Construct**.



111) Double click on the **LT_Ditch Back Slope 11** **End Condition** and **modify** the following settings:

Component Properties

Name: **LT_Top Bench (Flat)**

☐ Use Name Override: LT_Ditch Back Slope 11

Description:

Feature Definition: onents\Grading\XS_Ground_Proposed

Display Rules:

Parent Component: LT_Bench_Wall (Rock)

☐ Exclude From Top/Bottom Mesh

Buttons: Apply, Close, < Previous, Next >, Edit..., Classifications


- 112) To get the **End Condition** in the proper orientation, **Modify** the **LT_Dtch_Bkslp_1_T*** point with the following Settings:

Notes:

- If **Use Feature Name Override** was left on the point would draw to the other **LT_LOC_Cut** point in the previously placed End Condition. Later we will turn this option “**ON**” after we apply a **Display Rule** for our two Top of Bench solutions (Flat vs. Sloped).
- The reason we are turn OFF Check for Interception, is to get the End Condition to temporally draw while we construct the remainder of the template.




- 113) To get the **LT_Top Bench (Flat)** to draw out to the Slope of Repose modify again the **LT_Seek Slope of Repose 2** point with the following Settings:



The screenshot shows the 'Constraints' dialog box with two tabs: 'Constraint 1' and 'Constraint 2'. 'Constraint 1' is set to 'Vertical' with 'Parent 1' as 'LT_Bench_Outer' and a 'Value' of '0.0000'. 'Constraint 2' is highlighted with a red box and is set to 'Slope' with 'Parent 1' as 'LT_Back of Ditch (Rock)' and a 'Value' of '-50.00%'. The 'Label' for Constraint 2 is '-Slope of Repose'. A green checkmark icon is visible to the right of the dialog box.


Next, we need to add another **End Condition** to the left side of the **LT_Top Bench (Flat) Component** that will draw to the **Existing Ground** Terrain model.

- 114) Again, select the **Ditch Back Slope 1 (4:1)** End Condition located under **End Conditions** → **Ditch** and place it on the **LT_Seek Slope of Repose 2** point.
- 115) Modify the **LT_Ditch Back Slope 11** **Component** with the following settings:



The screenshot shows the 'Component Properties' dialog box for 'LT_Top Bench (Seek Ground) 2'. The 'Name' field is highlighted with a red box. The 'Parent Component' is set to 'LT_Top Bench (Flat)'. The 'Feature Definition' is set to 'onents\Grading\XS_Ground_Proposed'. The 'Display Rules' field is empty. The 'Exclude From Top/Bottom Mesh' checkbox is unchecked. Buttons for 'Apply', 'Close', '< Previous', 'Next >', and 'Classifications' are visible on the right.

116) Modify the **LT_Dtch_Bkslp_1_T2** Point with the following settings:



Point Properties

Name:

☒ Use Feature Name Override:

Feature Definition:

☐ Superelevation Flag

Alternate Surface:

End Condition Properties

☒ Check for Interception

☒ Place Point at Interception

☒ End Condition is Infinite

☐ Do Not Construct

Member of:

Constraints

	Constraint 1		Constraint 2
Type:	<input type="text" value="Slope"/>		<input type="text" value="Horizontal"/>
Parent 1:	<input type="text" value="LT_Back of Ditch (Rock)"/> <input type="button" value="Apply"/>		<input type="text" value="LT_Seek Slop of Repose"/> <input type="button" value="Apply"/>
Parent 2:	<input type="checkbox"/> <input type="button" value="Rollover Values..."/>		
Value:	<input type="text" value="-50.00%"/> =		<input type="text" value="-3.0000"/> =
Label:	<input type="text" value="-Slope of Repose"/>		<input type="text"/>


☐ Horizontal Feature Constraint:

Range:

19.6.1 Interesting Notes about End Conditions, Benching, Parent/Child Relationships:

Say you have **Two End Conditions** called “A” and “B”. **End Condition B** is connected to its parent **End Condition A**. **End Condition A** is connected to its parent the **Rock Benching** Component. All elements are **Checking for Interception**.

- a) If the End Conditions and Rock Benching all find their targets, the End Conditions and the Rock Benching **will all** draw.
- b) If any of the **End Conditions or Rock Benching** can't find their target, the End Conditions and Rock Benching **will all not** draw.



Notes: A **Child Component** will only be displayed if it's **Parent Component** is displayed.

When deleting Components/End Conditions, deleting a **Parent** deletes all **Children** too.


19.6.2 Template Display Rules

We are going to use a **Display Rule** to draw the Flat Slope when the Rock Bench falls down and away Rock Bench Wall and follow the slope when it slopes upward.

117) In the **Dynamic Cross Section View** navigate to **Sta. 62+00**


In the next few steps, we are going to setup a Display Rule that will turn **OFF** the Display the **LT_TOP Bench (Sloped)** component when **Rock Surface** is sloping **downward and away** from the **LT_Bench_Outer** point.

118) Edit the **LT_Top Bench (Sloped)** Component and select the **Edit** button right of **Display Rules**.




In the **Component Display Condition Expression** Dialog select the **Add** button.

119) Set up the Display Rule dialog as follows:




- 120) Select the newly created **Display Rule** and **Add** it to the **Condition Expression** section of the dialog.



Note: The **True/False** result that is reported after selecting the **equal (=)** sign is based off the **Current Template Location**.

- 121) You can now see the **Display Rule** within the Component Properties. Select **Apply** and **Close** to the Component properties Dialog Box.




In the next few steps, we are going to setup a Display Rule that will turn **OFF** the Display the **LT_TOP Bench (Flat)** component when **Rock Surface** is sloping **upward and away** from the **LT_Bench_Outer** point.

122) In the **Dynamic Cross Section View** navigate to **Sta. 71+00**

123) Edit the **LT_Top Bench (Flat)** Component and select the **Edit** button right of **Display Rules**.

The screenshot shows the 'Component Properties' dialog box for the 'LT_Top Bench (Flat)' component. The 'Name' field is 'LT_Top Bench (Flat)'. The 'Use Name Override' checkbox is unchecked. The 'Description' field is empty. The 'Feature Definition' is set to 'onents\Grading\XS_Ground_Proposed'. The 'Display Rules' field is highlighted with a red arrow pointing to the 'Edit...' button. The 'Parent Component' field is empty. The 'Exclude From Top/Bottom Mesh' checkbox is unchecked. The 'End Condition Properties' section includes 'Target Type' set to 'Terrain Model', 'Priority' set to '1', 'Terrain Model' set to '<Active>', 'Fillet Tangent Length' set to '0.0000', 'Benching Count' set to '0', and 'Rounding Length' set to '0.0000'. The 'Offsets' section shows 'Horizontal' as '-0.0000' and 'Vertical' as '0.0000'. The 'No Datum' button is disabled.


124) In the **Component Display Condition Expression** Dialog select the **NOT** button.



Lastly select the previously defined **Template Display Rule** and **Add** it to the **Condition Expression** section of the dialog.

Note: The **True/False** result that is reported after selecting the **equal (=)** sign is based off the **Current Template Location**.


125) You can now see the **Display Rule** within the Component Properties. Select **Apply** and **Close** to the Component properties Dialog Box.



- 126) You will notice when using a Display Rule with a **Condition Expression** that is **False** the Component will not display in the Template Window unless you select the **Active Template** Tab.




- 127) In the **Dynamic Cross Section View** navigate through the sections withing the first Rock Surface.
- 128) Remove the temporary **Slope of Repose** line from the Template.




- 129) In the **Dynamic Cross Section View** navigate to **Sta. 74+00**

- 130) You will notice that the **Berm Component** continues to draw even though there is no rock bench. To take care of this we will define the **Benching Component** as the **Top Bench (Sloped)** Parent Component. That way if the **Benching Component** does not draw, the **Top Bench (Sloped)** will not draw as well. When Defining **Benching Components** as **Parents**, it is recommended to select a **Benching Component** that does not have **Benching Count** (See Note below).




- 131) Within the **Berm Component**, Set the **Parent Component** as the **LT_Foreslope and Ditch (Rock)** Component.



Note #1: The reason we did not use the **Rock Wall** as the **Parent Component** is because in doing so the **Lt_Top Bench (Sloped)** Component (Berm) would start to draw on several segments of the Rock Wall.

Note #2: The reason we did not use two **End Condition** for the **Flat** and **Sloped** Components is because **Display Rules** have **no** effect on the **End Condition Priorities**.

Example 1: Display Rules and End Conditions



Scenario 1) There is a Display Rule that toggles between **Displaying** the **Sloped End Condition** and the **Flat End Condition**, and at a certain Template drop the **Display Rule** tries to **Visualize** the **Sloped End Condition**


Result = Sloped End Condition WILL Display.

Scenario 2) There is a Display Rule that toggles between **Displaying** the **Sloped End Condition** and the **Flat End Condition**, and at a certain Template drop the **Display Rule** tries to **Visualize** the **Flat End Condition**

Result = Flat End Condition will NOT Display.

This is because the **Flat End Conditions** has a lower **Priority (2)** than the **Sloped End Condition (1)** and will not draw even though the **Display Rule** is turning it **ON**.

Remember a **higher** End Condition **Priority** is the one with a **lower** number.

Example 2: Display Rules and End Conditions

Scenario 3) There is a Display Rule that toggles between **Displaying** the **Sloped End Condition** and the **Flat End Condition**, and at a certain Template drop the Display Rule tries to **Visualize** the **Sloped End Condition**

Result = Sloped End Condition will NOT Display.


Scenario 4) There is a Display Rule that toggles between **Displaying** the **Sloped End Condition** and the **Flat End Condition**, and at a certain Template drop the Display Rule tries to **Visualize** the **Flat End Condition**

Result = Flat End Condition WILL Display.

This is because the **Sloped End Conditions** has a lower Priority (2) than the Flat End Condition (1) and will not draw even though the Display Rule is turning it **ON**.

Remember a **higher** End Condition Priority is the one with a **lower** number.

Conclusion: Display Rules do not have a higher level of control over End Condition Priorities. End Condition Priorities will always supersede Display Rules. In other words, even though a Display Rule is allowing an End Condition to display, the End Condition Priority may still not allow it to draw.

Example 3: End Conditions with **Same Priority**

Scenario 5) There is **no** Display Rules to toggle between **Displaying** the **Sloped End Condition** and the **Flat End Condition**, and **both** End Condition can **solve** for their **target**.

Result = Sloped End Condition WILL Only Display

This is because the **Sloped End Condition (Priority = 1)** was added to the template **first**, and then the **Flat End Condition (Priority = 1)** was second.

If the **End Condition** priorities are **equal**, the **first** End Condition placed in the template will be the only **End Condition** to draw.

Conclusion #2: The relationship between **Display Rules and End Condition Priorities** is the reason we did not use **two** End Condition to solve for the two “**Tie to Ground**” scenarios/components we have set up. By using a “**Regular**” Component for either the **Slope** or **Flat** Element that branches off the **LT_Bench_Outer** point we are able to then utilize a **Display Rule** to turn the elements OFF and ON.

19.6.3 Point - Feature Name Override


Next, we will edit the Roadway Template by turning **ON** the **Use Feature Name Override** option on several of the Template **Points**.



Notes: Use **Feature Name Override** displays the **Override Point Name** of the feature that will be created in the surface to correspond to the point. This field is **optional**. If it is **blank**, then the **Original Point Name** will be used as the Feature Name.

Another way of describing Point Property **Feature Name Overrides**, is that it changes the final design surface **Point Names** (which can be many) to a **Common Single Name** for different tie slopes.

- The option is intended primarily for End Condition components to create connectivity from one template drop to the next, when the template End Conditions change.
- **For example**, if you want all surface tie-in points to belong to one feature, then set the feature name of all the ending end condition points on each side of the template to the same name (i.e. all **Cut and Fill End Points** on the **Right** would be given the feature name **R-Tie** and all the ones on the **Left** would be given the feature name **L-Tie**).
- If the Point has a **Feature Name Override** defined, the point name is displayed in **Red** in the Template window.
- Also helps Avoids End Condition **Transition Issues**.

132) Use the following two **Named Overrides** listed in the diagram below for the **four** Points indicated.





19.6.4 Component - Feature Name Override

Next, we will edit the Roadway Template by turning **ON** the **Use Feature Name Override** option on several of the Template **Components**.

Notes: Use this dialog to set the Component Name Override property on a group of components. Be careful when using this dialog to ensure that only components that are mutually exclusive to the solution at any given station will be assigned to the same component name.

Component Name Override does not apply to component display rules, Active Template list, or Parent/Child pulldown.






The **first** encountered component's feature definition is used for all components with that override.



Component Feature Name Overrides help with gaps in models where **Display Rules** in abutting template drops display different components.

133) Use the following two **Named Overrides** listed in the diagram below for the **four** Components indicated.





Next, we need to add the **Rock Benching** component on the Right side of our Roadway Template.

- 134) But, before we add the **Rock Benching** Components adjust the Priorities of the right Ditch (to **Priority 3**) and right Fill (to **Priority 4**) End Conditions



- 135) Select the **Rock Benching with Top of Bench Ground Sloped/Flat Component** located under Components → Benching and place it on the **RTO_AsphSurf_T_O_EOS** Point.


Make sure you have **Apply Affixes** Turn on.

- 136) Using the diagram below make sure the **Components and Points** are targeting the **Final Rock-1** Surface.

- 137) Once the Template is fully created it might be beneficial to save it in the Project itl. Using the **Template Library Organizer**, copy the Active Template into the **J5U0441G** Folder and call it **4 Lane Asphalt w/ Type C Barrier with Rock Benching**.

Note: One thing you probably notice is that this Template is only good for the **First Rock Surface** because the **Left and Right Rock Benching Components** are seeking the Terrain Model called **Rock Final 1**.


Also, the Point **Seek Slope of Repose** on each side of the Template is also Projecting to a **Rock Final 1** Surface (Terrain)



To make the Template draw to the other **Rock Surfaces** we will need to adjust Template Drop Stationing for the first Rock Surface, and then copy multiple times the template drop so that each Rock Surface has their own Template drop.

- 138) First, adjust the **Station Range** of the **Template Drop** by selecting the **Template Grips** and adjusting the **Start and Ending Station** to **Sta. 61+99.90 and Sta. 85+00.10**.

- 139) Selecting the “heads-up” tools on **Template Drop** select **Copy Template Drop**, apply to the **RTE179** Corridor and using a **Station Range** of **Sta. 85+99.90 to Sta. 101+00.10**.



IMPORTANT: Make sure after the Template Drop has been added that there is only one Corridor.

- 140) In the **Second** Template Drop adjust The Rock Surface that the Template Elements (discussed on the previous page) are Targeting that need to point to **Rock Final 2** Surface (Terrain).

You will need to **modify** the following **Components** and **Points** on **both** sides of the Template:

Components

Bench_Wall (Rock)
Foreslope and Ditch (Rock)
Foreslope and Ditch (Rock) B

Points

Seek Slope of Repose

- 141) Open the following file located under data\Final\Corridors_X_J5U0441G.dgn

This file already has the following **Template Drops** ranges added:

Actual Station Ranges

- Sta. 61+99.90 to Sta. 85+00.10
- Sta. 85+99.90 to Sta. 101+00.10
- Sta. 101+99.90 to Sta. 115+00.10
- Sta. 115+99.90 to Sta. 123+00.10
- Sta. 123+99.90 to Sta. 139+00.10
- Sta. 139+99.90 to Sta. 142+00.10

Equivalent Station Ranges

Sta. 62+00 to Sta. 85+00
Sta. 86+00 to Sta. 101+00
Sta. 102+00 to Sta. 115+00
Sta. 116+00 to Sta. 123+00
Sta. 124+00 to Sta. 139+00
Sta. 140+00 to Sta. 142+00

We will be creating **Cross Sections** and their corresponding **Named Boundaries** every **100 ft** down the **Rte179** alignment. Eventually we will also be creating **Earthwork Meshes** from this Corridor file. Based on experience, we have determined it's best not to **start** and **stop** the Template Drop ranges where **XS Named Boundaries** will be located, therefore we will use the “**Actual**” **Station Ranges** listed above.


Also refer to **Page 20** in this chapter about cutting sections right on the edge of a Mesh element.

19.7 Verify Cross Sections are drawing at Critical Locations


142) Next, we need to review all the Cross Section in which we are planning use to calculate Earthwork. In this exercise, our Earthwork End Area calculation will happen on even 100-foot sections.

The following are some examples of Cross Sections not drawing 100% correct, and how to fix each of their issues.


Station **87+00**, to fix this issue add a **Key Station at 86+99.90**




Station **103+00**, to fix this issue add a **Key Station at 102+99.90**



Station **117+00**, to fix this issue add a **Key Station at 116+99.90**



Station **132+00**, to fix this issue add a **Key Station at 132+00.10**



19.8 Creating Rock Meshes to be used in Earthwork Calculations


Up to this point we have created Rock Surfaces to be used/targeted by our Benching Template to help us define the limits of our Rock Excavation within our Cross Sections.

Now we need to create a **Rock Mesh** to help OpenRoads Designer calculate the **Rock Excavation** using the **Cut and Fill Volumes** tool.

- 139) Open the **Create Closed Mesh** tool located under the **OpenRoads Modeling** Workflow → **Modeling Detailing** Tab → **3D Tools** Section.

Within the **View 2, Default 3D** use the following settings when applying the tool to the **Final Rock-1** Surface.

Use Fence:	Unchecked
Method:	Element to Depth
Depth:	75
Feature Definition:	Rock
Name:	Rock Mesh-1



The Feature Definition is located here:
Mesh → Existing → Rock


- 140) Using **Create Closed Mesh** tool apply the same settings to the remaining **Rock Surfaces** incrementing the Name (Rock Mesh-2, Rock Mesh-3, etc.).

19.9 Create Cut and Fill Volumes:


In the next few steps, we are going to setup and run the Cut and Fill Volumes tool. Based on experience, we have discovered the more complex the Corridor Templates are, the more unsteady this tool becomes. Also, the length of the corridor can have an impact on the stability of this tool.

141) Open the **Create Cut Fill Volumes** tool located under the **OpenRoads Modeling Workflow** → **Home Tab** → **Model Analysis and Reporting Section** → **Civil Analysis Tools**.

142) Check on **Compute Substrata** and **Accept** all the prompts.




143) You will notice that the program will melt down with this dataset.




At this point the Designer will need to break up the Corridor into smaller sections to-the-point where the **Create Cut Fill Volumes** tool will function. In this exercise we will break up our Corridor based on our six Existing Template drops.

- 144) Open the following file located under data\Final\Corridors_1-of-6_J5U0441G.dgn
- 145) Open the **Create Cut Fill Volumes** tool located under the **OpenRoads Modeling Workflow** → **Home Tab** → **Model Analysis and Reporting Section** → **Civil Analysis Tools**.
- 146) Check on **Compute Substrata** and **Accept** all the prompts.




- 147) When the **Create Cut Fill Volumes** tool works, it will draw Earthwork Meshes in **View 2, Default 3D**. The user will be able to view the meshes in the plan and XS view.



148) Next, we need to **review** the Cross Section view so that all meshes are drawn correctly on sections we're planning use to calculate Earthwork. In this exercise, our Earthwork End Area calculation will happen on even **100-foot** sections.

The reason we need to check these sections is because the **Create Cut Fill Volumes** tool does not always draw the Meshes fully on each section.


To demonstrate this issue, navigate to Station **65+00**, at this section there are a couple of areas of concerns:



Most of the times these gaps in the Mesh happen when the template is transitions from one template Drop to another, for example the following:


<u>Station</u>	<u>Situation</u>
65+00	Two Rock Benches on the Left side
65+20	One Rock Bench on the Left Side

149) To fix the Mesh, insert a **Key Station** just after the **65+00** Template Drop, use a value of **65+00.10**




150) Meshes are not dynamic so after adding the **Key Station** you will have to **delete** Earthwork Volumes (on Levels **Volumes-Rock Excavated**, **Volumes-Fill**, and **Volumes-Cut**) that were created and **rerun** the **Create Cut Fill Volumes** tool. It helpful to utilize the "Used" Filter in the **Level Display**.

The **Create Cut Fill Volumes** tool is located under the **OpenRoads Modeling Workflow** → **Home Tab** → **Model Analysis and Reporting Section** → **Civil Analysis Tools**.



151) Continue checking the Meshes at the full 100' even stations, adding **Key Station** where needed to help the Mesh to draw fully at those stations.

Below is a list where we recommend **Key Stations** be added:



The remaining dgn files have been processed for **Earthwork** and **Key Stations** added where necessary.

Corridors_2-of-6_J5U0441G.dgn

86+99.90, 89+00.10, 90+00.10, 90+99.90, and 91+00.10

Corridors_3-of-6_J5U0441G.dgn

102+99.90, 103+99.90, and 108+00.10

Corridors_4-of-6_J5U0441G.dgn

116+99.99, 118+00.10, and 119+00.10

Corridors_5-of-6_J5U0441G.dgn

126+99.90, 127+00.10, 128+99.90, and 132+00.10

Corridors_6-of-6_J5U0441G.dgn

No Key Stations

19.10 Create Cross Sections Sheets with Earthwork Quantities:

152) Create a new file named:

Named_Boundary_Route-179_XS_Earthwork_J5U0441G.dgn

a) Use the **MoDOT_Roadway_Seed_2D.dgn** seed file.

b) Set the **Geographic Coordinate System** using the settings in the following file:

Terrain_Existing_Ground_J5U0441G.dgn

c) Reference in the following dgn files from the **J5U0441G/data/Final** folder:

Civil_Geometry_J5U0441G.dgn

Corridors_1-of-6_J5U0441G.dgn

Corridors_2-of-6_J5U0441G.dgn

Corridors_3-of-6_J5U0441G.dgn

Corridors_4-of-6_J5U0441G.dgn

Corridors_5-of-6_J5U0441G.dgn

Corridors_6-of-6_J5U0441G.dgn

Terrain_Existing_Ground_J5U0441G.dgn

Terrain_Rock_Final_J5U0441G

d) Set **Annotation Scale** to **50**


e) **Activate** Existing Ground Terrain.

f) Select **F6** to open the **Muli-Model** View


19.11 Creating the Named Boundary

- 153) **IMPORTANT:** If you haven't already enable both the **2D** and a **3D** view by selecting the **F6** key (or the tool will create the Named Boundaries and **NOT** the sheet and drawing models. The sheets may be created at a different time using the Named Boundaries Manager)
- 154) In this next step we are going to be placing Named Boundary's to indicate where we want to cut cross sections. We are going to show you two ways to open the Named Boundary Tool.


The first way to access the Named Boundary tool is to select the *OpenRoads Modeling Workflow* → **Drawing Production** tab → **Named Boundary** tool.



This method unfortunately does not set up the **Named Boundary** Attributes.




The **second** way to open the **Named Boundary** tool is to **Right-Click** and hold in a blank area in the Default 2D window (typically **View #1**)




The benefit of using the right click option is that ORD will automatically set up the Attributes for the **Named Boundary**.


Before




After



155) After the **Place Named Boundary** dialog opens, select the **Civil Cross Section** icon



- Use a Drawing Seed: XS Sheet – 20 Scale
- First** Identify the Path Element
- Set the following Dialog Settings:




- Once the dialog has been filled out then Accept/Reject to either place the named boundary or end the tool.


Place Named Boundary Civil Cross Section > Accept/Reject. Data point in Plan View to place boundary

19.12 End Area Volume Reporting:

- 156) Within the OpenRoads Modeling Workflow select the **Home Tab → Model Analysis and Reporting Section → Civil Analysis Tools → End Area Volume Report tool.**



- 157) Choose the **RTE179** for the Named Boundary Group.



- 158) In the next prompt, the tool will ask the User to define a **Volume Exception** by selecting the start and stop cross section named boundaries. Once the **Volume Exception** is defined or if there is no **Volume Exception**, the User can just **Reset** (Right-Click) to complete and create the **End Area Volume** report.


Select the start cross section named boundary for volume exception. Reset to complete.

Select the end cross section named boundary for volume exception. Reset to complete.

Note: This will bring up a report that has many other volume reports that are created. The importance of this report is that it creates an XML that is attached to each of the cross-section shapes that will allow for annotation.

19.12.1 Changing the Format Options of the Report:

159) Select the **Tools** option in the top left corner of the report and then select **Format Options**



160) In the Format Options dialog change the following:

Station **ss+ss.ss**

Cubic Units **Check the Convert to Cubic Yards box**

NOTE: Then close the dialog. In SS4 this dialog was dynamic meaning that if you changed a setting it would immediately change the report but in ORD it is not so closing the dialog enables the changes made.

A screenshot of the 'Format Options' dialog box. The dialog has a 'Close' button in the top right. It contains several settings organized into columns: 'Mode', 'Precision', and 'Format'. The 'Station' row is highlighted with a red rectangle, showing '0.12' in the Precision column and 'ss+ss.ss' in the Format column. The 'Cubic Units' row is also highlighted with a red rectangle, showing '0.12' in the Precision column and a checked box for 'Convert to Cubic Yard' in the Format column. Other settings include 'Northing/Easting/Elevation' (0.12), 'Angular' (Degrees, 0, ddd^mm'ss), 'Slope' (0.12, 0.5), 'Use Alternate Slope if Slope Exceeds' (0.00%), 'Alternate Slope' (0.12, 0.5), 'Linear' (0.12), 'Acres/Hectares' (0.12), 'Area Units' (0.12), 'Direction' (Bearings, 0, ddd^mm'ss), 'Face' (Right Face), and 'Vertical Observation' (Zenith). A 'Delimiter' field with a '+' sign is also present.

End Area Volume Report

Report Created: Thursday, July 10, 2025
Time: 2:32:14 PM

Cross Section Set Name: RTE179

Alignment Name: RTE179

Input Grid Factor:

Note: All units in this report are in feet, square feet and cubic yards unless specified otherwise.

----- Station Quantities -----									
Baseline Station	Factor	----- Cut -----				----- Fill -----			
		Area	Volume	Adjusted	Factor	Area	Volume	Adjusted	Mass Ordinate
62+00 R1	1.000	3546.88	0.00	0.00	1.000	0.00	0.00	0.00	0.00
63+00 R1	1.000	3631.60	13293.48	13293.48	1.000	0.00	0.00	0.00	13293.48
64+00 R1	1.000	3432.86	13082.34	13082.34	1.000	0.00	0.00	0.00	26375.82
65+00 R1	1.000	2869.53	11671.09	11671.09	1.000	0.00	0.00	0.00	38046.91
66+00 R1	1.000	2285.94	9547.17	9547.17	1.000	0.00	0.00	0.00	47594.08
67+00 R1	1.000	1192.58	6441.71	6441.71	1.000	0.00	0.00	0.00	54035.80
68+00 R1	1.000	837.71	3759.81	3759.81	1.000	0.00	0.00	0.00	57795.61
69+00 R1	1.000	558.99	2586.50	2586.50	1.000	19.32	35.78	35.78	60346.32
70+00 R1	1.000	333.75	1653.22	1653.22	1.000	362.90	707.83	707.83	61291.71
71+00 R1	1.000	160.72	915.68	915.68	1.000	818.44	2187.67	2187.67	60019.72
72+00 R1	1.000	103.48	489.26	489.26	1.000	1562.08	4408.37	4408.37	56100.61
73+00 R1	1.000	15.75	220.80	220.80	1.000	2325.94	7200.03	7200.03	49121.39
74+00 R1	1.000	0.00	29.17	29.17	1.000	4072.63	11849.20	11849.20	37301.36
75+00 R1	1.000	0.00	0.00	0.00	1.000	4797.86	16426.84	16426.84	20874.52
76+00 R1	1.000	0.00	0.00	0.00	1.000	5545.81	19154.95	19154.95	1719.57
76+08 R1	1.000	0.00	0.00	0.00	1.000	5609.74	19381.31	19381.31	0.00
77+00 R1	1.000	0.00	0.00	0.00	1.000	6365.92	22058.76	22058.76	-20339.19
78+00 R1	1.000	0.00	0.00	0.00	1.000	5949.22	22805.81	22805.81	-43145.01
79+00 R1	1.000	0.00	0.00	0.00	1.000	4778.62	19866.38	19866.38	-63011.38
80+00 R1	1.000	0.00	0.00	0.00	1.000	3804.18	15894.08	15894.08	-78905.47
81+00 R1	1.000	0.00	0.00	0.00	1.000	3392.77	13327.69	13327.69	-92233.16
82+00 R1	1.000	0.00	0.00	0.00	1.000	2956.52	11757.94	11757.94	-103991.10
83+00 R1	1.000	0.00	0.00	0.00	1.000	2976.36	10986.81	10986.81	-114977.91
84+00 R1	1.000	0.00	0.00	0.00	1.000	2341.42	9847.73	9847.73	-124825.64
85+00 R1	1.000	0.00	0.00	0.00	1.000	1994.21	8028.94	8028.94	-132854.58
86+00 R1	1.000	0.00	0.00	0.00	1.000	1000.69	5546.12	5546.12	-138400.69
87+00 R1	1.000	1286.62	2382.63	2382.63	1.000	0.00	1853.14	1853.14	-137871.20
88+00 R1	1.000	1580.90	5310.22	5310.22	1.000	0.00	0.00	0.00	-132560.98
89+00 R1	1.000	1781.93	6227.46	6227.46	1.000	0.00	0.00	0.00	-126333.53
90+00 R1	1.000	1232.71	5582.67	5582.67	1.000	0.00	0.00	0.00	-120750.86
91+00 R1	1.000	935.10	4014.47	4014.47	1.000	0.00	0.00	0.00	-116736.39
92+00 R1	1.000	502.74	2662.68	2662.68	1.000	237.60	439.99	439.99	-114513.70
93+00 R1	1.000	152.82	1214.01	1214.01	1.000	1277.24	2805.25	2805.25	-116104.94
94+00 R1	1.000	210.76	673.30	673.30	1.000	28.49	2418.03	2418.03	-117849.67
95+00 R1	1.000	1746.55	3624.64	3624.64	1.000	0.00	52.77	52.77	-114277.80
96+00 R1	1.000	1644.22	6279.20	6279.20	1.000	0.00	0.00	0.00	-107998.60
97+00 R1	1.000	1236.24	5334.19	5334.19	1.000	0.00	0.00	0.00	-102664.41
98+00 R1	1.000	960.64	4068.30	4068.30	1.000	0.00	0.00	0.00	-98596.11
99+00 R1	1.000	417.01	2551.21	2551.21	1.000	428.07	792.72	792.72	-96837.62
100+00 R1	1.000	0.00	772.25	772.25	1.000	1885.62	4284.62	4284.62	-100349.99
101+00 R1	1.000	0.00	0.00	0.00	1.000	5768.78	14174.82	14174.82	-114524.82
102+00 R1	1.000	0.00	0.00	0.00	1.000	2444.78	15210.30	15210.30	-129735.11
103+00 R1	1.000	419.21	776.31	776.31	1.000	166.80	4836.27	4836.27	-133795.07
104+00 R1	1.000	1478.71	3514.67	3514.67	1.000	0.00	308.90	308.90	-130589.30
105+00 R1	1.000	1595.35	5692.70	5692.70	1.000	0.00	0.00	0.00	-124896.59
106+00 R1	1.000	1468.33	5673.48	5673.48	1.000	0.00	0.00	0.00	-119223.11
107+00 R1	1.000	1258.19	5049.12	5049.12	1.000	0.00	0.00	0.00	-114174.00
108+00 R1	1.000	1295.98	4729.95	4729.95	1.000	0.00	0.00	0.00	-109444.05
109+00 R1	1.000	352.67	3053.06	3053.06	1.000	133.09	246.45	246.45	-106637.34
110+00 R1	1.000	0.00	653.09	653.09	1.000	2042.19	4028.28	4028.28	-110012.63
111+00 R1	1.000	0.00	0.00	0.00	1.000	4651.83	12396.32	12396.32	-122408.96
112+00 R1	1.000	0.00	0.00	0.00	1.000	5877.28	19498.34	19498.34	-141907.30
113+00 R1	1.000	0.00	0.00	0.00	1.000	6858.32	23584.44	23584.44	-165491.74
114+00 R1	1.000	0.00	0.00	0.00	1.000	7044.88	25746.68	25746.68	-191238.42
115+00 R1	1.000	0.00	0.00	0.00	1.000	5336.57	22928.61	22928.61	-214167.03
116+00 R1	1.000	0.00	0.00	0.00	1.000	3205.29	15818.25	15818.25	-229985.28
117+00 R1	1.000	236.74	438.40	438.40	1.000	923.89	7646.63	7646.63	-237193.52
118+00 R1	1.000	642.68	1628.55	1628.55	1.000	34.80	1775.35	1775.35	-237340.32
119+00 R1	1.000	1125.09	3273.65	3273.65	1.000	0.00	64.45	64.45	-234131.12
120+00 R1	1.000	1224.41	4350.92	4350.92	1.000	0.00	0.00	0.00	-229780.20
121+00 R1	1.000	1095.75	4296.60	4296.60	1.000	0.00	0.00	0.00	-225483.60
122+00 R1	1.000	551.53	3050.52	3050.52	1.000	396.51	734.28	734.28	-223167.37
123+00 R1	1.000	96.12	1199.34	1199.34	1.000	2296.31	4986.70	4986.70	-226954.72
124+00 R1	1.000	0.00	178.00	178.00	1.000	1444.13	6926.74	6926.74	-233703.46
125+00 R1	1.000	173.53	321.35	321.35	1.000	11.04	2694.76	2694.76	-236076.87
126+00 R1	1.000	1600.22	3284.73	3284.73	1.000	0.00	20.44	20.44	-232812.59
127+00 R1	1.000	1674.03	6063.43	6063.43	1.000	0.01	0.02	0.02	-226749.18
128+00 R1	1.000	1567.93	6003.63	6003.63	1.000	0.00	0.02	0.02	-220745.57
129+00 R1	1.000	1252.66	5223.31	5223.31	1.000	0.00	0.00	0.00	-215522.25
130+00 R1	1.000	580.44	3394.64	3394.64	1.000	285.67	529.03	529.03	-212656.64
131+00 R1	1.000	309.56	1648.15	1648.15	1.000	2180.85	4567.64	4567.64	-215576.13
132+00 R1	1.000	152.53	855.73	855.73	1.000	1745.05	7270.19	7270.19	-221990.59
133+00 R1	1.000	0.00	282.47	282.47	1.000	3364.21	9461.60	9461.60	-231169.72
134+00 R1	1.000	0.00	0.00	0.00	1.000	6227.96	17763.28	17763.28	-248933.00
135+00 R1	1.000	0.00	0.00	0.00	1.000	6235.42	23080.34	23080.34	-272013.33
136+00 R1	1.000	0.09	0.16	0.16	1.000	5516.13	21762.15	21762.15	-293775.32
137+00 R1	1.000	0.00	0.16	0.16	1.000	3804.10	17259.69	17259.69	-311034.84
138+00 R1	1.000	0.00	0.00	0.00	1.000	2357.28	11409.95	11409.95	-322444.80
139+00 R1	1.000	0.00	0.00	0.00	1.000	1288.01	6750.54	6750.54	-329195.34
140+00 R1	1.000	0.00	0.00	0.00	1.000	558.95	3420.31	3420.31	-332615.65
141+00 R1	1.000	899.65	1666.01	1666.01	1.000	0.00	1035.10	1035.10	-331984.74
142+00 R1	1.000	1710.85	4834.25	4834.25	1.000	0.00	0.00	0.00	-327150.48
Grand Total:			195523.83	195523.83			522674.32	522674.32	

161) Switch the to the **Volumes.xls Report** to show the individual types of Volume.

Volumes Report							
Report Created: Thursday, July 10, 2025 Time: 2:38:29 PM							
Cross Section Set Name: RTE179							
Alignment Name: RTE179							
Input Grid Factor: Note: All units in this report are in feet, square feet and cubic yards unless specified otherwise.							
Station	Type	Area	Volume	Factor	Adjusted Volume	Included in Mass Ordinate?	Mass Ordinate
62+00 R1							0.00
	XS_Concrete Barrier Type C:	4.65	0.00	1.000	0.00	No	
	XS_Asphalt Base Shld:	5.33	0.00	1.000	0.00	No	
	XS_Asphalt Surface Shld:	2.33	0.00	1.000	0.00	No	
	XS_Agg Base:	6.67	0.00	1.000	0.00	No	
	XS_Asphalt Base Pavt:	48.80	0.00	1.000	0.00	No	
	XS_Asphalt Surface Pavt:	9.36	0.00	1.000	0.00	No	
	XS_Rock Base:	167.74	0.00	1.000	0.00	No	
	XS_Rock_Bench:	482.00	0.00	1.000	0.00	No	
	Rock (removed):	8178.63	0.00	1.000	0.00	No	
	Total Rock:	25800.00	0.00	1.000	0.00		
	Cut:	3546.88	0.00	1.000	0.00	Yes	
63+00 R1							13293.48
	XS_Concrete Barrier Type C:	4.65	17.22	1.000	17.22	No	
	XS_Asphalt Base Shld:	5.33	19.75	1.000	19.75	No	
	XS_Asphalt Surface Shld:	2.33	8.64	1.000	8.64	No	
	XS_Agg Base:	6.67	24.69	1.000	24.69	No	
	XS_Asphalt Base Pavt:	48.79	180.70	1.000	180.70	No	
	XS_Asphalt Surface Pavt:	9.35	34.65	1.000	34.65	No	
	XS_Rock Base:	167.62	621.00	1.000	621.00	No	
	XS_Rock_Bench:	369.50	1576.85	1.000	1576.85	No	
	Rock (removed):	5080.48	22578.63	1.000	22578.63	No	
	Total Rock:	25800.00	95555.56	1.000	95555.56		
	Cut:	3432.86	13082.34	1.000	13082.34	Yes	
65+00 R1							38046.91
	XS_Concrete Barrier Type C:	4.71	17.38	1.000	17.38	No	
	XS_Asphalt Base Shld:	5.33	19.76	1.000	19.76	No	
	XS_Asphalt Surface Shld:	2.33	8.64	1.000	8.64	No	
	XS_Agg Base:	6.67	24.69	1.000	24.69	No	
	XS_Asphalt Base Pavt:	48.78	180.68	1.000	180.68	No	
	XS_Asphalt Surface Pavt:	9.35	34.65	1.000	34.65	No	
	XS_Rock Base:	167.59	620.77	1.000	620.77	No	
	XS_Rock_Bench:	257.00	1160.19	1.000	1160.19	No	
	Rock (removed):	3189.79	15315.31	1.000	15315.31	No	
	Total Rock:	25830.34	95611.74	1.000	95611.74		
	Cut:	2869.53	11671.09	1.000	11671.09	Yes	

- 162) We used the **Measure Area Tool**, located under the **OpenRoads Modeling Workflow** → **Drawing Tab** → **Measure Section**, to verify the area in the Excavated Rock and compared it to the Report on the previous page. The **Flood** Method was utilized. Also helpful is turning off all the levels in the Cross Section View except for **Volumes-Rock Excavated**.

Flatten Direction:	None
Area Unit:	Square '
Area:	8177.8168 Sq.'
Perimeter Unit:	US Survey Feet
Perimeter:	499.0742'



Flatten Direction:	None
Area Unit:	Square '
Area:	7111.9852 Sq.'
Perimeter Unit:	US Survey Feet
Perimeter:	491.0396'



Flatten Direction:	None
Area Unit:	Square '
Area:	5080.4771 Sq.'
Perimeter Unit:	US Survey Feet
Perimeter:	444.9639'



- 163) We used the **Measure Area Tool**, located under the **OpenRoads Modeling Workflow** → **Drawing Tab** → **Measure Section**, to verify the area in the Excavated Rock and compared it to the Report on the previous page. The **Flood** Method was utilized. Also helpful is turning off all the levels in the Cross Section View except for **Volumes-Rock Excavated**.

Flatten Direction:	None
Area Unit:	Square '
Area:	8177.8168 Sq.'
Perimeter Unit:	US Survey Feet
Perimeter:	499.0742'



Flatten Direction:	None
Area Unit:	Square '
Area:	7111.9852 Sq.'
Perimeter Unit:	US Survey Feet
Perimeter:	491.0396'



Flatten Direction:	None
Area Unit:	Square '
Area:	5080.4771 Sq.'
Perimeter Unit:	US Survey Feet
Perimeter:	444.9639'



